

[Manuals.plus](#) /

› [Gyfirmoie](#) /

› Gyfirmoie 63" Wide 6-Drawer Black Dresser Instruction Manual

## Gyfirmoie 63" Wide 6 Drawer Dresser

# Gyfirmoie 63" Wide 6-Drawer Black Dresser Instruction Manual

Model: 63" Wide 6 Drawer Dresser

## 1. INTRODUCTION

---

Thank you for choosing the Gyfirmoie 63" Wide 6-Drawer Black Dresser. This versatile furniture piece is designed to provide ample storage with its six spacious drawers, each featuring divided compartments, and includes modern conveniences such as a built-in charging station and customizable RGB LED lighting. Its sleek black design and robust construction make it a functional and stylish addition to any room.



*The Gyfimoie 63" Wide 6-Drawer Black Dresser, showcasing its modern design and integrated features.*


## 2. SAFETY INFORMATION

---








- Always follow assembly instructions carefully.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload drawers or shelves.
- Use the included anti-tipping kits to secure the dresser to a wall, especially in homes with children or pets, to prevent serious injury.
- Keep electrical components (charging station, LED lights) away from water and moisture.
- Unplug the charging station and LED lights before cleaning or moving the dresser.

**RGBW**

# Multiple Color RGB Light Strip

**APP  
Control**RGB  
ColorsLight  
ControlMic  
ModeMusic  
ModeTiming  
Function**key  
Control****Sync Your Lights with Your Favourite Music****Light Off Status**

OFF/ON

**Light On Status**

*Detail showing the anti-tip hardware for enhanced safety and stability.*

## 3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included parts list in your package for specific quantities.

### 3.1. Main Components

- Top Panel
- Bottom Panel
- Side Panels (Left & Right)
- Back Panels
- Drawer Fronts (6)
- Drawer Sides & Backs
- Drawer Bottoms
- Internal Dividers for Drawers
- Open Cubby Dividers

### 3.2. Hardware & Accessories

- Screws, Dowels, Cam Locks
- Drawer Slides (Left & Right sets)
- Anti-tipping Kit
- Built-in Charging Station (2 AC outlets, 2 USB ports)
- RGB LED Light Strip with Controller
- Power Cord

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is designed to be straightforward with clearly labeled parts and step-by-step instructions. It is recommended to have a screwdriver and a drill for efficient assembly. Please refer to the detailed assembly video for visual guidance.

### 4.1. Assembly Video Guide

*Official installation video for the 6-drawer dresser, provided by Gyfimoie Distributor.*

### 4.2. Step-by-Step Guide

1. **Prepare the Base:** Attach the wooden dowels and cam locks to the bottom panel.
2. **Install Cubby Dividers:** Secure the internal dividers for the open cubbies onto the bottom panel.
3. **Attach Drawer Slides:** Fasten the drawer slides to the side panels and internal cubby dividers. Ensure correct orientation for left (CL) and right (CR) slides.
4. **Assemble the Frame:** Connect the side panels and top panel to the assembled base and cubby dividers.
5. **Install LED Lights:** Carefully place and secure the RGB LED light strip along the designated channel on the underside of the top panel. Connect the power cord and controller.
6. **Install Charging Station:** Insert the built-in charging station into its designated cutout on the top panel and secure it.
7. **Assemble Drawers:** For each of the six drawers, assemble the drawer box using the provided sides, back, and bottom. Insert the internal dividers as desired. Attach the drawer fronts and the corresponding drawer slides (DL/DR).
8. **Insert Drawers:** Carefully slide all six assembled drawers into their respective tracks on the dresser frame.
9. **Secure Anti-Tipping Kit:** Attach the anti-tipping hardware to the back of the dresser and to a wall stud according to the instructions provided with the kit.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Using the Charging Station

The dresser is equipped with a convenient charging station featuring 2 AC outlets and 2 USB ports. Simply plug the dresser's main power cord into a wall outlet. You can then plug in your devices directly to the AC outlets or use USB cables for charging phones, tablets, and other compatible electronics.

# Spacious Storage Capacity

Organize and categorize your belongings to suit your lifestyle



## 12 Private Storage Drawers

*The integrated charging station provides easy access to power for your devices.*

### 5.2. Controlling the RGB LED Lights

The RGB LED lighting system can be customized to create your desired ambiance. Use the included controller or a compatible app (if available) to:

- Change between over 60,000 vibrant colors.
- Adjust brightness levels.
- Select various lighting modes (e.g., static color, fading, flashing).
- Activate music sync mode for dynamic lighting effects.

*Video demonstrating the various color options and effects of the LED lights.*

# Dresser with Built-in Charging Station



*Illustration of the RGB LED light strip features and control options.*

## 6. MAINTENANCE

---

### 6.1. Cleaning

To maintain the sleek appearance of your dresser, wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the laminate finish. For spills, clean immediately to prevent staining.

### 6.2. General Care

- Periodically check all fasteners and tighten if necessary to ensure stability.
- Avoid placing hot items directly on the surface; use coasters or protective pads.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or discoloration.

## 7. TROUBLESHOOTING

---

### 7.1. Drawers Not Sliding Smoothly

- Check that the drawer slides are correctly installed and aligned.
- Ensure no obstructions are in the drawer tracks.
- Verify that the dresser is on a level surface.

## 7.2. LED Lights Not Working

- Confirm the power cord is securely plugged into both the dresser and a working wall outlet.
- Check the connection between the LED strip and its controller.
- Ensure the power outlet is functional by testing with another device.



## 7.3. Charging Station Not Functioning

- Verify the dresser's main power cord is plugged into a live outlet.
- Test the charging station with different devices and cables to rule out device-specific issues.

# 8. SPECIFICATIONS

---

Feature	Detail
Brand	Gyfimoie
Model Name	63" Wide 6 Drawer Dresser
Color	Black
Material	Engineered Wood
Product Dimensions	15.28"D x 63"W x 30.71"H
Item Weight	101 Pounds
Number of Drawers	6 (with double compartments)
Open Cubbies	4
Charging Station	2 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
LED Lighting	RGB (60,000+ colors), App Control, Music Mode, Timing Function
Special Features	Divided Compartments, Built-In Charging Station, RGB LED Lights, Anti-tipping Kit



*Detailed dimensions of the dresser and its drawers.*

## 9. WARRANTY & SUPPORT

---

Gyfirmoie ensures each product is thoroughly checked before shipment. If you encounter any issues or have questions regarding your dresser, our customer service team is available to resolve any concerns within 24 hours. Please contact us through the retailer's platform or visit the official Gyfirmoie store for assistance.

For further information or to explore other products, visit the [Gyfirmoie Store](#).