

U`King ZQ07010

U`King LED Pinpoint Stage Light ZQ07010 User Manual

Brand: U`King | Model: ZQ07010

1. INTRODUCTION

Thank you for purchasing the U`King LED Pinpoint Stage Light ZQ07010. This high-performance lighting fixture is designed to create dynamic and vibrant lighting effects for various events, including clubs, parties, stages, and home entertainment. Featuring a powerful 15W RGBW LED, DMX512 compatibility, and multiple control modes, this light offers versatility and ease of use. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image: U'King LED Pinpoint Stage Light ZQ07010, showcasing its compact design and mounting bracket.

2. PRODUCT FEATURES

- **High-Quality Light Performance and Energy Saving:** Equipped with a high-brightness 10W RGBW 4-in-1 / White LED, delivering vivid and uniform light with low power consumption (12W). A 25° beam angle and unique optical design allow for beautiful RGBW color mixing, strobe, and dimming effects.
- **Compact and Easy to Use:** Small and lightweight design ensures easy portability and flexible installation (can be placed or hung). Clear function display with 4 LED tubes and menu buttons simplifies operation, even for beginners. Multiple lights can be operated simultaneously with a single switch.
- **High Durability:** Constructed from durable ABS material with an integrated design for robustness. Features an excellent heat dissipation structure and temperature protection function for long-term stable use and extended lifespan. Silent design ensures quiet operation.
- **Control Modes:** Supports DMX 512, Master-Slave, and Sound Control modes. Offers precise light control with 6 channels, covering various wavelengths (red, green, blue, white) for creative lighting expressions.
- **Ideal for Various Scenes:** Suitable for a wide range of applications including clubs, DJ shows, theaters, TV

studios, rental purposes, home parties, band lives, and wedding venues, enhancing the atmosphere of any setting.

3. SETUP

1. **Unpacking:** Carefully remove the light fixture and all accessories from the packaging. Inspect for any signs of damage during transit.
2. **Mounting:** The light can be placed on a flat surface or mounted using the included bracket. Ensure the mounting surface or structure is stable and can support the weight of the fixture. Use appropriate clamps or screws (not included) for secure installation.
3. **Power Connection:** Connect the power cord to the fixture's power input and then to a suitable power outlet (AC 100-240V, 50/60Hz). Ensure the power source matches the fixture's requirements.
4. **DMX Connection (Optional):** If using DMX control, connect a DMX cable from your DMX controller to the DMX IN port of the first fixture. For multiple fixtures, connect from the DMX OUT of the first fixture to the DMX IN of the next, and so on (daisy-chaining).

4. OPERATING MODES

The U`King LED Pinspot Stage Light ZQ07010 offers three primary control modes:

- **DMX 512 Mode:** This mode allows for professional control using a DMX controller. Set the DMX address for each fixture using the menu buttons and LED display. Refer to the DMX channel chart (usually provided in a separate DMX manual or on the product itself) for specific channel functions (e.g., dimmer, strobe, color control).
- **Master-Slave Mode:** Connect multiple fixtures via DMX cables. Set one fixture as the 'Master' and the others as 'Slave'. The slave units will then mirror the master unit's operations, allowing for synchronized lighting effects without a dedicated DMX controller.
- **Sound Control Mode:** The fixture's built-in microphone detects ambient sound and synchronizes lighting effects to the beat of the music. This mode is ideal for parties and events where dynamic, sound-reactive lighting is desired.
- **Auto Mode:** The fixture runs through pre-programmed lighting sequences automatically. This mode is suitable for quick setup and continuous lighting effects without external input.

Use the 4 LED tubes and menu buttons on the fixture to navigate through modes and adjust settings.

5. MAINTENANCE

- **Cleaning:** Regularly clean the lens and housing with a soft, lint-free cloth. For stubborn dirt, use a mild glass cleaner. Ensure the fixture is unplugged before cleaning.
- **Inspection:** Periodically check power cables, DMX cables, and mounting hardware for wear or damage. Replace any damaged components immediately.
- **Storage:** When not in use, store the fixture in a dry, dust-free environment. If storing for extended periods, consider using the original packaging or a protective case.
- **Ventilation:** Ensure proper ventilation around the fixture during operation to prevent overheating. Do not block ventilation openings.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power / Light does not turn on	Power cable disconnected; No power from outlet; Faulty fuse	Check power cable connection; Test outlet with another device; Replace fuse if necessary.
No light output in DMX mode	Incorrect DMX address; DMX cable issue; Controller not sending signal	Verify DMX address setting; Check DMX cable connections; Ensure DMX controller is active and sending data.
Light not responding to sound	Sound control mode not activated; Microphone sensitivity too low; No sound detected	Activate Sound Control mode; Increase microphone sensitivity via menu; Ensure sufficient sound is present.
Fixture overheating	Poor ventilation; Blocked fan/vents	Ensure adequate space around the fixture; Clear any obstructions from vents.

7. SPECIFICATIONS

Specification	Detail
Brand	U`King
Model Number	ZQ07010
Product Dimensions	21 x 18 x 10.2 cm
Product Weight	670 g
Light Source Type	LED (Light Emitting Diode)
LED Power	10W RGBW 4-in-1 / White LED
Power Consumption	12W
Beam Angle	25°
Control Modes	DMX 512, Master-Slave, Sound Control, Auto Mode
DMX Channels	6 Channels
Power Source	Corded Electric
Housing Material	ABS
Color	Black

8. SAFETY INFORMATION

- Always disconnect the power supply before cleaning or servicing the fixture.
- Do not look directly into the LED light source when the fixture is operating, as it may cause eye strain or damage.
- Ensure the fixture is installed in a well-ventilated area to prevent overheating.

- Keep the fixture away from moisture, water, and flammable materials.
- Only use the fixture with the specified voltage and frequency.
- Do not attempt to repair the fixture yourself. Refer all servicing to qualified personnel.

9. WARRANTY AND SUPPORT

U`King products are manufactured to high standards and undergo strict quality control. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. For warranty claims, technical support, or any questions regarding your U`King LED Pinspot Stage Light ZQ07010, please contact your retailer or U`King customer service. Please retain your proof of purchase for warranty purposes.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question