

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [AMERLIFE](#) /

› AMERLIFE 4-Piece Bedroom Furniture Set Instruction Manual (Models CNS037, CNS089, CNS091)

## AMERLIFE CNS037+CNS089+CNS091

# AMERLIFE 4-Piece Bedroom Furniture Set Instruction Manual

Models: CNS037, CNS089, CNS091

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, and maintenance of your AMERLIFE 4-Piece Bedroom Furniture Set. This set includes two nightstands with charging stations, one 8-drawer dresser with LED lighting, and one 5-drawer chest with a lift-top mirror. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your furniture.



Image 1.1: Overview of the AMERLIFE 4-Piece Bedroom Furniture Set, including the 8-drawer dresser, 5-drawer chest, and two nightstands.

## 2. SAFETY INFORMATION

---

Please observe the following safety precautions to prevent injury or damage to the product:

- Exercise caution around sharp edges during assembly and use.
- Follow all assembly instructions carefully to prevent injury and ensure structural integrity.
- Be cautious of slippery surfaces due to the high gloss finish.
- Keep the furniture away from direct heat sources to prevent damage to the finish and materials.
- Always use the provided anti-tip devices to secure the dresser and chest to the wall, especially in households with children or pets, to prevent tipping hazards.

## 3. PACKAGE CONTENTS

---

Your AMERLIFE 4-Piece Bedroom Furniture Set includes the following components:

- **Two (2) Nightstands:** Each with a charging station (2 AC outlets, 1 USB, 1 Type-C port).
- **One (1) 8-Drawer Dresser:** Features LED lighting with 3 color modes.
- **One (1) 5-Drawer Chest:** Includes a lift-top mirror with divided compartments.
- All necessary hardware and assembly tools.
- Detailed assembly instructions.

## 4. SETUP AND ASSEMBLY

---

Assembly of the AMERLIFE Bedroom Furniture Set requires careful attention to detail. Each cabinet includes step-by-step instructions and clearly labeled parts to facilitate the process. It is recommended that two adults assemble each cabinet, with an estimated assembly time of approximately 1.5 hours per cabinet.

### 4.1. General Assembly Guidelines

1. **Unpack Components:** Carefully unpack all boxes and lay out all parts on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Verify that all parts listed in the instruction manual are present.
2. **Identify Hardware:** Separate and identify all hardware components using the provided labels.
3. **Follow Instructions:** Refer to the specific assembly manual provided with each furniture piece. Follow the diagrams and written steps precisely.
4. **Secure Connections:** Ensure all screws, bolts, and fasteners are tightened securely, but do not overtighten, which can strip threads or crack wood.
5. **Anti-Tip Device Installation:** For the dresser and chest, install the anti-tip device as instructed in the manual. This is a critical safety step.



Image 4.1: Detailed dimensions for the 8-drawer dresser, 5-drawer chest, and nightstands, useful for planning placement and assembly.

## 5. OPERATING INSTRUCTIONS

### 5.1. Nightstands with Charging Station

Each nightstand is equipped with a convenient charging station integrated into the top surface. This station includes two standard AC outlets, one USB port, and one Type-C port.

- Power Connection:** Connect the power cord extending from the back of the nightstand to a standard wall outlet.
- Using AC Outlets:** Plug your electronic devices (e.g., lamps, alarm clocks) into the 125V/12A AC outlets.
- Using USB/Type-C Ports:** Connect your compatible devices (e.g., smartphones, tablets) to the 5V/2A USB or Type-C ports for charging.

# Ample Storage Space



Open Shelf

Two Drawers with Metal Handles

Smooth Metal Slide Rail

Image 5.1: A nightstand featuring an open shelf, two drawers, and a visible charging station on the top surface.

# Glass Top & Charging Station



**Power Outlet**  
[ 125V / 12A ]



**USB Port & Type-c**  
[ 5V / 2A ]



**5.9-Foot**  
[ POWER CORD LENGTH ]

Image 5.2: Close-up view of the charging station on the nightstand, showing the power outlets, USB, and Type-C ports.

## 5.2. 5-Drawer Chest with Lift-Top Mirror

The 5-drawer chest features a unique lift-top design that reveals a mirror and divided storage compartments.

1. **Accessing Mirror and Compartments:** Gently lift the top panel of the chest. The panel will reveal a built-in mirror and several compartments suitable for jewelry, cosmetics, or other small items.
2. **Closing the Top:** Carefully lower the top panel until it rests securely in its closed position.

# 6 STORAGE COMPARTMENTS

Achieve Orderly Storage



Image 5.3: The 5-drawer chest with its top open, revealing six storage compartments designed for jewelry, cosmetics, perfume, and skincare items.



Image 5.4: The 5-drawer chest with its top panel lifted, showcasing the built-in makeup mirror and the foldable visible glass desktop.

### 5.3. 8-Drawer Dresser with LED Light

The 8-drawer dresser features integrated LED lighting with adjustable color modes to enhance your bedroom ambiance.

1. **Power Connection:** Ensure the dresser's power cord is connected to a standard wall outlet.
2. **Activating LED Lights:** Use the provided remote control to turn the LED lights on or off.
3. **Changing Light Modes:** The LED lights offer three color modes: 3000K Warm Light, 4000K Natural Light, and 6000K Cool Light. Select your desired mode using the remote control.

# ADJUSTABLE 3 LIGHTING MODE

Perfectly adaptable to any life scenario — whether you're getting ready or unwinding.



**3000K Warm Light**



**4000K Natural Light**



**6000K Cool Light**



*Easy mode selection via remote control*



Image 5.5: The 8-drawer dresser demonstrating the three adjustable LED lighting modes: 3000K Warm Light, 4000K Natural Light, and 6000K Cool Light, with remote control for easy selection.

## Modern Storage Cabinet with 8 Drawers & LED Light



Image 5.6: The 8-drawer dresser with multiple drawers open, illustrating its ample storage capacity for various items like shirts, toys, pants, socks, and books.

## 6. MAINTENANCE

Proper care and maintenance will help preserve the appearance and functionality of your AMERLIFE furniture set.

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the high gloss UV finish.
- **Spills:** Clean spills immediately with a soft, dry cloth to prevent staining or damage to the finish.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If necessary, clean any dust or debris and apply a silicone-based lubricant sparingly.
- **Hardware:** Occasionally check all screws and fasteners to ensure they remain tight. Retighten if loose.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.

## 7. TROUBLESHOOTING

This section addresses common issues you might encounter with your furniture set.

## 7.1. General Issues

- **Wobbly Furniture:** Ensure all assembly hardware is securely tightened. Check that the furniture is placed on a level surface. Adjust glides if present.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned. Check for any obstructions or debris in the tracks. A small amount of silicone lubricant can improve movement.
- **Scratches on High Gloss Finish:** Minor scratches may be buffed out with specialized polishing compounds designed for high-gloss surfaces. For deeper scratches, professional repair may be required.

## 7.2. Electrical Features (Nightstands, Dresser)

- **Charging Station Not Working:**
  - Ensure the nightstand's power cord is securely plugged into a functional wall outlet.
  - Check if the wall outlet itself is receiving power (test with another device).
  - Verify that the device you are trying to charge is compatible and its cable is functioning correctly.
- **LED Lights Not Functioning:**
  - Confirm the dresser's power cord is plugged into a live wall outlet.
  - Check the remote control's battery.
  - Ensure there are no obstructions between the remote and the dresser's sensor.

If you encounter issues not covered here, please contact AMERLIFE customer support for assistance.

## 8. SPECIFICATIONS

Feature	Detail
Brand	AMERLIFE
Model Numbers	CNS037 (Nightstand), CNS089 (5-Drawer Chest), CNS091 (8-Drawer Dresser)
Material	Engineered Wood, Glass, Metal
Finish	High Gloss UV Finish
Color	White
Total Drawers	17 (8 in dresser, 5 in chest, 2 per nightstand)
Dresser Dimensions (L x W x H)	47.2 x 15.8 x 34.6 inches
Chest Dimensions (L x W x H)	31.5 x 15.7 x 50.2 inches
Nightstand Dimensions (L x W x H)	23.6 x 17.7 x 20.2 inches
Item Weight	111.3 pounds
Nightstand Charging Station	2 AC Outlets (125V/12A), 1 USB Port (5V/2A), 1 Type-C Port (5V/2A), 5.9-foot power cord

Feature	Detail
Dresser LED Lighting	3 Color Modes (3000K Warm, 4000K Natural, 6000K Cool), Remote Control
Special Features	Anti-tip device, Aluminium Alloy Handles, Smooth Sliding Drawers, Solid Base
Product Care Instructions	Wipe with Damp Cloth

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact AMERLIFE customer service directly. Ensure you have your model number (CNS037, CNS089, CNS091) and proof of purchase available when contacting support.

You can typically find contact information on the manufacturer's website or through your retailer.

