

## EINSEO B0FRMCX678

# EINSEO Male Masturbator Instruction Manual

Model: B0FRMCX678

## 1. PRODUCT OVERVIEW

The EINSEO Male Masturbator is designed to provide a versatile and satisfying experience with advanced features. It incorporates a diamond-shaped design for comfortable handling and a 3-section detachable structure for easy maintenance. The device offers multiple stimulation options, including 5 adjustable suction levels and 9 vibration modes, controlled via an intuitive LCD display or a dedicated smartphone application.



Image: Overview of the EINSEO Male Masturbator, showcasing its diamond design, control buttons, and internal structure with dual motors, 5-speed suction, 9-speed vibration, and a 3D realistic soft sleeve.

### Key Features:

- **Diamond-Shaped Design:** Ergonomic waistline for a secure and comfortable grip.
- **3-Section Detachable Structure:** Facilitates easy cleaning and maintenance.
- **5 Sucking Modes:** Adjustable suction levels for varied intensity.
- **9 Vibrating Modes:** Multiple vibration patterns for diverse sensations.

- **Automatic Suction Technology:** Delivers powerful and consistent sensations.
- **LCD Display:** Provides clear visual feedback on current settings.
- **APP Control:** Seamless control and enhanced features via a smartphone application.
- **3D Realistic Soft Channel:** Made from premium materials, designed to accommodate various sizes.

## 2. SETUP AND FIRST USE

### 2.1 Charging the Device

Before first use, fully charge the device. Connect the provided USB charging cable to the charging port on the device and a suitable USB power source. The LCD display will indicate charging status.

- **Charging Time:** Approximately 270 minutes (4.5 hours).
- **Usage Time:** Approximately 50 minutes on a full charge.



Image: The device connected to its charging cable, illustrating the charging process and indicating the charging and usage times.

## 2.2 App Installation and Connection

For enhanced control and features, download the JOYHUB app on your smartphone. The app allows for personalized settings and interactive experiences.

1. Scan the QR code provided in the product packaging or visit [joyhub.net/app](http://joyhub.net/app) to download the JOYHUB app.
2. Ensure your device is charged and powered on.
3. Open the JOYHUB app on your smartphone and follow the on-screen instructions to pair with your EINSEO Male Masturbator via Bluetooth.




Image: A smartphone showing the JOYHUB app interface, with QR codes for Android and iOS app downloads.

## 2.3 Assembly

The device features a 3-section detachable design for ease of cleaning and assembly. Ensure all sections are securely connected before use.

- Align the internal sleeve with the main body.
- Gently push and twist until the components are firmly in place.

## 3. OPERATING INSTRUCTIONS

### 3.1 Power On/Off

- To power on, press and hold the Suction Button (indicated by three wavy lines) for 3 seconds. The LCD display will illuminate.
- To power off, press and hold the Suction Button again for 3 seconds.

### 3.2 Adjusting Sucking Modes

- With the device powered on, short press the Suction Button to cycle through the 5 available sucking modes.
- The current mode will be displayed on the LCD screen.



Image: An illustration of the internal mechanism demonstrating the intense suction effect within the device.

### 3.3 Adjusting Vibrating Modes

- While the device is in standby mode or operating, short press the Vibration Button (indicated by a single wavy line) to switch between the 9 vibration modes.
- The LCD display will show the active vibration mode.

# DUAL SENSATION DELIGHT



Image: An internal view highlighting the combined suction and vibration elements, illustrating the 'Dual Sensation Delight' feature.

## 3.4 Using APP Control

Once connected to the JOYHUB app, you can access a wider range of controls and interactive features:

- **Adjust Settings:** Precisely control suction and vibration intensity and patterns.
- **Explore Modes:** Access various app-exclusive modes such as Recommended, Video, DIY, Sound, AI Lover, and Game modes.
- **Sound Control:** Utilize the app to synchronize sensations with audio input, creating a unique experience.

# APP-CONTROLLED PLEASURE





-  Recommended
-  Video
-  DIY
-  Sound



Image: A smartphone screen showing the JOYHUB app interface, demonstrating app-controlled pleasure with various mode options.




Image: An illustration depicting users engaging with the sound-controlled features of the app, where sound undulations influence the device's sensations.

## 4. MAINTENANCE AND CARE

---

### 4.1 Cleaning

Regular cleaning is essential for hygiene and to prolong the product's lifespan. The 3-section detachable structure allows for thorough cleaning.

1. Disassemble the device by separating the internal sleeve from the main body.
2. Clean the internal sleeve thoroughly with warm water and a mild, toy-safe soap. Rinse completely.
3. Wipe the exterior of the main body with a damp cloth. **Important:** Do not immerse the main body (motor part) in water to prevent damage.
4. Allow all components to air dry completely before reassembling or storing.



Image: The device disassembled into its main components, illustrating the simple structure for easy cleaning. A warning is included to avoid water ingress into the motor part.

### 4.2 Storage

- Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Keep out of reach of children.

## 5. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device fully (refer to Section 2.1).
App cannot connect to the device.	Bluetooth is off; device is off; app permissions not granted.	Ensure device is on and charged. Turn on Bluetooth on your phone. Check app permissions. Try restarting both the device and the app.
Device is unusually noisy.	Internal bullet/vibration unit misaligned.	Disassemble the device and ensure the internal sleeve and vibration unit are correctly aligned and seated according to the sleeve's pattern. Reassemble carefully.
Suction/Vibration not working.	Low battery; mode not selected.	Charge the device. Press the respective button to activate and cycle through modes.

## 6. SPECIFICATIONS



Image: A visual representation of the product specifications, including materials, dimensions, battery, and performance metrics.

Feature	Detail
Material	ABS, Silicone, TPE
Size (L x W x H)	245mm x 85mm x 70mm (9.6 x 3.3 x 2.8 inches)
Insertable Length	13cm / 5.2 inches
Diameter (Outer Soft Meat)	80mm
Weight	804g (including inner container)
Battery	Lithium Battery - 1800mAh
Charging Time	270 minutes
Usage Time	50 minutes
Sucking Frequency	5 frequencies
Vibration Frequency	9 frequencies
Maximum Noise	50dB (at 10cm/4 inches distance)
Package Dimensions	10.8 x 4.3 x 4.3 inches; 1.87 Pounds

## 7. SAFETY INFORMATION

---

- Clean the product thoroughly before and after each use.
- Use only water-based lubricants with this product. Oil-based lubricants may damage the material.
- Do not use if the product appears damaged or defective.
- If you experience any discomfort or irritation, discontinue use immediately and consult a healthcare professional.
- Keep the device away from extreme heat, cold, and direct sunlight.

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or any inquiries regarding your EINSEO Male Masturbator, please refer to the product packaging or contact EINSEO customer service directly. You may also visit the official EINSEO store on Amazon for additional resources: [EINSEO Store](#).