Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOVHEIYL TF-2202EB LE-TF009A

MOVHEIYL Replacement Remote Control User Manual

For VCK 13-Inch Tower Fan Models TF-2202EB and LE-TF009A

Introduction

This manual provides instructions for the MOVHEIYL Replacement Remote Control, designed for use with VCK 13-Inch Tower Fan models TF-2202EB and LE-TF009A. This remote control offers a convenient way to operate your tower fan from a distance, ensuring comfortable use.



Image: The MOVHEIYL Replacement Remote Control, emphasizing its durable ABS material, comfortable feel, and long lifespan.

Setup

The MOVHEIYL Replacement Remote Control requires minimal setup. No programming or pairing is needed. Simply install the batteries, and the remote is ready for use.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover by sliding or pressing the designated release tab.
3. Insert one CR2025 3V lithium button battery, ensuring the positive (+) side faces upwards as indicated inside the compartment. **(Battery not included)**
4. Close the battery compartment cover securely.



Image: The back of the remote control with the battery compartment open, showing the correct orientation for a CR2025 3V lithium battery. Batteries are not included with the remote.

Once batteries are installed, the remote control is ready to operate your compatible VCK tower fan.

Operating Instructions

This remote control provides full functionality for your VCK 13-Inch Tower Fan (TF-2202EB, LE-TF009A). Ensure there is a clear line of sight between the remote control and the fan's infrared receiver for optimal performance. The remote operates using infrared technology with a maximum range of up to 10 meters (approximately 40 feet).



Image: The remote control positioned near a tower fan in a living room setting, highlighting its immediate usability without complex setup or pairing.

Remote Control Functions

- **POWER:** Turns the fan On or Off.
- **SPEED:** Adjusts the fan's speed settings.
- **OSC (Oscillation):** Activates or deactivates the fan's oscillation feature.
- **TIMER:** Sets the fan's automatic shut-off timer.
- **MODE:** Cycles through different fan modes (e.g., Normal, Natural, Sleep).



Image: A family relaxing in a living room with a tower fan, illustrating the ease of controlling the fan with the MOVHEIYL remote. Key features like stable link and fast response are highlighted.



Image: The remote control shown with a tower fan, visually representing its wide operating range of up to 40 feet, allowing control from various points in a room.



Image: The remote control and a tower fan, illustrating the ability to switch between different fan modes (Normal, Natural, Sleep) and adjust wind speeds for reliable performance.

Maintenance

Proper maintenance ensures the longevity and reliable performance of your remote control.

Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or alcohol, as these can damage the surface.

Battery Replacement

- Replace the CR2025 battery when the remote's range decreases or it stops responding.
- Follow the battery installation steps outlined in the Setup section.
- Dispose of used batteries responsibly according to local regulations.

Troubleshooting

If you experience issues with your remote control, refer to the following common solutions:

- **Remote not responding:**
  - Check if the battery is installed correctly with the positive (+) side facing up.
  - Replace the battery with a new CR2025 battery.
  - Ensure there are no obstructions between the remote control and the fan's infrared receiver.
  - Confirm you are within the operating range (up to 10 meters / 40 feet).
- **Intermittent response:**
  - The battery may be low; replace it.
  - Ensure you are pointing the remote directly at the fan.

If problems persist after trying these steps, please contact customer support.

Specifications

Brand	MOVHEIYL
Compatible Models	VCK 13-Inch Tower Fan TF-2202EB, LE-TF009A
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 meters (approximately 40 feet)
Power Source	1 x CR2025 3V Lithium Button Battery (not included)
Material	High-quality ABS
Special Feature	Ergonomic design, No programming required

Warranty and Support

For any questions or concerns regarding your MOVHEIYL Replacement Remote Control, please do not hesitate to contact the seller directly. We are committed to assisting you with any issues you may encounter and ensuring your satisfaction.
Please refer to your purchase documentation for specific warranty details and contact information.

© 2026 MOVHEIYL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRMNQNVX

More documents and user manuals: **https://manuals.plus/**