

Newbealer NB282C

Newbealer Heavy-duty Steam Cleaner NB282C User Manual

Model: NB282C

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Newbealer Heavy-duty Steam Cleaner NB282C. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Power Supply:** This appliance is designed for 110~125-volt outlets only. Do not use with other voltage systems.
- **Water Tank:** Do not overfill the water tank. Use distilled or demineralized water to prevent mineral buildup.
- **Hot Steam:** Steam is extremely hot. Keep hands, face, and body away from the steam nozzle during operation. Do not direct steam at people, pets, or electrical appliances.
- **Child and Pet Safety:** The steam cleaner is designed with a multi-layer safety mechanism, including pressure and temperature controls and overpressure protection. However, always supervise children and pets when the appliance is in use. Keep the device out of reach of children when not in use.
- **Maintenance:** Always unplug the steam cleaner and allow it to cool completely before performing any maintenance or cleaning.
- **Chemical-Free Cleaning:** This steam cleaner uses only water for cleaning, making it safe for environments with children and pets. Do not add cleaning solutions or chemicals to the water tank.

Child & Pet Safe with the Chemical-Free Steam



Image: The Newbealer Steam Cleaner is designed with internal intelligent control of pressure and temperature, ensuring safety for use around children and pets.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Main Body of Steam Cleaner
- 1 x Exclusive Magic Brush (with 4 replaceable scrub heads)
- 2 x Extension Rods
- 8 x Washable Microfiber Pads
- 2 x Nylon Brushes
- 2 x Brass Brushes
- 1 x Microfiber Bonnet
- 1 x Mop Head
- 1 x Spade
- 1 x Squeegee
- 1 x Steam Jet Nozzle

- 1 x Gap Brush
- 1 x Measuring Cup

3. SETUP AND ASSEMBLY

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Use the provided measuring cup to fill the stainless steel boiler with distilled or demineralized water. Do not exceed the maximum fill line. The 1.5L boiler provides approximately 45 minutes of continuous steam.
3. **Attach Accessories:** Depending on your cleaning task, attach the desired accessory (e.g., steam jet nozzle, brush, mop head) to the main unit or extension rod. For floor cleaning, attach the mop head and secure a microfiber pad.
4. **Connect Power:** Plug the steam cleaner into a grounded 110~125-volt electrical outlet.



Image: The microfiber pads are designed to perfectly fit the Newbealer Steam Cleaner's floor tool for easy attachment.

4. OPERATING INSTRUCTIONS

4.1 General Operation

1. **Power On:** Turn on the steam cleaner. Allow a few minutes for the water to heat up and steam to generate. The indicator light will typically change when ready.
2. **Steam Release:** Press the steam trigger or button to release steam. The cleaner delivers 5 bar max steam pressure for effective cleaning.
3. **Cleaning:** Direct the steam towards the surface to be cleaned. For stubborn dirt, use appropriate brush attachments.
4. **Power Off:** After use, turn off the steam cleaner and unplug it from the outlet.

4.2 Floor Cleaning

The Newbealer Steam Cleaner is suitable for various sealed flooring types, including hardwood, marble, laminate, and tile.

1. Attach the mop head and a clean microfiber pad.
2. Use the extension rods for comfortable upright cleaning.
3. Move the mop head slowly over the floor surface, allowing the steam to penetrate and clean. The 180° steering allows for easy maneuverability around furniture.



Image: The steam cleaner features a retractable handle and a mop head hook for convenient storage and multi-surface

cleaning.

4.3 Versatile Cleaning Applications

Utilize the various accessories for targeted cleaning:

- **Magic Brush:** Ideal for scrubbing tough grime and stains.
- **Nylon/Brass Brushes:** Use nylon for delicate surfaces and brass for more abrasive cleaning tasks like grout or metal.
- **Steam Jet Nozzle:** For concentrated steam on small areas or crevices.
- **Squeegee:** For streak-free cleaning of windows and mirrors.
- **Spade/Gap Brush:** For reaching into tight spaces and removing baked-on dirt.



Image: The steam cleaner can be used to clean car seats to loosen dirt and refresh, and to scrub wheel nooks with an extended pole.

5. MAINTENANCE

5.1 Cleaning the Unit

1. Ensure the unit is unplugged and completely cool before cleaning.

2. Wipe the exterior of the steam cleaner with a damp cloth. Do not use abrasive cleaners or solvents.
3. Empty any remaining water from the tank after each use to prevent mineral buildup.

5.2 Microfiber Pads Care

The included triple-layer microfiber mop pads are washable and designed for repeated cleaning.

- Remove pads from the mop head after use.
- Machine wash the pads with similar colors in warm water. Do not use bleach or fabric softeners, as these can reduce the pads' effectiveness.
- Tumble dry on low heat or air dry. The microfiber material is designed for strong water absorption and fast drying without fading in high temperatures.



Image: The efficient cleaning mop pads feature a sandwich mesh lining that allows steam to release easily for effective cleaning.

Replacement pads of microfiber material for effective cleaning, without fading in high temperature, strong water absorption




Image: The replacement pads are made of microfiber material, ensuring effective cleaning, strong water absorption, and resistance to fading in high temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam output	Unit not plugged in; water tank empty; insufficient heating time.	Ensure unit is plugged in; refill water tank; allow 3-5 minutes for heating.
Low steam pressure	Mineral buildup in boiler; low water level.	Descal the boiler (refer to maintenance); refill water tank.
Water leaking from nozzle	Condensation; accessory not properly attached.	This is normal at startup; ensure accessories are securely fastened.
Microfiber pad not cleaning effectively	Pad is dirty or worn out.	Replace with a clean pad; wash dirty pads as per instructions.

7. SPECIFICATIONS

- **Model:** NB282C
- **Power:** 1500W (estimated from image)
- **Voltage:** 110~125V
- **Steam Pressure:** 5 bar max
- **Boiler Capacity:** 1.5L
- **Continuous Steam Time:** Approximately 45 minutes
- **Boiler Material:** Premium Stainless Steel

Heavy-Duty Steam Cleaner

Conquer tough jobs—and grease, grime, stains, dirt vanish easily



**On-demand
steam power**



**5 bar
high-pressure**



**45 min
steady flow**



**1500W
steam drive**

Image: Key features of the Newbealer Heavy-Duty Steam Cleaner include on-demand steam power, 5 bar high-pressure, 45 minutes of steady flow, and a 1500W steam drive.

8. SUPPORT

For any questions, technical assistance, or support regarding your Newbealer Heavy-duty Steam Cleaner NB282C, please contact Newbealer customer service. Refer to the product packaging or the official Newbealer website for contact information.

