

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Furmax](#) /

› [Furmax Ergonomic Drafting Chair Instruction Manual](#)

Furmax MY0240833001AA

Furmax Ergonomic Drafting Chair Instruction Manual

Model: MY0240833001AA

INTRODUCTION

Thank you for purchasing the Furmax Ergonomic Drafting Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your chair. Please read this manual thoroughly before assembly and use.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly.
- Do not use power tools for assembly as this may overtighten screws and damage components.
- Do not stand on the chair.
- Do not use the chair if any parts are missing or damaged.
- Keep children away from the chair during assembly.
- Maximum weight capacity: 330 lbs (150 kg).

PACKAGE CONTENTS

Please verify that all components are included in your package:

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Footrest Ring
- Chair Base (5-star)
- Casters (5)
- Mechanism Plate
- Hardware Pack (screws, washers, Allen wrench)

SETUP AND ASSEMBLY

Follow these steps to assemble your Furmax Drafting Chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of the chair base legs. Push firmly until they click into place.
2. **Insert Gas Lift and Footrest:** Place the gas lift cylinder into the center hole of the assembled chair base. Slide the footrest ring over the gas lift cylinder and secure it at your desired height using the adjustment knob.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Secure it using the provided screws and Allen wrench. Ensure the front of the mechanism faces the front of the seat.
4. **Attach Backrest to Seat:** Connect the backrest to the seat cushion using the designated screws. Ensure a secure fit.
5. **Attach Armrests:** Secure the armrests to the seat cushion using the provided screws. Note that these armrests are designed to flip up.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.





Image showing the fully assembled Furmax Drafting Chair, highlighting the flip-up armrests and adjustable lumbar support. This provides a visual reference for the completed assembly.

OPERATING INSTRUCTIONS

Chair Height Adjustment

To adjust the chair's height, locate the lever on the right side beneath the seat.

- **To raise the seat:** Lift the lever while taking your weight off the seat. The seat will rise automatically. Release the lever at the desired height.
- **To lower the seat:** Lift the lever while remaining seated. The seat will lower. Release the lever at the desired height.

Footrest Adjustment

The footrest ring can be adjusted vertically along the gas lift cylinder. Loosen the knob on the footrest, slide it to the desired height, and then tighten the knob securely to lock it in place.

MULTI-DIMENSIONAL ADJUSTMENT

Meet your different usage needs



Chair Height Adjustable



Footrest Height Adjustable



Image illustrating the chair height adjustment lever and the footrest height adjustment mechanism. This demonstrates how to customize the chair's height and footrest position.

Flip-up Armrests

The armrests can be flipped up 90 degrees to save space or allow the chair to be pushed closer to a desk. Simply lift the armrests upwards until they lock into the vertical position. To lower them, gently pull them down.

Lumbar Support Adjustment

The chair features a 2-inch adjustable lumbar support. To adjust, grasp the lumbar support mechanism on the backrest and slide it up or down to find the most comfortable position for your lower back.

Ergonomic Backrest Design

Perfectly fit your body curves to protect your spine



Adjustable Lumbar Support



90° Flip-up Armrest



Image showing a person seated in the chair, highlighting the ergonomic backrest and the adjustable lumbar support feature. This illustrates how the chair conforms to the body for spinal protection.

MAINTENANCE

- **Cleaning:** Wipe down the chair with a soft, damp cloth. For mesh and fabric areas, use a mild soap solution if necessary, and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Caster Care:** Periodically check casters for hair or debris accumulation and clean as needed to ensure smooth rolling.
- **Hardware Check:** Every 3-6 months, check all screws and bolts to ensure they are tight. Retighten if necessary to maintain stability and safety.
- **Gas Lift:** The gas lift cylinder is maintenance-free. Do not attempt to disassemble it.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift lever not fully engaged or gas lift cylinder malfunction.	Ensure the lever is fully pulled. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check all assembly screws and tighten them securely. Ensure the gas lift is fully seated in the base and mechanism.
Casters do not roll smoothly.	Debris (hair, dust) caught in casters.	Remove any debris from the caster wheels. Ensure casters are fully inserted into the base.
Armrests do not flip up/down smoothly.	Mechanism obstruction or damage.	Check for any obstructions. If damaged, contact customer support for replacement parts.

SPECIFICATIONS

- **Model Name:** Furmax Draft Chair
- **Model Number:** MY0240833001AA
- **Brand:** Furmax
- **Color:** Black
- **Product Dimensions:** 20"D x 20"W x 43"H (Adjustable height up to 51"H)
- **Seat Depth:** 20 inches
- **Item Weight:** 34.1 pounds
- **Weight Capacity:** 330 lbs
- **Special Features:** Adjustable Height, Rolling Casters, Flip-up Armrests, Adjustable Lumbar Support, Adjustable Footrest
- **Fill Material:** Cotton, Memory Foam
- **Gas Lift:** Class 4

Product Dimensions

Recommended Weight Capacity 330LBS



Diagram illustrating the key dimensions of the Furmax Drafting Chair, including height, width, and depth. This provides a visual reference for the chair's size and adjustable range.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact Furmax customer service. Refer to your purchase documentation for specific warranty terms.

Contact Information:

- **Website:** Visit the [Furmax Store on Amazon](#)
- Please refer to your product packaging or the Furmax website for the most current contact details.

