

VEVOR 99153

VEVOR Electronic Dart Board Instruction Manual

Model: 99153 | Brand: VEVOR

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your VEVOR Electronic Dart Board. Please read this manual thoroughly before installation and operation to ensure proper functionality and to prevent damage. This electronic dartboard is designed for recreational use, offering a wide variety of games for multiple players.

2. SAFETY INFORMATION

- Use only soft-tip darts with this electronic dartboard. Do not use steel-tip darts, as they can damage the board and pose a safety risk.
- Ensure the dartboard is securely mounted to a stable surface before use.
- Keep children under 10 years old under adult supervision when playing.
- Do not throw darts at people or animals.
- Keep the dartboard away from water or excessive moisture.
- Unplug the power adapter when not in use or during cleaning.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x VEVOR Electronic Dart Board
- 6 x Dart Shafts with Flights (3 red, 3 blue)
- 50 x Replacement Soft Dart Tips
- 1 x USB Power Cable
- 2 x Plastic Expansion Anchors
- 2 x Screws
- 1 x User Manual (this document)




Figure 3.1: Included accessories with the VEVOR Electronic Dart Board.

4. SETUP & INSTALLATION

Follow these steps to set up your electronic dart board:

1. **Choose a Suitable Location:** Select a wall space that is clear of obstructions and provides enough room for players to throw darts safely. Ensure the wall can support the weight of the dartboard.
2. **Mark Mounting Points:** Determine the desired height for the center of the dartboard. The standard height for the bullseye is 5 feet 8 inches (1.73 meters) from the floor. Mark the positions for the two mounting screws.
3. **Install Mounting Hardware:** Drill pilot holes at the marked positions. Insert the plastic expansion anchors into the holes, then screw in the provided screws, leaving a small portion exposed for hanging the dartboard.
4. **Mount the Dart Board:** Align the keyhole slots on the back of the dartboard with the installed screws. Carefully slide the dartboard down until it is securely seated on the screws.
5. **Connect Power:** Plug the USB power cable into the dartboard's power input port and connect the other end to a suitable USB power adapter (not included) or a USB port.



Figure 4.1: Three-step quick installation guide for the dartboard.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on the dartboard, press the **ON/OFF** button located on the control panel.
- To power off, press the **ON/OFF** button again.

5.2 Game Selection

The dartboard features 43 game modes with over 320 variations. Refer to the game list printed on the dartboard's control panel for available games.

- Use the **GAME** button to cycle through the available game modes.
- Once a game is selected, press **ENTER** to confirm.

5.3 Player Selection

The dartboard supports up to 8 players.

- Press the **PLAYER** button to select the number of players.
- The LCD screen will display the current player's score and turn progress.

5.4 Scoring & Features

The large color LCD screen provides real-time feedback and includes several features to enhance gameplay:

- **Automatic Scoring:** The board automatically registers hits and updates scores on the LCD screen.
- **Interactive Sound:** Enjoy interactive scoring sounds that provide an engaging experience.
- **Invalid Dart Detection:** The system can detect darts that do not register correctly.
- **Cricket Mode:** Quick access to popular cricket games.
- **Single/Double Bullseye Option:** Customize bullseye rules for certain games.
- **Play Against Computer:** Challenge the built-in AI for solo practice.
- **Handicap Function:** Adjust game difficulty for players of different skill levels.

Track Every Score Clearly

Real-time feedback with color LCD screen



Supports USB Power Supply

5.0V/1000mA Dc

Figure 5.1: Detailed view of the LCD scoring screen and control panel.

5.5 Dart Usage

The dartboard features a honeycomb target design to minimize bounce-outs and is designed for use with soft-tip darts.

- Ensure darts are properly assembled with shafts and flights.
- Use only the provided soft-tip darts or compatible soft-tip darts to prevent damage to the board.
- If a dart tip breaks, replace it with one of the 50 included replacement tips.

Precise Hits, No Bounce-Outs

Honeycomb dartboard surface




Figure 5.2: Honeycomb target design for reduced bounce-outs.

6. MAINTENANCE

- **Cleaning:** Wipe the dartboard surface and control panel with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Dart Tips:** Regularly check dart tips for wear or damage. Replace broken or worn tips promptly using the provided replacements.
- **Storage:** When not in use for extended periods, store the dartboard in a dry, cool place away from direct sunlight.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dart not registering score	Dart did not hit a segment sensor; broken dart tip; power issue.	Ensure darts are thrown with sufficient force to activate sensors. Check and replace broken dart tips. Verify power connection.
Dartboard does not power on	Power cable not connected; faulty power adapter; power outlet issue.	Check if the USB power cable is securely connected. Try a different USB power adapter or power outlet.
Darts bounce out frequently	Worn dart tips; incorrect dart throwing technique.	Replace worn dart tips. Practice throwing technique to ensure darts land straight.
Buttons unresponsive	Temporary software glitch; debris under buttons.	Try turning the dartboard off and on again. Gently clean around the buttons.

8. SPECIFICATIONS

Feature	Detail
Brand	VEVOR
Model Name	Electronic Dart Board
Item Model Number	99153

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS), Polypropylene (PP)
Color	Black
Product Dimensions	22.44"W x 22.44"H (570 x 570 mm)
Item Dimensions (LxWxH)	19.65 x 19.65 x 22.44 inches (499 x 499 x 570 mm)
Target Area Diameter	15.5 inches
Item Weight	4.2 Pounds (1.90 kg)
Display	LCD Color Screen
Voltage/Current	5V / 1A
Number of Games	43 (320+ variations)
Max Players	8



Item Model Number: **99153**

Voltage/Current: **5V / 1A**

Display: **LCD Color Screen**

Target Area Diameter: **15.5 inch**

Main Materials: **PP & ABS**

Net Weight: **4.2 lbs / 1.90 kg**








Item Dimensions: **22.44 x 19.65 x 1.38 inch / 570 x 499 x 35 mm**


Figure 8.1: Product dimensions and key specifications.

9. WARRANTY & SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official VEVOR website. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - 99153

<div><p>VEVOR Affordable. Reliable. Home Improvement.</p></div> <div><p>ELECTRONIC DARTBOARD MODEL 99153</p></div>	<p>VEVOR Electronic Dartboard Model 99153 - User Manual and Game Guide</p> <p>Comprehensive user manual and game guide for the VEVOR Electronic Dartboard, Model 99153. Learn about setup, safety, game rules, and operations.</p>
<div><p>VEVOR® TOUGH TOOLS. HALF PRICE</p></div> <div><p>Technical Support and E-Warranty Certificate www.vevor.com/support</p></div> <div><p>Electrical Enclosure Product Description</p><p>Material: TIP-125TIP-438TIP-545 TIP-405TIP-435</p></div>	<p>VEVOR Electrical Enclosure Installation and Warranty Guide</p> <p>This guide provides detailed instructions for installing and using VEVOR TIP series electrical enclosures. It covers features, specifications, installation steps for locks, DIN rails, mounting plates, and wall mounting pendants, along with warranty information.</p>
<div><p>VEVOR</p></div> <div><p>Jumbo Soccer Darts Inflatable Game Set with Air Blower & Accessories</p></div> <div></div>	<p>VEVOR Jumbo Soccer Darts - Inflatable Game Set with Air Blower & Accessories</p> <p>Set up and enjoy the VEVOR Jumbo Soccer Darts inflatable game. This guide covers setup, included items, safety instructions, maintenance, and proper disposal for this fun outdoor activity.</p>
<div><p>VEVOR</p></div> <div><p>Jumbo Soccer Darts Setup and Game Guide</p></div> <div></div>	<p>Jumbo Soccer Darts - Setup and Game Guide</p> <p>A comprehensive guide to setting up and playing the VEVOR Jumbo Soccer Darts inflatable game. Includes step-by-step instructions, safety guidelines, and product information for this fun outdoor activity.</p>
<div><p>VEVOR® TOUGH TOOLS. HALF PRICE</p></div> <div><p>Technical Support and E-Warranty Certificate www.vevor.com/support</p></div> <div><p>PADDLE BOARD SUP-X Series</p></div>	<p>VEVOR SUP-X Series Paddle Board User Manual and Warranty Certificate</p> <p>Comprehensive guide for VEVOR SUP-X series paddle boards, covering product parameters, accessories, safety warnings, operation, and maintenance. Includes e-warranty information.</p>



Official manual for the VEVOR AH726 and AH726-EU Electronic Scoring Air Hockey Table,
including specifications, safety instructions, part lists, assembly, and maintenance guidance.