VGC919

Generic Vegas High Back Gaming Chair VGC919 Instruction Manual

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Generic Vegas High Back Gaming Chair, model VGC919. Please read all instructions carefully before assembly and use to ensure proper function and safety. This chair is designed for comfort and support during extended periods of sitting, featuring an ergonomic high back, adjustable components, and a pull-out footrest.

Safety Information

- Ensure all components are securely fastened before use. Regularly check for loose screws or parts.
- Do not stand on the chair. Use it only for sitting.
- Avoid placing heavy objects on the chair's armrests or backrest.
- Keep hands and fingers clear of moving parts during adjustment.
- Do not use the chair on uneven surfaces.
- Keep children away from the chair during assembly. Small parts may be a choking hazard.
- Maximum weight capacity: Refer to specifications. Do not exceed.

Package Contents

Please verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1x Backrest
- 1x Seat Base
- 2x Armrests
- 1x Gas Lift Cylinder
- 1x Gas Lift Cover
- 1x Five-Star Base
- 5x Caster Wheels
- 1x Mechanism Plate
- 1x Footrest Assembly

- 1x Lumbar Support Cushion
- 1x Headrest Cushion
- Hardware Kit (screws, washers, Allen wrench)
- Assembly Instructions (this document)

Assembly Instructions

Follow these steps carefully to assemble your gaming chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Step 1: Attach Caster Wheels to Base

Insert each of the five caster wheels into the holes at the end of each leg of the five-star base. Push firmly until they click into place.



Image: Illustration of the five-star base with caster wheels inserted into each leg.

Step 2: Install Gas Lift Cylinder

Place the gas lift cylinder into the center hole of the assembled five-star base. Then, slide the gas lift cover over the gas lift cylinder.

Step 3: Attach Mechanism Plate to Seat Base

Align the mechanism plate with the pre-drilled holes on the underside of the seat base. Ensure the front of the mechanism plate faces the front of the seat. Secure it with the provided screws and Allen wrench.

Step 4: Attach Armrests to Seat Base

Attach the armrests to the sides of the seat base using the designated screws. Ensure they are oriented correctly (left and right armrests).



Image: The seat base with both armrests securely fastened to its sides.

Step 5: Connect Backrest to Seat Base

Align the backrest with the brackets on the seat base. Secure it using the remaining screws. It may be helpful to have a second person assist with this step to hold the backrest in place.

Step 6: Attach Footrest Assembly

Slide the footrest assembly into the designated slots under the seat base. Ensure it moves smoothly in and out.



Image: A side view of the gaming chair with the footrest fully extended from beneath the seat.

Step 7: Place Assembled Seat onto Gas Lift

Carefully place the assembled seat (with backrest, armrests, and mechanism plate) onto the gas lift cylinder. The tapered hole in the mechanism plate should fit snugly over the top of the gas lift.

Step 8: Attach Cushions

Attach the lumbar support cushion and headrest cushion using their integrated straps or clips to the backrest as desired for additional comfort.

Operating Instructions

Height Adjustment

To adjust the chair's height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower

the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at the desired height.

Backrest Recline

To recline the backrest, pull the recline lever located on the right side of the chair, near the seat. Lean back to the desired angle and release the lever to lock it in place. To return to an upright position, pull the lever and lean forward.

Footrest Operation

To extend the footrest, pull the handle located under the front edge of the seat. The footrest will slide out. To retract it, push the footrest back under the seat until it is fully stored.



Image: A side view of the gaming chair demonstrating the footrest in its extended position, ready for use.

Maintenance

- **Cleaning:** Wipe the PVC upholstery with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.

- **Casters:** Periodically clean hair and debris from the caster wheels to ensure smooth movement.
- **Fasteners:** Every 3-6 months, check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Moving Parts:** Do not lubricate the gas lift cylinder. If any moving parts become stiff, ensure they are clean and free of obstructions.

Troubleshooting

Problem: Chair does not adjust height.

Solution: Ensure the gas lift lever is fully engaged. Check if the gas lift cylinder is properly seated in the base and mechanism plate. If the issue persists, the gas lift may need replacement.

Problem: Chair wobbles or feels unstable.

Solution: Check all assembly screws, especially those connecting the armrests, backrest, and mechanism plate to the seat. Ensure they are tightened securely. Verify the five-star base is fully assembled and casters are properly inserted.

Problem: Caster wheels do not roll smoothly.

Solution: Remove any hair, dust, or debris that may be caught in the wheels. Clean the wheel axles. Ensure the casters are fully inserted into the base.

Problem: Footrest is difficult to extend or retract.

Solution: Check for any obstructions in the footrest's sliding mechanism. Ensure the tracks are clean. Avoid forcing the footrest.

Specifications

Model Number	VGC919
Brand	Generic
Material	Polyvinyl Chloride (PVC), Nylon
Color	Black/Grey
Dimensions (L x W x Thickness)	86L x 63W x 7Th centimetres
Features	High back ergonomic design, Pull-out footrest, Nylon armrests, Nylon base
Manufacturer	Totally Home

Warranty and Support

Specific warranty details are not provided in this manual. For information regarding warranty coverage, technical support, or to order replacement parts, please contact the retailer or manufacturer directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Totally Home

© 2026 Generic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question