Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Smart Tech /
- > Smart Tech 32HH01K 32-inch HD Smart TV Instruction Manual

Smart Tech 32HH01K

Smart Tech 32HH01K 32-inch HD Smart TV Instruction Manual

Model: 32HH01K | Brand: Smart Tech

1. Introduction

Thank you for choosing the Smart Tech 32HH01K 32-inch HD Smart TV. This television combines a compact design with advanced features, offering a high-definition viewing experience and access to a world of entertainment through its integrated Whale OS smart platform. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new TV.




Image: Front view of the Smart Tech 32HH01K 32-inch HD Smart TV, showcasing its display and slim bezels.

2. WHAT'S IN THE BOX

Please check the contents of your product packaging. If any items are missing or damaged, contact your retailer.

- Smart Tech 32HH01K 32-inch HD Smart TV
- Remote Control
- Power Cable
- User Manual (this document)
- TV Stand (2 pieces)
- · Screws for Stand Installation

3. SETUP GUIDE

3.1 Stand Installation

- 1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
- 2. Identify the left and right stand pieces.
- 3. Align each stand piece with the corresponding screw holes on the bottom of the TV.
- 4. Securely fasten the stands using the provided screws. Do not overtighten.
- 5. Carefully lift the TV and place it on a stable, level surface.

3.2 Connecting Devices

The Smart Tech 32HH01K offers various connectivity options:

- HDMI Ports (x2): Connect external devices such as Blu-ray players, game consoles, or set-top boxes.
- USB Ports (x2): Connect USB storage devices for media playback or software updates.
- Ethernet (LAN) Port: For a wired internet connection.
- Wi-Fi: For wireless internet connection.
- Antenna/Cable Input: For connecting an aerial or cable TV signal.
- Optical Audio Output: For connecting to external audio systems.

Ensure all connections are secure before powering on the TV.





Image: Side view of the Smart Tech 32HH01K TV, illustrating the placement of various input/output ports.

3.3 Initial Power-On and First-Time Setup

- 1. Connect the power cable to the TV and then to a power outlet.
- 2. Press the Power button on the remote control or on the TV.
- 3. Follow the on-screen instructions to complete the initial setup, which typically includes:

- Language selection
- · Country/Region selection
- Network connection (Wi-Fi or Ethernet)
- Channel scanning (for antenna/cable TV)
- Time zone settings

4. OPERATING INSTRUCTIONS

4.1 Remote Control Overview

The remote control provides access to all TV functions. Insert two AAA batteries (not included) into the battery compartment.



Image: The Smart Tech TV remote control, highlighting dedicated buttons for popular streaming applications like Netflix, YouTube, Disney+, and Prime Video.

- Power Button: Turns the TV on or off.
- Number Buttons (0-9): Select TV channels directly.
- Volume Up/Down (+/-): Adjust the volume level.
- Channel Up/Down (P+/P-): Change TV channels.
- Navigation Buttons (Up/Down/Left/Right): Navigate menus and select options.
- OK Button: Confirm selections.
- Back Button: Return to the previous screen.
- Home Button (House icon): Access the Whale OS home screen.
- Source Button: Select input sources (HDMI, USB, TV).
- Dedicated App Buttons: Quick access to Netflix, YouTube, Prime Video, Disney+.

4.2 Smart TV Features (Whale OS)

Your Smart Tech TV runs on Whale OS, providing a user-friendly interface for accessing various applications and content.



Image: The Whale OS smart TV interface displaying various pre-installed streaming applications and content recommendations.

- **Home Screen**: Press the Home button to access the main Whale OS interface, where you can find installed apps, input sources, and settings.
- **Pre-installed Applications**: Enjoy instant access to popular streaming services like Netflix, YouTube, Prime Video, and Disney+.
- **App Store**: Explore and download additional applications from the Whale OS app store (internet connection required).
- **Miracast**: Wirelessly mirror the screen of compatible smartphones or tablets to your TV. Access this feature from the Whale OS home screen or input menu.

4.3 Input Selection

To switch between different connected devices or TV modes:

- Press the **Source** button on your remote control.
- A menu will appear on the screen listing all available inputs (e.g., HDMI1, HDMI2, USB, TV, AV).
- Use the navigation buttons to select your desired input and pressOK.

5. MAINTENANCE

5.1 Cleaning the TV

- Always unplug the TV from the power outlet before cleaning.
- Screen: Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (do not spray directly onto the screen).
- TV Body: Wipe the TV frame and stand with a soft, dry cloth. Avoid using abrasive cleaners, waxes, or solvents.

5.2 Software Updates

To ensure optimal performance and access to the latest features, it is recommended to keep your TV's software updated.

- Connect your TV to the internet.
- Navigate to the TV's settings menu (usually via the Home button).
- Look for a section like "System," "About," or "Software Update."
- Select "Check for Updates" and follow the on-screen prompts.

6. TROUBLESHOOTING

If you encounter any issues with your TV, refer to the following common problems and solutions before contacting support.

Problem	Possible Cause	Solution	
TV does not turn on	No power, remote control issues	Check power cable connection and outlet. Replace remote control batteries.	
No picture or sound	Incorrect input source, loose cables	Verify correct input source. Check all cable connections (HDMI, antenna).	
No internet connection	Wi-Fi issues, router problem	Check Wi-Fi settings on TV. Restart your router. Try a wired Ethernet connection.	
Remote control not responding	Low batteries, obstruction	Replace batteries. Ensure no obstructions between remote and TV sensor.	
Poor picture quality	Signal issue, settings	Check antenna/cable connection. Adjust picture settings (brightness, contrast).	

7. Specifications

Detailed technical specifications for the Smart Tech 32HH01K TV.

Feature	Specification	
Model Number	32HH01K	
Screen Size	32 inches (80 cm)	
Display Technology	LED	
Resolution	HD (1366 x 768 pixels)	
Refresh Rate	60 Hz	
Operating System	Whale OS	
Connectivity	Wi-Fi, Ethernet, 2x HDMI, 2x USB	
Audio Output	2x 8W Speakers, Dolby Digital+	
Special Features	Miracast	
Dimensions (with stand)	Approx. 72 cm (W) x 47 cm (H) x 20 cm (D)	
Color	Black	

7.1 Energy Efficiency


The Smart Tech 32HH01K TV is rated for energy efficiency as follows:

• Energy Efficiency Class (SDR): E

• Energy Consumption (SDR): 26 kWh/1000h

• Energy Efficiency Class (HDR): F

• Energy Consumption (HDR): 28 kWh/1000h






Image: The EU Energy Label for the Smart Tech 32HH01K TV, indicating its energy efficiency class and consumption. For more details, visit the EPREL database.

8. WARRANTY AND SUPPORT

8.1 Manufacturer's Warranty

This Smart Tech TV comes with a **2-year manufacturer's warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

8.2 Spare Parts Availability

Spare parts for this model are guaranteed to be available for up to 11 years.

8.3 Customer Support

For further assistance, technical support, or warranty inquiries, please contact Smart Tech customer service or visit the official Smart Tech store:

- · Seller: Smart Tech FR
- Online Store: Smart Tech Amazon Store

Related Documents - 32HH01K

