

Vicco Viktor (Model 57504)

Vicco Viktor Washing Machine Cabinet Instruction Manual

Model: Viktor (57504)

1. SAFETY INFORMATION

Important! Retain for future reference. Read carefully!

TIP-OVER HAZARD! Unanchored furniture can tip over. To prevent this furniture from tipping, it must be anchored to the wall. Appropriate wall-fixing accessories suitable for your home's walls should be used. If you have questions, consult your local specialized retailer. Please follow each step of the instructions carefully.

2. PRODUCT OVERVIEW

The Vicco Viktor washing machine cabinet is designed to provide a practical and elegant storage solution for your bathroom or laundry area. Its modern design and functional features make it a versatile addition to any home.

Key Features:

- Optimal design for universal utility.
- Modern aesthetic with high functionality.
- Simple assembly process.
- Constructed from 16 mm thick, easy-care particle board.

Dimensions:

The washing machine cabinet has the following approximate dimensions:

- **Depth:** 60 cm
- **Width:** 68 cm
- **Height:** 88.2 cm



Figure 2.1: Cabinet Dimensions Diagram. This image illustrates the width, depth, and height of the cabinet for proper placement and fit.



Figure 2.2: Front View of Assembled Cabinet. This image shows the cabinet with a washing machine integrated, highlighting its design.

3. SETUP AND ASSEMBLY

The Vicco Viktor washing machine cabinet requires assembly. Detailed assembly instructions and all necessary mounting hardware are included in the package. Please ensure all components are present before beginning assembly.

Before You Begin:

- Read the entire instruction manual carefully before assembly.
- Identify all parts and hardware using the provided list.
- Ensure you have the necessary tools (e.g., screwdriver, hammer).
- Assemble on a soft, clean surface to prevent scratches.

Assembly Steps:

1. Follow the step-by-step diagrams and instructions provided in the included assembly guide.
2. Securely fasten all connections. Do not overtighten screws.
3. Once assembled, ensure the cabinet is stable and level.
4. **Wall Anchoring:** As per safety information, anchor the cabinet to a suitable wall using appropriate hardware (not always included, depending on wall type). This is crucial to prevent tipping.



Figure 3.1: Integrated Cabinet Setup. This image demonstrates how the cabinet can be incorporated into a larger bathroom or laundry room design.

4. OPERATING AND USAGE

The Vicco Viktor washing machine cabinet is designed for organized storage in your bathroom or laundry area. It provides a stable surface above your washing machine and additional storage space.

Recommended Uses:

- Storing detergents and laundry supplies.
- Holding towels and other bathroom linens.
- Organizing various bathroom accessories.

Important Considerations:

- Do not exceed the maximum weight capacity of 15 kg for the top surface.
- Distribute weight evenly to maintain stability.
- Avoid placing hot items directly on the surface without protection.



Figure 4.1: Top Surface Detail. This image shows the practical use of the cabinet's top surface for bathroom essentials.

5. CARE AND MAINTENANCE

The Vicco Viktor cabinet is made from easy-care particle board, ensuring simple maintenance to keep it looking new.

Cleaning Instructions:

- Wipe surfaces with a soft, damp cloth.
- Use mild cleaning agents if necessary. Avoid harsh chemicals or abrasive cleaners.
- Dry surfaces immediately after cleaning to prevent moisture damage.
- Regularly check and tighten any loose fittings to maintain structural integrity.

6. SPECIFICATIONS

Feature	Detail
Brand	Vicco
Model Name	Viktor
Model Number	57504
Color	White/Artisan Oak
Material	16 mm Particle Board
Product Dimensions (D x W x H)	60 cm x 68 cm x 88.2 cm
Item Weight	18.75 kg
Maximum Weight Capacity	15 kg
Recommended Uses	Detergents, Towels, Bathroom accessories
Assembly Required	Yes
Included Components	Washing machine cabinet, assembly instructions, mounting hardware
Style	Modern
Finish Type	Laminate

7. TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following general advice:

- **Missing Parts:** Double-check the packaging and compare with the parts list in the assembly instructions. If parts are still missing, contact customer support.
- **Assembly Difficulties:** Re-read the specific step in the assembly instructions. Ensure all components are oriented correctly. Do not force parts together.
- **Instability:** Ensure all screws and fasteners are tightened. Verify the cabinet is on a level surface. Confirm wall anchoring is properly installed.
- **Damage:** If the product arrived damaged, document the damage with photos and contact customer support immediately.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Vicco customer

service directly. Contact details can typically be found on the manufacturer's website or on your purchase receipt.

Manufacturer: ok-living

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question