

[Manuals.plus](#) /

> [Garvee](#) /

> Garvee Farmhouse TV Stand (Model T3-NZC-PHK_3536FNK9-F9dp) Instruction Manual

Garvee T3-NZC-PHK_3536FNK9-F9dp

Garvee Farmhouse TV Stand Instruction Manual

Model: T3-NZC-PHK_3536FNK9-F9dp

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, do not proceed with assembly.
- For safety and ease of assembly, it is recommended that two adults assemble this TV stand.
- Do not overtighten screws or fasteners, as this may damage the material.
- Place the TV stand on a level and stable surface to prevent tipping.
- Do not exceed the recommended weight capacity for the top surface or shelves. This stand is designed for TVs up to 70 inches.

PACKAGE CONTENTS

Before assembly, verify that all components are present. Refer to the detailed parts list provided in the separate assembly instruction booklet included in your package.

- All necessary furniture panels and components.
- Hardware pack (screws, dowels, cam locks, etc.).
- Installation Kit (tools may be required, not included).
- Assembly Instruction Booklet.

SETUP AND ASSEMBLY

The Garvee Farmhouse TV Stand requires assembly. Follow the step-by-step instructions provided in the dedicated assembly booklet for a hassle-free setup. All parts are labeled to simplify the process.

1. **Unpack Components:** Carefully remove all items from the packaging and lay them out on a soft, clean surface.
2. **Identify Parts:** Match each component with the corresponding labels in the assembly instruction booklet.

3. **Follow Step-by-Step Instructions:** Proceed through the assembly booklet, completing each step in the order specified. Pay close attention to diagrams and warnings.
4. **Secure Fasteners:** Ensure all screws and fasteners are tightened securely, but do not overtighten.
5. **Final Placement:** Once assembled, carefully move the TV stand to its desired location. Ensure it is on a stable and level surface.



Image: The Garvee Farmhouse TV Stand, fully assembled and ready for use, showcasing its design and capacity for a large television.

OPERATING AND FEATURES

Your Garvee Farmhouse TV Stand is designed with several functional features to enhance your living space.

- **Sliding Barn Doors:** The two barn doors slide smoothly along a track, allowing you to conceal or reveal the central storage compartments as desired.
- **Adjustable Shelf:** The central compartment features an adjustable shelf, providing flexible storage options for media devices, books, or decorative items. Adjust the shelf height by repositioning the shelf pins.
- **Four Drawers:** Two drawers on each side offer enclosed storage for smaller items, keeping your space tidy. The

drawers feature metal gliders for smooth operation.

- **Cord Management:** Three pass-through cutouts on the back panel facilitate organized routing of cables and wires for your electronic devices, reducing clutter.



Image: Detail showing the adjustable shelves within the Garvee TV Stand, allowing customization for various item heights.



Image: Detailed view highlighting the sliding barn doors, metal drawer hardware, smooth black metal gliders, and the design of the deep carved drawers.

MAINTENANCE

Proper care will ensure the longevity and appearance of your Garvee Farmhouse TV Stand.

- **Cleaning:** Wipe the surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** The imitation wood grain finish is designed to resist wear and is waterproof. Promptly wipe up any spills to prevent potential damage.
- **Dusting:** Regularly dust with a soft, dry cloth to maintain its appearance.
- **Inspection:** Periodically check all fasteners and tighten if necessary to ensure stability.

TROUBLESHOOTING

If you encounter any issues with your Garvee Farmhouse TV Stand, consider the following common solutions:

- **Wobbling or Instability:** Ensure the TV stand is placed on a completely level surface. Check all assembly screws and bolts to confirm they are securely tightened.
- **Drawers Not Sliding Smoothly:** Verify that the drawer glides are correctly installed and free of obstructions. Ensure the drawers are not overloaded.
- **Doors Not Sliding Properly:** Check the barn door track for any debris or misalignment. Ensure the doors are properly seated on the track.
- **Missing Parts:** If you discover missing parts during assembly, refer to the contact information in the Support section for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	T3-NZC-PHK_3536FNK9-F9dp
Dimensions (L x W x H)	66 x 15.7 x 32 inches
Item Weight	144.6 pounds

Feature	Detail
Material	Engineered Wood
Color	Walnut
TV Size Compatibility	Up to 70 inches
Storage Options	4 drawers, 1 adjustable shelf, 1 semi-open cubby
Special Features	Adjustable Shelf, Sliding Barn Doors, Cord Management
Installation Type	Freestanding
Waterproof	Yes



Image: A visual representation of the product's detailed specifications, including dimensions and material information.

WARRANTY AND SUPPORT

For warranty information or any questions regarding your Garvee Farmhouse TV Stand, please contact Garvee Customer Support.

You can typically find contact details on the Garvee brand website or through the retailer where the product was purchased. Please have your model number (T3-NZC-PHK_3536FNK9-F9dp) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question