Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Conyat X5S

Conyat X5S Open-Ear Bluetooth Earbuds User Manual

Model: X5S

Introduction

Thank you for choosing the Conyat X5S Open-Ear Bluetooth Earbuds. These earbuds are designed to provide a comfortable listening experience while maintaining situational awareness. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds.

What's in the Box

Please check the package contents:

- Headphones (L/R) x 2
- USB-C charging cable x 1
- Portable charging box x 1
- User manual x 1



Image: Package contents of the Conyat X5S Open-Ear Bluetooth Earbuds.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

- Connect the provided USB-C charging cable to the charging case and a power source.
- The LED display on the charging case will indicate the battery status.
- A full charge for the case and earbuds typically takes about 1.5 hours.
- The earbuds offer 8-10 hours of playtime per charge, extending to a total of 40 hours with the charging case.




Image: LED display and Type-C charging for the Conyat X5S earbuds.

2. Pairing with Your Device

The Conyat X5S earbuds utilize Bluetooth 6.0 technology for quick and stable connections.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for "X5S" in the list of available Bluetooth devices and select it to connect.
4. Once paired, the earbuds will automatically connect to the last paired device when taken out of the case.




Image: One-step instant pairing process for the Conyat X5S earbuds.

Operating Instructions

1. Wearing the Earbuds

The X5S earbuds feature an open-ear design for comfort and situational awareness.

1. Hook the end of the earphone onto your ear bone.
2. Rotate the earphone and slide it behind your ear.
3. Adjust the ear hook and pull it down slightly for a secure and comfortable fit.



Image: How to wear Conyat X5S Open Earbuds.

The lightweight design (approx. 6.7g per earpiece) ensures comfort even during extended wear, making them suitable for sports, running, and daily use.

2. Touch Controls

The earbuds feature intelligent touch controls for various functions:

Function	Action
Power On/Off	Automatic when removed/placed in case
Play/Pause	Double-tap (L/R)
Next Track	Long tap 2s (R)
Previous Track	Long tap 2s (L)
Answer/Hang Up Call	Double-tap (L/R)
Refuse Incoming Call	Long tap 2s (L/R)
Adjust Volume	One-tap (L for volume down, R for volume up)
Voice Assistant (Siri)	Triple-tap (L/R)



Image: Easy control functions of the Conyat X5S earbuds.

3. Sound and Call Quality

The X5S earbuds feature 14.2mm dynamic drivers for rich audio and directional sound transmission technology to minimize sound leakage. Equipped with an ENC noise-cancelling microphone, they accurately capture your voice and filter background noise for clear calls.

Maintenance

1. Cleaning

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture into any openings.

2. Water Resistance (IP7)

The earbuds are IP7-certified water resistant, protecting them against sweat and rain. This makes them suitable for intense workouts and outdoor activities.

- Do not submerge the earbuds in water.
- Ensure the earbuds are dry before placing them back in the charging case to prevent damage.



Image: Conyat X5S IP7 Waterproof & Sweatproof feature.

3. Storage

Store the earbuds in their charging case when not in use to protect them and keep them charged. Avoid extreme temperatures.

Troubleshooting

Common Issues and Solutions:

- **Earbuds not pairing:**
  - Ensure earbuds are charged.
  - Turn off Bluetooth on your device and turn it back on.
  - Forget "X5S" from your device's Bluetooth list and try pairing again.
  - Place earbuds back in the case, close it, wait a few seconds, then open to reset.
- **No sound:**
  - Check the volume level on both your device and the earbuds.
  - Ensure earbuds are properly connected to your device.
  - Try playing audio from a different application or device.
- **Charging issues:**
  - Ensure the USB-C cable is securely connected to both the case and the power source.
  - Try a different USB-C cable or power adapter.
  - Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
- **Poor call quality:**
  - Ensure the microphone is not obstructed.
  - Move closer to your connected device to improve signal strength.
  - Avoid noisy environments if possible, though ENC helps reduce background noise.

Specifications

Feature	Detail
Model Name	X5S
Connectivity Technology	Bluetooth 6.0
Ear Placement	Open Ear
Audio Driver Type	14.2mm Dynamic Driver
Battery Life (Earbuds)	8-10 Hours
Total Playtime (with Case)	Up to 40 Hours
Charging Time	Approx. 1.5 Hours (for case and earbuds)
Charging Interface	USB-C

Feature	Detail
Water Resistance Level	IP7 (Waterproof)
Control Method	Touch Control
Microphone	ENC Noise-Cancelling
Weight (per earpiece)	Approx. 6.7g
Compatible Devices	iOS, Android, and all Bluetooth-enabled devices

Warranty and Support

Conyat products are designed for quality and reliability.

- **12-Month Quality Guarantee:** Your Conyat X5S earbuds are covered by a 12-month quality guarantee from the date of purchase.
- **30-Day Worry-Free Trial:** Enjoy a 30-day trial period to ensure complete satisfaction.
- **24-Hour Customer Service:** For any questions, issues, or support needs, please contact Conyat customer service.




Image: Conyat customer service and warranty information.

For further assistance, please refer to the contact information provided with your product packaging or visit the official Conyat website.

© 2026 Conyat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRS7R3G3

More documents and user manuals: **https://manuals.plus/**