

[Manuals.plus](#) /

› [Russell Hobbs](#) /

› Russell Hobbs TrueTemp 1.8L 1500W Retro Electric Kettle RJK1800 User Manual

Russell Hobbs RJK1800

Russell Hobbs TrueTemp 1.8L 1500W Retro Electric Kettle RJK1800 User Manual

Model: RJK1800

INTRODUCTION

Thank you for choosing the Russell Hobbs TrueTemp 1.8L 1500W Retro Electric Kettle. This manual provides important information for the safe and efficient use of your appliance. Please read it thoroughly before first use and keep it for future reference.



Image: Front view of the Russell Hobbs TrueTemp Retro Electric Kettle, showcasing its cream stainless steel body and retro design.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- This appliance is for household use only.
- Ensure the kettle is placed on a firm, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged, or if the kettle malfunctions or has been damaged in any way.
- Always ensure the lid is securely closed before operating the kettle.
- Do not fill above the maximum fill line or below the minimum fill line.
- Avoid contact with steam escaping from the spout or lid when water is boiling.
- The kettle features an automatic shut-off and boil-dry protection for safety.
- Keep out of reach of children.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Russell Hobbs TrueTemp Electric Kettle.

1. Spout

2. Lid
3. Cool-Touch Handle
4. Water Level Indicator
5. Retro Temperature Display Dial
6. Power Switch with Indicator Light
7. Power Base



Image: Close-up of the kettle's cool-touch handle and the clear water level indicator on the side.



Image: Underside of the kettle showing the central connector and the separate power base.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with fresh water to the maximum level. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
3. **Placement:** Place the power base on a stable, flat, heat-resistant surface, away from the edge of the countertop and out of reach of children.
4. **Power Connection:** Plug the power cord into a suitable wall outlet.

OPERATING INSTRUCTIONS

Filling the Kettle

1. Remove the kettle from its power base.
2. Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX mark (1.8 Liters).
3. Close the lid securely.
4. Place the kettle back onto its power base.



Image: Top-down view of the kettle's wide mouth interior, showing the heating element and maximum fill line.

Boiling Water

1. Ensure the kettle is properly filled and placed on the power base.
2. Press the power switch down. The indicator light will illuminate, signifying that the kettle is heating.
3. The retro temperature display dial will show the real-time water temperature as it heats up.
4. Once the water reaches boiling point, the kettle will automatically switch off, and the indicator light will extinguish.
5. You can remove the kettle from the base to pour. The cool-touch handle ensures safe handling.



Image: Close-up of the kettle's retro analog temperature display dial, showing temperature readings in Celsius.

Boil-Dry Protection

The kettle is equipped with a boil-dry protection feature. If the kettle is accidentally switched on without sufficient water, it will automatically switch off to prevent damage. If this occurs, allow the kettle to cool down for 15-20 minutes before refilling with cold water and operating again.

MAINTENANCE AND CLEANING

Exterior Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Ensure no water enters the electrical components.

Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. Regular descaling is recommended to maintain performance and extend the life of your kettle.

- Fill the kettle with a mixture of one part white vinegar and two parts water, or use a commercial descaling solution according to its instructions.
- Bring the mixture to a boil and let it stand for at least 30 minutes, or longer if scale is heavy.

- Empty the kettle and rinse thoroughly with fresh water several times.
- If necessary, repeat the process until all scale is removed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	• Kettle not properly seated on base. • Power switch not pressed. • No power to the outlet. • Boil-dry protection activated.	• Ensure kettle is correctly placed on the power base. • Press the power switch down. • Check the power outlet and circuit breaker. • Allow kettle to cool, then refill and restart.
Water takes too long to boil.	• Limescale buildup. • Overfilling the kettle.	• Descale the kettle as per maintenance instructions. • Do not fill above the MAX line.
Kettle switches off before boiling.	• Boil-dry protection activated (insufficient water). • Limescale buildup affecting sensor.	• Allow kettle to cool, then refill to at least MIN level and restart. • Descale the kettle.

SPECIFICATIONS

Model Name	RJK1800
Capacity	1.8 Liters
Wattage	1500W
Material	Stainless Steel
Color	Cream
Special Features	Retro Temperature Display Dial, Auto Shut-Off, Boil Dry Protection, Cool-Touch Handle
Product Dimensions (L x W x H)	5L x 5W x 5H Centimeters
Item Weight	1 Kilogram
Included Components	Kettle
Country of Origin	China

WARRANTY AND SUPPORT

Your Russell Hobbs TrueTemp Electric Kettle (Model RJK1800) comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or service inquiries, please contact Russell Hobbs customer service. Please retain your purchase receipt as proof of purchase.

For more information, you may visit the official Russell Hobbs store: [Russell Hobbs Store on Amazon.in](#)

