

[Manuals.plus](#) /

› [Evmore](#) /

› Evmore 12V Kids ATV Instruction Manual - Model B0FRSN7B3J

Evmore B0FRSN7B3J

Evmore 12V Kids ATV Instruction Manual

Model: B0FRSN7B3J

1. SAFETY INFORMATION

Your child's safety is paramount. Please read and understand all safety instructions before assembly and operation.

General Safety Guidelines:

- This product is recommended for children aged 3-6 years old.
- Maximum weight capacity: 110 lbs.
- Always supervise children during operation.
- Ensure the ATV is used on flat, stable surfaces. Avoid slopes, uneven terrain, or public roads.
- The ATV has passed ASTM certification, meeting high safety standards.

Battery Safety:

- DO NOT incinerate or expose the battery to high temperatures, as they may explode in a fire.
- Charging time: 8-12 hours. Do not overcharge.
- The low battery voice prompt will inform kids about battery levels.

2. PRODUCT OVERVIEW

The Evmore 12V Kids ATV is an electric ride-on vehicle designed for toddlers, offering a fun and safe driving experience with robust features.

COMFORTABLE SIZE FOR KIDS



Image: Evmore 12V Kids ATV in pink, highlighting its dimensions (33.46" L x 21.65" W x 21.77" H), recommended age (3-6 years), max load (110 lbs), and playtime (up to 80 minutes).

Key Features:

- **Powerful Performance:** Dual 35W motors and a 12V 4.5AH rechargeable battery, reaching a top speed of 3.7 miles per hour.
- **Enjoyable Driving Experience:** Bright LED headlights, forward/reverse functions with high/low speed adjustment, USB/local music modes, and realistic engine sounds.
- **Large-Size EVA Anti-Slip Tires:** Oversized, durable EVA tires with deep tread patterns for superior traction and wear resistance on various surfaces.
- **Robust Construction & Comfortable:** Made from PP, stainless steel, and EVA for durability and safety. Comfortable seat and grips.
- **Safe & Reliable:** Rear-wheel drive system for enhanced traction and stability.

3. PACKAGE CONTENTS

The package includes:

- Kids Electric Car (Main Body)
 - 12V 4.5AH Rechargeable Battery (Pre-installed)
 - Charger
 - Assembly Hardware (Screws, washers, nuts, etc.)
 - Wheels (EVA Anti-Slip Tires)
 - Handlebars
 - Seat
-

4. SETUP & ASSEMBLY

Follow these steps to assemble your Evmore 12V Kids ATV. A screwdriver and needle-nose pliers may be required (not included).

Assembly Steps:

1. Remove the ATV from its packaging.
2. Place the ATV on a flat, stable surface.
3. Ensure the ATV is turned off.
4. Insert the battery pack into the battery compartment.
5. Secure the battery pack in place.
6. Connect the left motor to the left wiring harness and the right motor to the right wiring harness.
7. Attach the wheels according to the instructions provided in the manual.
8. Install the handlebars, ensuring they are securely fastened.
9. Secure the seat onto the ATV.

Assembly Video:

Video: A detailed assembly guide for the Evmore 12V Kids ATV, demonstrating each step from unboxing to final setup.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the controls for a safe and enjoyable ride.

OPERATION PANEL MULTI-FUNCTIONAL DESIGN



Image: The multi-functional operation panel of the ATV, indicating controls for USB/local music, battery indicator, music button, horn, forward/reverse, and on/off switch.

1. Turn the ATV on using the power switch.
2. Help the child onto the ATV, ensuring they are seated comfortably with feet on the footrest.
3. Demonstrate how to use the forward/reverse functions and high/low speed adjustment.
4. Use the music button to play pre-loaded tunes or connect a USB device for local music.
5. Activate the horn for realistic sound effects.
6. Supervise the child while they ride the ATV, ensuring they follow safety guidelines.

Product in Action:

Video: A demonstration of the Evmore 12V Kids ATV in use, showcasing its features and how children interact with the ride-on toy.

6. BATTERY CHARGING & MAINTENANCE

Proper battery care ensures longevity and optimal performance.

- Charge the battery for 8-12 hours before first use and after each use.

- Do not overcharge the battery, as this can reduce its lifespan.
- Store the ATV in a dry, cool place when not in use.
- Regularly check all connections and components for wear or damage.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	33.46 x 21.65 x 21.77 inches
Item Weight	23.6 pounds
Recommended Age	3-6 years old
Max Weight Capacity	110 lbs
Battery	12V 4.5AH (included)
Motors	Dual 35W
Max Speed	3.7 Mph
Tire Type	14.4" Anti-Slip EVA Tires
Charging Time	8-12 hours
Playtime	1-1.2 hours
Manufacturer	Evmore

8. TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

- **Vehicle not moving:** Check battery charge level. Ensure all wiring connections are secure. Verify the power switch is in the 'On' position.
- **Lights or sounds not working:** Check battery charge. Ensure all electrical connections are properly seated.
- **Reduced speed or power:** The battery may need charging. Ensure the vehicle is not overloaded beyond the maximum weight capacity.
- **Unusual noises:** Inspect wheels and axles for any obstructions or loose parts.

For persistent issues, please contact customer support.

9. WARRANTY & SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Evmore directly through their official channels. Keep your purchase receipt for warranty claims.

