



[Manuals.plus](#) /

> [Groovz](#) /

> Groovz Open-Ear True Wireless Headphones (Model GRZ-OPN-PUR) User Manual

Groovz GRZ-OPN-PUR

Groovz Open-Ear True Wireless Headphones (Model GRZ-OPN-PUR) User Manual

Comprehensive instructions for setup, operation, and maintenance.

INTRODUCTION

Thank you for choosing Groovz Open-Ear True Wireless Headphones. This manual provides detailed instructions to help you get the most out of your device. Please read it carefully before use and retain it for future reference.



Image: Groovz Open-Ear True Wireless Headphones and their charging case, both in a deep purple color. The case features an LED battery display.

SETUP

1. Unboxing and Initial Charge

Upon unboxing, ensure all components are present: Groovz Open-Ear True Wireless Headphones, charging case, and user manual. Before first use, fully charge the headphones and charging case.

- Place the earbuds into the charging case.
- Connect the charging case to a power source using a compatible USB-C cable (not included).
- The LED Battery Display on the case will indicate the charging status. A full charge is indicated by 100% on the

display.


Reliable Battery Life

Stay charged and connected no matter where your day takes you



LED Battery Display

Check your charge instantly and never be surprised by dead earbuds



Fast Charging

Type-C fast charging gets you back to full power quickly



26 Hours of Total Playtime

Enjoy up to 4 hours with the earbuds plus 22 hours with the charging case



Image: The Groovz charging case with its LED display showing "100", indicating a full charge. The two open-ear headphones are shown next to it.

2. Bluetooth Pairing

The headphones feature instant pairing with Bluetooth 5.3 technology.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
3. Select "Groovz Open-Ear" from the list of available devices.
4. Once connected, you will hear an audio confirmation, and the earbuds will be ready for use.

Break Free from Wires

Simplify your life with one less cord to worry about!



Instant pairing
with **Bluetooth 5.3**
Technology



Navigate playlists
or answer calls with
Smart Touch Controls



Image: A user demonstrating the smart touch controls on a Groovz open-ear headphone, highlighting the ease of pairing and control.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The Groovz Open-Ear headphones are designed for a secure and comfortable fit, featuring ergonomic and flexible ear hooks.

- Gently place the earbud over your ear, ensuring the ear hook rests comfortably behind your ear.
- Adjust the earbud until the speaker is positioned correctly near your ear canal for optimal sound without blocking ambient noise.



The Perfect Fit for Everyone

Designed for all-day wear
and full awareness



Lightweight, open-ear
headphones with
ergonomic silicone
earbuds and flexible
ear hooks for a secure,
comfortable fit

Image: A woman wearing a Groovz open-ear headphone, illustrating the ergonomic design that allows for comfort and environmental awareness.

2. Smart Touch Controls

The earbuds feature intuitive smart touch controls for managing audio playback and calls.

Action	Function
Single Tap	Play/Pause music, Answer/End call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap	Activate Voice Assistant
Long Press (2 seconds)	Reject Call

3. Call Management

The dual microphones with noise reduction ensure clear conversations.

- **Answering/Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Long press either earbud for 2 seconds.

4. Battery Life and Display

The charging case features an LED display to show the remaining battery percentage in real-time. The earbuds provide up to 4 hours of playtime on a single charge, with an additional 22 hours provided by the charging case, totaling up to 26 hours.



Reliable Battery Life

Stay charged and connected no matter where your day takes you

100%
LED Battery Display
Check your charge instantly and never be surprised by dead earbuds

Fast Charging
Type-C fast charging gets you back to full power quickly

26 Hours of Total Playtime
Enjoy up to 4 hours with the earbuds plus 22 hours with the charging case

Image: The Groovz charging case with its LED display showing "100", indicating a full charge. The two open-ear headphones are shown next to it.

5. Video Demonstration

Watch this video for a visual guide on using your Groovz True Wireless Earbuds in various daily activities.

Your browser does not support the video tag.

Video: A demonstration of Groovz True Wireless Earbuds being used by individuals during activities such as running, yoga, commuting, and working, showcasing their versatility and comfortable fit.

MAINTENANCE

1. Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts are free of dust and debris.



Crystal Clear Sound & Premium Comfort

Experience flawless communication and immersive sound with technology that adapts to your life

Secure & Comfortable Fit

Dual Microphones & Noise Reduction

Easy Touch Controls

Image: An exploded diagram illustrating the internal structure and materials of the Groovz open-ear earbud, including its sweat and water-resistant coating.

2. Storage

When not in use, store the headphones in their charging case to protect them and ensure they are charged for your next use.

- Store in a cool, dry place away from extreme temperatures.
- Avoid prolonged exposure to direct sunlight.

TROUBLESHOOTING

If you encounter issues, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget the device in Bluetooth settings and re-pair.
No sound	Check device volume. Ensure earbuds are properly connected. Try playing different audio.
Low volume	Adjust volume on both your device and the earbuds. Ensure earbuds are positioned correctly.
Charging issues	Verify the charging cable and power source are functional. Clean charging contacts on earbuds and case.
Intermittent connection	Ensure no obstructions between earbuds and device. Move closer to your device. Avoid environments with high Wi-Fi or Bluetooth interference.

SPECIFICATIONS

Feature	Detail
Model Number	GRZ-OPN-PUR
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	Open Ear
Water Resistance Level	IPX5 (Water Resistant)
Control Method	Touch
Earbud Battery Life	Up to 4 Hours
Total Playtime (with case)	Up to 26 Hours
Microphones	Dual Microphones with Noise Reduction
Charging Case Feature	LED Battery Display
Compatible Devices	Cellphones, Tablets (Apple & Android)
Item Weight	6.4 ounces
Package Dimensions	4.13 x 3.74 x 2.13 inches

WARRANTY INFORMATION

Groovz products are manufactured with quality and care. For specific warranty details regarding your Groovz Open-Ear True Wireless Headphones, please refer to the warranty card included in your product packaging or visit the official Groovz website.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need further support, please contact Groovz customer service. You can typically find contact information on the product packaging or on the official Groovz website: [Groovz Store on Amazon](#).

