

FUNTOK BDM-0928

FUNTOK 24 Volt 2 Seater Kids Ride-On Toy Truck Instruction Manual

Model: BDM-0928

Brand: FUNTOK

IMPORTANT SAFETY INFORMATION

Read this entire manual before assembly and use. Failure to follow these instructions may result in serious injury or property damage. Keep this manual for future reference.

- **Adult Supervision Required:** This product is intended for children aged 3 years and up. Constant adult supervision is mandatory during operation.
- **Weight Limit:** Do not exceed the maximum weight capacity of 140 lbs (63.5 kg).
- **Seating:** Designed for two children. Ensure both children are properly seated and secured with seat belts.
- **Protective Gear:** Always wear a helmet and other protective gear (e.g., knee pads, elbow pads) when operating the vehicle.
- **Operating Environment:** Use only on flat, level surfaces. Avoid slopes, stairs, public roads, swimming pools, or other hazardous areas.
- **Battery Safety:** Only use the provided charger and battery. Do not modify the electrical system.
- **Moving Parts:** Keep hands, hair, and clothing away from moving parts.
- **Braking:** The vehicle stops when the foot pedal is released. Ensure children understand this operation.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Ride On Truck (Main Body)
- Remote Control

- Charger
- Assembly Hardware (screws, washers, etc.)
- Instruction Manual

ASSEMBLY AND SETUP

Follow these steps for initial assembly and preparation:

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Wheel Installation:** Attach the four wear-resistant wheels to the vehicle axles. Ensure they are securely fastened according to the diagrams in the separate assembly guide.
3. **Steering Wheel:** Install the steering wheel, ensuring it clicks into place or is secured with the provided hardware.
4. **Seat Installation:** Secure the 20-inch wide seat into position.
5. **Battery Connection:** Connect the battery terminals. Refer to the battery compartment for specific instructions.
6. **Initial Charge:** Before first use, fully charge the 24V 7AH battery for 8-12 hours. Do not overcharge.

OPERATING INSTRUCTIONS

The FUNTOK Ride-On Truck offers dual operating modes for varied control.

Self-Driving Mode (Child Operated)

- **Age Range:** Recommended for children aged 3 to 8 years.
- **Operation:** The child uses the steering wheel and foot pedal to control the vehicle.
- **Speeds:** This mode offers 2 speeds, ranging from approximately 2.67 to 5 MPH.
- **Soft Start:** The vehicle features a slow start function for gradual acceleration, enhancing safety and comfort.

Remote Control Mode (Parent Operated)

- **Age Range:** Recommended for children aged 1 to 3 years, or for parental assistance with older children.
- **Operation:** Parents can control the vehicle's direction and speed using the 2.4GHz remote control.
- **Speeds:** This mode offers 3 speeds, ranging from approximately 2 to 5 MPH.
- **Pairing Remote:** Refer to the remote control's specific instructions for pairing with the vehicle. Typically involves holding a button on the remote while turning on the vehicle.

Dual Modes, Join Kid's Fun



Self Driving Mode **2** Speeds:
2.67 - 5 MPH for 3 - 8 Years



Remote Control Mode **3** Speeds:
2 - 5 MPH for 1 - 3 Years

Dual Driving Modes: The vehicle can be operated by the child using the steering wheel and pedal, or by a parent using the included 2.4GHz remote control. This image shows both modes of operation, highlighting the age ranges and speed options for each.

Additional Features

- **LED Lights:** Turn on the vehicle's LED lights using the designated switch on the dashboard.
- **Horn/Music:** Use the buttons on the steering wheel for horn sounds or pre-installed music.

BATTERY INFORMATION

Proper battery care ensures optimal performance and longevity.

- **Battery Type:** The vehicle is powered by a 24 Volt 7 AH battery.
- **Charging:** Use only the provided charger. Plug the charger into the charging port on the vehicle, then into a standard wall outlet.
- **Charging Time:** An initial charge of 8-12 hours is required. Subsequent charges typically take 8-12 hours. Do not charge for more than 18 hours.
- **Playtime:** A fully charged battery provides approximately 45-60 minutes of playtime, depending on terrain and usage.

- **Storage:** If storing the vehicle for an extended period, charge the battery fully every 3 months to maintain its health.

Superior Power, Keeps All Day Fun



24V 7AH Battery

Speed: **2 - 5 MPH** Play Time: **1 - 2H**

Battery and Performance: This image highlights the 24V 7AH battery, indicating a play time of 1-2 hours and speeds of 2-5 MPH. It shows children enjoying the vehicle, powered by its robust battery system.

PRODUCT FEATURES

The FUNTOK Ride-On Truck is designed with several key features for performance and safety.

- **Powerful Motors:** Equipped with 4 x 200W motors, providing strong performance.
- **Drive System:** Features switchable 2WD/4WD capability for varied terrain.
- **Suspension:** Four-wheel spring suspension ensures a smooth ride.
- **Spacious Seating:** A 20-inch wide seat comfortably accommodates two children.
- **Safety Belts:** Adjustable seat belts are included for both passengers.
- **Double-Locking Doors:** For enhanced security during operation.
- **Non-Slip Tires:** Designed for improved traction and stability.

Stronger Motor, Faster Speed

2X2 / 4X4 Switchable



Powerful Motor System: This image illustrates the vehicle's 4x200W motors and the 2x2/4x4 switchable drive system, indicating stronger power and faster speed capabilities.

Roomy Space, More Joys



Seats
2 Seaters



Max Load
132 lbs



Age
3 to 8 Years



Spacious Seating: This image details the roomy interior, featuring a 20-inch wide seat designed for two children, with a maximum load capacity of 132 lbs and suitable for ages 3 to 8 years.

Start Safer, All in Control



Adjustable
Safety Belts

4 Wear-Resistant
Wheels



Safety and Control: This image emphasizes safety features like adjustable seat belts and durable wear-resistant wheels. It also visually represents the soft start function, which ensures smooth and safe acceleration.

MAINTENANCE

Regular maintenance helps prolong the life of your ride-on toy.

- **Cleaning:** Wipe the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery Care:** Always recharge the battery after each use. If storing for extended periods, charge the battery fully every 3 months.
- **Inspection:** Periodically check all screws, nuts, and fasteners to ensure they are tight. Inspect wheels and tires for wear.
- **Storage:** Store the vehicle in a dry, cool place away from direct sunlight and moisture.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Vehicle Does Not Move:**

- Check battery connection.
- Ensure battery is charged.
- Verify power switch is ON.
- Check for loose wiring.

- **Short Playtime:**

- Battery may not be fully charged.
- Battery may be old and require replacement.
- Vehicle is overloaded.

- **Remote Control Not Working:**

- Replace remote control batteries.
- Re-pair the remote control with the vehicle.

- **Loud Grinding Noise:**

- Inspect gears for damage or debris.
- Contact customer support if issue persists.

For issues not listed here, please contact FUNTOK customer support.

SPECIFICATIONS

Feature	Detail
Model Number	BDM-0928
Product Dimensions	42.13 x 22.44 x 25.98 inches
Item Weight	67.2 pounds
Battery	24 Volt 7 AH
Motors	4 x 200W
Max Load Capacity	140 lbs (63.5 kg)
Recommended Age	3 years and up
Seat Width	20 inches
Speeds (Self-Drive)	2.67 - 5 MPH (2 speeds)
Speeds (Remote Control)	2 - 5 MPH (3 speeds)

WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or any questions regarding your FUNTOK Ride-On Toy Truck, please contact FUNTOK customer service through the retailer's platform or the official FUNTOK website.