



[Manuals.plus](#) /

› [DOGNESS](#) /

› DOGNESS Rechargeable Pet Shock Mat (Model P01A) - User Manual

DOGNESS P01A

DOGNESS Rechargeable Pet Shock Mat (Model P01A) - User Manual

Brand: DOGNESS | Model: P01A

INTRODUCTION

The DOGNESS Rechargeable Pet Shock Mat is an electronic training aid designed to help deter pets from specific areas such as furniture, countertops, or doorways. It emits a harmless static pulse and an audible warning sound when a pet steps on it, encouraging them to avoid the designated zone. This manual provides detailed instructions for the safe and effective use of your pet shock mat.

PRODUCT FEATURES

- **Safe and Effective:** Delivers a gentle static correction to deter pets without causing harm.
- **Three Training Modes:** Adjustable low, medium, and high voltage settings to suit different pet sizes and sensitivities.
- **Rechargeable Battery:** Equipped with a 1500mAh Lithium Ion battery, eliminating the need for disposable 9V batteries.
- **Battery Life Indicator:** LEDs display the current battery level.
- **Auto-Deactivation:** Automatically turns off after five consecutive static corrections to prevent overuse.
- **Washable Mat:** The mat fabric is washable (ensure battery compartment is removed/protected).
- **Test Pen Included:** Allows for easy verification of proper mat functionality.

PACKAGE CONTENTS

- DOGNESS Rechargeable Pet Shock Mat
- Rechargeable Control Unit
- USB-C Charging Cable
- Test Pen
- User Manual

SETUP

1. Initial Charging

Before first use, fully charge the control unit. Connect the provided USB-C charging cable to the control unit and a 5V1A to 5V2A USB power adapter (not included). The battery indicator LEDs will show charging progress.

Your browser does not support the video tag.

Video: Demonstrates how to charge the DOGNESS Pet Shock Mat control unit. The video shows the USB-C port and the charging indicator lights.

2. Placement

Place the mat in the area you wish to deter your pet from. Common areas include couches, beds, doorways, or near valuable items. Ensure the mat lies flat and covers the desired area effectively.

DOGNESS Training Mat for pets can help you!

NO MORE MESS
NO MORE TATTERED FURNITURE



Image: The DOGNESS Pet Shock Mat can be placed in various locations such as couches, doorways, countertops, and under furniture to keep pets away from unwanted areas.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn **ON** the mat, press and hold the power button (top button on the control unit) for 3 seconds until you hear a beep.
- To turn **OFF** the mat, press and hold the power button for 3 seconds.

2. Selecting Voltage Level

The mat offers three voltage levels: Low (L), Medium (M), and High (H). To cycle through these levels, briefly press the gear key (bottom button on the control unit). The indicator light for the corresponding level will change to a flashing blue light after selection.

- **Low (L):** Suitable for small cats and dogs.
- **Medium (M):** Suitable for medium-sized dogs.
- **High (H):** Suitable for large dogs.



Image: The control unit with buttons for power and voltage level selection (Low, Medium, High), indicating suitability for different pet sizes.

3. Testing the Mat

Use the included test pen to verify the mat's functionality. Place the test pen on the mat's surface. If the mat is working correctly, the test pen will light up, indicating a static pulse is being emitted.

Your browser does not support the video tag.

Video: Demonstrates how to test the DOGNESS Pet Shock Mat using the included test pen. The video shows the test pen lighting up when placed on the mat.

MAINTENANCE

Cleaning the Mat

The mat fabric is washable. Before cleaning, ensure the control unit is powered off and detached from the mat. The battery compartment (control unit) is **NOT** washable. Wipe the mat surface with a damp cloth or hand wash gently. Allow the mat to air dry completely before reattaching the control unit and using it again.

Your browser does not support the video tag.

Video: Shows the DOGNESS Pet Shock Mat being cleaned. The control unit is detached, and the mat is wiped down, emphasizing that the control unit is not washable.

TROUBLESHOOTING

- **Mat not activating:**

- Ensure the control unit is powered on.
- Check the battery level and recharge if necessary.
- Verify the mat is lying flat and there are no obstructions.
- Use the test pen to confirm functionality.

- **Pet not responding to correction:**

- Increase the voltage level (Low, Medium, High) to a setting appropriate for your pet's size and temperament.
- Ensure the mat is placed in a location where the pet cannot easily bypass it.

- **Battery not charging:**

- Check the USB-C cable and power adapter for damage.
- Ensure the power adapter meets the 5V1A to 5V2A specification.

SPECIFICATIONS

Brand	DOGNESS
Model Number	P01A
Dimensions	31 x 15 x 1 inches
Item Weight	15.1 ounces
Battery Type	1 Lithium Ion battery (included)
Battery Capacity	1500mAh
Charging Port	USB-C
Voltage Modes	Low, Medium, High

WARRANTY INFORMATION

This DOGNESS Pet Shock Mat comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, troubleshooting assistance, or warranty claims, please contact DOGNESS customer support. Refer to the product packaging or the official DOGNESS website for the most current contact information.

Online Support: [Visit the DOGNESS Store on Amazon](#)