

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [DEVAISE](#) /

› DEVAISE ASJZ031 Electric Standing Desk 55x28 Inch Instruction Manual

DEVAISE ASJZ031-new

DEVAISE ASJZ031 Electric Standing Desk 55x28 Inch Instruction Manual

Model: ASJZ031-new

1. INTRODUCTION

Thank you for choosing the DEVAISE ASJZ031 Electric Standing Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions thoroughly before use and retain them for future reference.

This electric standing desk is designed to provide a versatile workspace, allowing seamless transitions between sitting and standing positions to promote better posture and productivity. It features a robust steel frame, a powerful lift system, and a seamless one-piece desktop for enhanced stability.

2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly.
- Keep children and pets away from the desk during operation to prevent injury.
- Do not overload the desk. The maximum weight capacity is 176 lbs (80 kg).
- Ensure there are no obstructions above or below the desk when adjusting its height.
- Keep hands and fingers clear of moving parts during height adjustments.
- Only use the provided power adapter and cables.
- Do not disassemble or modify the desk's electrical components. Contact customer support for service.
- Place the desk on a level surface to ensure stability.

3. PACKAGE CONTENTS

Verify that all parts are included in your package. Refer to the diagram below for identification.

15 MINUTES QUICK INSTALLATION

All Holes Are Pre-Drilled And All Accessories Are Pre-Labeled Clearly



Image: All components of the DEVAISE Electric Standing Desk laid out for assembly.

- Desktop (1 piece)
- Legs (2 pieces)
- Feet (2 pieces)
- Crossbar/Motor Assembly
- Control Panel
- Power Adapter and Cables
- Headphone Hook
- Assembly Hardware (screws, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Follow these steps for assembling your DEVAISE Electric Standing Desk. It is recommended to have two people for certain steps.

1. **Attach Feet to Legs:** Secure the two feet to the bottom of each leg using the provided screws.
2. **Install Crossbar/Motor Assembly:** Connect the crossbar, which contains the motor, between the two legs. Ensure it is securely fastened.
3. **Attach Legs to Desktop:** Carefully place the desktop upside down on a soft, clean surface. Align the assembled leg frame with the pre-drilled holes on the desktop and secure it with the appropriate screws.
4. **Connect Control Panel and Power:** Mount the control panel to the underside of the desktop in the designated area. Connect all motor and power cables as per the diagram in your included paper manual.
5. **Install Headphone Hook:** Attach the headphone hook to the desired side of the desk.
6. **Cable Management:** Use the included cable ties or clips to organize and secure all cables to prevent tangling and damage.
7. **Initial Power-Up:** Plug the desk into a power outlet. The control panel should light up.

For a visual overview of the desk's features and operation, please refer to the video below:

Your browser does not support the video tag.

Video: Overview of the DEVAISE Adjustable Electric Standing Desk, demonstrating its features and height adjustment.

5. OPERATING INSTRUCTIONS

Your DEVAISE Electric Standing Desk is equipped with an intuitive digital control panel for easy height adjustment and memory presets.

DIGITAL CONTROL PANEL



LED DISPLAY

Check Clearly Accurate Height For Adjusting



UP & DOWN

Adjust Customizable Height



MEMORY HEIGHT

Save 3 Kinds Of Height Memory



S BUTTON

Lock and Set Up

Image: Close-up of the digital control panel with LED display, up/down arrows, and three memory preset buttons.

Height Adjustment

- **Raise Desk:** Press and hold the **Up Arrow (▲)** button to raise the desk to your desired standing height.
- **Lower Desk:** Press and hold the **Down Arrow (▼)** button to lower the desk to your desired sitting height.
- The LED display will show the current height in inches. The adjustable height range is approximately 28.35 inches to 46.46 inches.

HEIGHT ADJUSTABLE

Adjust Height From 28.35" to 46.45"



Image: Illustration showing the DEVAISE Standing Desk adjusting from its lowest height (28.35 inches) to its highest height (46.45 inches).

Memory Presets

The desk features three programmable memory presets to save your favorite sitting and standing heights.

1. Adjust the desk to your desired height using the up/down arrows.
2. Press the 'S' button (Set button). The display will flash.
3. Immediately press one of the numbered memory buttons (**1, 2, or 3**) to save the current height to that preset.
4. To recall a saved height, simply press the corresponding numbered memory button (**1, 2, or 3**). The desk will automatically move to the saved position.

Anti-Collision System

The desk is equipped with an anti-collision system that automatically stops and slightly reverses movement if it encounters an obstruction during height adjustment. This feature enhances safety and prevents damage to the desk or surrounding objects.

Your browser does not support the video tag.

Video: Demonstration of the DEVAISE Electric Standing Desk in various home office settings, highlighting its smooth operation and cable management features.

6. MAINTENANCE

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Periodically check that all cables are securely fastened and not pinched or tangled.
- **Fasteners:** Occasionally check and tighten any loose screws to maintain stability.
- **Motor:** The motor is maintenance-free. Do not attempt to lubricate or open the motor housing.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; motor cable loose.	Check all power and motor connections. Ensure the desk is plugged into a working outlet.
Desk moves unevenly or makes unusual noise.	Uneven load; loose fasteners; obstruction.	Distribute weight evenly. Check and tighten all screws. Ensure no obstructions are interfering with movement.
Anti-collision system frequently activates.	Sensitivity too high; frequent obstructions.	Ensure clear path for desk movement. Refer to the full manual for adjusting anti-collision sensitivity if available.
Memory presets not working.	Presets not saved correctly.	Re-program the memory presets following the operating instructions.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact DEVAISE customer support.

8. SPECIFICATIONS

Brand	DEVAISE
Model Number	ASJZ031-new
Product Dimensions	27.5"D x 55"W x 28"H
Adjustable Height Range	28.35" to 46.46"

Color	Black
Top Material Type	Engineered Wood
Base Material	Iron
Maximum Weight Recommendation	180 Pounds (81.6 kg)
Item Weight	37 Pounds (16.8 kg)
Special Features	3 Preset Memories, Adjustable Height, Electric, Quiet, Whole Piece Desktop

9. WARRANTY AND SUPPORT

The DEVAISE ASJZ031 Electric Standing Desk comes with a **1-year frame warranty**. For any questions regarding assembly, product selection, or warranty claims, please contact our U.S.-based product support team. We offer 24/7 customer service to assist you.

For further assistance, please visit the official DEVAISE website or contact the customer service number provided with your purchase documentation.