Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nordivale H21426-70BK+H20100-36SWHSNL

Nordivale 70-inch Fireplace TV Stand User Manual

Model: H21426-70BK+H20100-36SWHSNL

1. Safety Information

Please read all safety instructions carefully before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Secure this heavy furniture to the wall using appropriate anti-tip hardware to prevent tip-over, especially in households with children or pets.
- Exercise caution when handling components during assembly to avoid personal injury.
- Always adhere to safety guidelines when operating the electric fireplace feature to prevent burns or fire hazards. Do not obstruct the fireplace vents.
- Ensure the electric fireplace is plugged directly into a wall outlet. Avoid using extension cords or power strips, which can lead to overheating.

2. Product Overview

The Nordivale 70-inch Fireplace TV Stand is a modern entertainment center designed for TVs up to 80 inches. It features a realistic electric fireplace, ample storage with side cabinets, and unique RGB light strips. The fireplace offers adjustable flame brightness, temperature control, and a timer function, certified for safety. The stand is supported by four cylindrical acrylic columns for stability and includes a high-gloss, mirror-like surface for a contemporary aesthetic.




Figure 2.1: The Nordivale 70-inch Fireplace TV Stand, showcasing its black and white design with an illuminated electric fireplace.



Figure 2.2: Detailed view of the 36-inch panoramic electric fireplace, highlighting its temperature settings, heat modes, timer function, and safety certifications.



Figure 2.3: The TV stand's open storage cabinet, demonstrating its capacity for media devices, books, and other items.



Figure 2.4: Close-up view of the TV stand's RGB LED strips and the transparent acrylic support columns.

3. Assembly Instructions

Assembly of the Nordivale 70-inch Fireplace TV Stand is required. The product is shipped in two separate boxes, which may arrive on different days. Box 1 typically contains the TV stand components, and Box 2 contains the electric fireplace unit. Follow the provided instructions carefully. Assembly often involves building the main structure upside down before flipping it over. Some holes may not be pre-drilled, requiring firm pressure for screw insertion. Two people are recommended for assembly due to the size and weight of the unit.



Figure 3.1: Illustration of the two-package delivery system for the TV stand and fireplace components.



Figure 3.2: Technical drawing displaying the overall dimensions of the 70-inch TV stand and its components.

4. Operating Instructions

4.1 Electric Fireplace Operation

The integrated 36-inch electric fireplace features realistic crystal stones and offers 5 levels of flame brightness. It includes two heat modes (750W/1500W) and allows temperature adjustment from 62°F to 82°F. An auto shut-off timer can be set from 0 to 8 hours. The fireplace is equipped with overheat protection and is CSA & ETL certified. Controls are available on the unit and via a remote control.



Figure 4.1: Diagram detailing the electric fireplace's control functions and internal components.




Figure 4.2: Visual guide to the 5 flame brightness levels, 12 LED colors, and 12 flame colors, controllable by remote.

4.2 RGB Lighting Control

The TV stand is equipped with unique RGB light strips offering multiple lighting modes and 12 backlight colors. These lights can be controlled via remote control or a dedicated app, allowing for synchronization with voice and music for dynamic effects. Over 60,000 color-changing modes are available to customize your ambiance.



Figure 4.3: Display of the 12 available LED light strip colors to customize the TV stand's appearance.




Figure 4.4: Graphic highlighting the low-noise operation of the fireplace, suitable for quiet environments.

5. Maintenance

To ensure the longevity and optimal appearance of your Nordivale Fireplace TV Stand, follow these maintenance guidelines:

- **Cleaning Surfaces:** Regularly wipe all surfaces with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Fireplace Vents:** Ensure the electric fireplace vents are kept clear of dust and obstructions to maintain proper airflow and prevent overheating.
- **Component Check:** Periodically inspect all screws, bolts, and fasteners to ensure they remain tight and secure. Retighten if necessary.
- **Electrical Components:** Do not attempt to service or repair the electrical components of the fireplace or LED lights yourself. Refer to qualified personnel if issues arise.

6. Troubleshooting

This section addresses common issues you might encounter with your Nordivale Fireplace TV Stand.

- **LED Remote Control Not Working:**

Solution: First, check the battery in the remote control and replace it if necessary. If the issue persists, the LED lights can also be controlled via the dedicated smartphone application. Ensure there are no obstructions between the remote and the receiver.

- **Heater Produces an Odor or Trips Circuit Breaker:**
  Solution: A slight odor from the heater upon initial use is normal and should dissipate after a few hours of operation. If the heater produces a strong, unusual smell, or if it repeatedly trips the circuit breaker, discontinue use immediately. Ensure the fireplace is plugged directly into a wall outlet and not into an overloaded extension cord or power strip. If the problem continues, consult a qualified electrician or contact customer support.
- **Missing or Damaged Parts During Assembly:**
  Solution: Carefully check all packaging materials to ensure no small parts were overlooked. If parts are genuinely missing or damaged, do not proceed with assembly. Contact Nordivale customer support immediately for assistance and replacement parts.

7. Specifications

Feature	Detail
Brand	Nordivale
Model Number	H21426-70BK+H20100-36SWHSNL
Color	Black & White
Size	70 inches
Item Weight	143 Pounds
Item Dimensions (L x W x H)	79.92 x 13.78 x 24.21 inches
Item Depth	13.8 inches
Material Type	Engineered Wood, Wood
Style	Modern
Required Assembly	Yes
Additional Features	Adjustable Flame, Multicolor Flame, Overheat Protection, Water Resistant
Included Components	TV Stand
Tabletop Weight Capacity	132 Lbs
Shelves Weight Capacity	33 Lbs

8. Warranty and Support

For any questions, assistance, or to report missing or damaged parts, please contact Nordivale customer support. Refer to your purchase documentation for specific warranty details and contact information. Our customer service team is available to help with any concerns regarding your product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FS1JLJ75

More documents and user manuals: **https://manuals.plus/**