Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JIAN BOLAND Lock-260

JIAN BOLAND Hidden Door Lock (Model Lock-260) Instruction Manual

Remote Door Lock with Keyless Entry, Electronic Deadbolt

1. Introduction

Thank you for choosing the JIAN BOLAND Hidden Door Lock. This electronic deadbolt provides enhanced security with its concealed design and convenient remote-controlled keyless entry. Designed for easy installation and reliable operation, it is suitable for various applications including homes, offices, and commercial spaces. This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance and security.

2. Package Contents

Please verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- Remote door lock ×1
- Mounting base ×1
- Screw pack ×1
- Adhesive tape ×3
- Remote controller ×4
- English instruction manual ×1



Image 2.1: Package Contents and Dimensions. This image displays all components included in the JIAN BOLAND Hidden Door Lock package, along with a quick reading guide card and key dimensions of the lock unit.

3. Product Features

- **Hidden & Tamper-Resistant Design:** Installed inside the door with no visible keyhole, making it difficult to detect or tamper with. This design helps prevent lock picking and unauthorized access.
- **Remote Control & Keyless Entry:** Control the lock/unlock function via remote control or by touch. Includes four rolling-code remotes, with support for up to ten remotes for multi-user access.
- **Durable Zinc Alloy Build:** Constructed from high-strength zinc alloy, offering resistance to wear, corrosion, and impact for long-lasting use.
- **Easy Installation:** Features adhesive backing and alignment guides for quick setup. No drilling or professional installation is required.
- **Low Power & Backup Design:** Operates on 4 AA batteries (estimated 8–12 months battery life). Includes a Type-C

emergency power port and a low-battery alert system for reliable operation.

- **Inductive Auto-Locking:** Automatically locks when the door closes. This feature is configurable and can be enabled or disabled as needed.



Image 3.1: Key Features Overview. This image highlights the main features of the JIAN BOLAND Hidden Door Lock, including keyless entry, remote control, durable construction, and one-touch locking.



Image 3.2: Hidden Security Design. This image demonstrates how the lock is installed internally, providing hidden security without an exterior keyhole, reducing vulnerability to tampering.



Image 3.3: Premium Zinc Alloy Body. A detailed view of the lock's construction, emphasizing its high-strength zinc alloy material for durability and protection.

4. Setup and Installation

The JIAN BOLAND Hidden Door Lock is designed for easy, drill-free installation. Follow these steps carefully.

4.1. Unboxing and Preparation

Before beginning installation, unbox all components and ensure everything is present as listed in the "Package Contents" section.

Your browser does not support the video tag.

Video 4.1: JIANBOLAND Hidden Door Lock Unboxing. This video demonstrates the unboxing process of the JIAN BOLAND Hidden Door Lock, showing all included components.

4.2. Installation Steps

1. **Choose Location:** Select an appropriate indoor location on your door for the lock unit. Ensure it does not interfere with the door's operation.
2. **Clean Surface:** Clean the door surface where the lock and mounting base will be attached. Ensure it is dry and free of dust or grease.
3. **Apply Adhesive:** Use the provided adhesive tape on the back of the mounting base and the main lock unit.
4. **Position and Attach:** Use the alignment guides to accurately position the mounting base and then the main lock unit on the door. Press firmly to secure.
5. **Secure with Screws (Optional but Recommended):** For added security and stability, use the provided screws to permanently attach the mounting base and lock unit to the door.
6. **Install Batteries:** Open the battery compartment on the lock unit and insert 4 AA batteries, ensuring correct polarity.

For a visual guide, please refer to the installation video linked via the QR code on the Quick Reading Guide Card included in your package. You can scan the QR code or visit: http://qr71.cn/o9tWs1/qvkwUOO

5. Operating Instructions

The JIAN BOLAND Hidden Door Lock offers multiple ways to lock and unlock your door.

5.1. Remote Control Operation

- **Lock:** Press the lock button on the remote control to engage the deadbolt.
- **Unlock:** Press the unlock button on the remote control to retract the deadbolt.
- The remote control has an effective range of up to 65 feet (20 meters) in open areas.
- Up to 10 remote controls can be paired with a single lock unit.



Image 5.1: Remote Unlocking. This image illustrates the remote control functionality and its effective range for locking and unlocking the door.

5.2. One-Touch Locking/Unlocking

- **To Lock:** Tap the upper icon on the lock unit.
- **To Unlock:** Tap the lower icon on the lock unit.
- The touch interface provides a sensitive and quick response.



Image 5.2: Touch to Lock & Unlock. This image details the one-touch operation, showing where to tap on the lock unit to engage or disengage the deadbolt.

5.3. Inductive Auto-Locking

The lock features an inductive auto-locking mechanism that automatically engages the deadbolt when the door closes.

- **Enable/Disable:** Locate the automatic locking switch button on the side of the lock unit (often inside the battery compartment or under a cover). Toggle it to enable or disable the auto-lock function as desired.



Image 5.3: Inductive Auto-Locking. This image illustrates the smart auto-lock feature that engages when the door closes, and shows the switch to configure this function.

Your browser does not support the video tag.

Video 5.4: JIANBOLAND Hidden Door Lock Operation. This video demonstrates the locking and unlocking functionality of the JIAN BOLAND Hidden Door Lock in action.

6. Maintenance

6.1. Battery Replacement

The lock operates on 4 AA batteries, which typically last 8-12 months.

- **Low Battery Alert:** The lock will provide an audible or visual alert when the battery power is low (below 10%). Replace batteries promptly when this alert occurs.
- **Replacement Procedure:** Open the battery compartment, remove the old batteries, and insert new AA batteries, ensuring correct polarity.

6.2. Emergency Power

In case of complete battery depletion, the lock is equipped with a Type-C emergency power port. Connect a Type-C cable to an external power source (e.g., power bank) to temporarily power the lock and gain entry.



Image 6.1: Power System and Low Battery Warning. This diagram illustrates the internal power system, the low battery warning mechanism, and the location of the Type-C emergency power port.

6.3. Cleaning

Wipe the lock unit with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish.

7. Troubleshooting

Problem	Possible Cause	Solution
Lock does not respond to remote.	• Dead batteries in lock or remote. • Remote out of range. • Remote not paired.	• Replace batteries in both lock and remote. • Move closer to the lock. • Refer to pairing instructions (not provided in current data, assume standard pairing process).
Lock does not engage/disengage smoothly.	• Misalignment during installation. • Obstruction in door frame.	• Check alignment of lock unit and mounting base. Reinstall if necessary. • Ensure door frame is clear of debris.
Low battery alert persists after replacement.	• Incorrect battery type or polarity. • Faulty batteries.	• Ensure correct AA batteries are used and inserted with correct polarity. • Try a different set of new batteries.

8. Specifications

Brand:	JIAN BOLAND
Model Number:	Lock-260
Model Name:	Hidden Door Lock
Lock Type:	Deadbolt
Special Feature:	Hidden Lock, Remote-controlled door opener
Control Method:	Remote, Touch
Material:	Plastic, Zinc Alloy
Color:	Silver
Item Dimensions (L x W x H):	6.5 x 1.2 x 3.4 inches (16.5 x 3.0 x 8.6 cm)
Item Weight:	1.5 Pounds (0.68 kg)
Power Source:	4 x AA Batteries
Emergency Power:	Type-C Port
Remote Range:	Up to 65 feet (20 meters) in open area
Included Components:	Lock unit, Mounting base, 4 Remote controls, Screw pack, Adhesive tape, Manual
Recommended Uses:	Residential, Commercial, Vehicle



Image 8.1: Suitable for Various Scenarios. This image illustrates the versatility of the JIAN BOLAND Hidden Door Lock, showing its applicability to different types of doors.

9. Warranty and Support

The JIAN BOLAND Hidden Door Lock comes with a manufacturer's warranty. Please refer to the warranty information provided with your purchase for specific terms and conditions.

- **Manufacturer Warranty:** 1 Year (as per available information).
- For technical support, warranty claims, or any questions regarding your product, please contact the seller,**boland-US**, through your purchase platform.

© 2026 JIAN BOLAND. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FS1JPSW4

More documents and user manuals: **https://manuals.plus/**