

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WSTER](#) /

› [WSTER Portable Bluetooth Speaker JC-810 User Manual](#)

## WSTER JC-810

# WSTER Portable Bluetooth Speaker JC-810 User Manual

Model: JC-810

## INTRODUCTION

This manual provides instructions for the WSTER Portable Bluetooth Speaker, model JC-810. This device is designed to deliver high-quality audio with features suitable for both indoor and outdoor environments. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan.




Figure 1: WSTER Portable Bluetooth Speaker JC-810 (White)

## Key Features:

- **40-Watt High-Power Speaker:** Delivers powerful bass and clear vocals.
- **True Wireless Stereo (TWS):** Connect two speakers for a stereo sound experience.
- **Multiple Input Interfaces:** Supports USB, TF card, and Bluetooth connectivity.
- **Physical Control Buttons:** For easy operation of volume, playback, and mode.
- **Durable and Portable Design:** Suitable for various indoor and outdoor activities.

- **LED Ambient Light:** Integrated lighting feature.

## PACKAGE CONTENTS

---

Ensure all items are present upon unboxing:

- WSTER Portable Bluetooth Speaker JC-810
- Power Cable
- Quick Start Guide

## SETUP

---

### 1. Charging the Speaker

1. Connect the provided power cable to the charging port on the speaker.
2. Plug the other end of the power cable into a compatible USB power adapter (not included) or a USB port.
3. The charging indicator light will illuminate. It will turn off or change color once fully charged.

### 2. Powering On/Off

- To power on, press and hold the **Power button** until the indicator light turns on and you hear an audible prompt.
- To power off, press and hold the **Power button** until the indicator light turns off and you hear an audible prompt.



Figure 2: Speaker control panel showing power button and input ports.

### 3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "**JC-810**" from the list of devices.
4. Once paired, the speaker will emit an audible confirmation, and the LED indicator will stop flashing.

### 4. True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two WSTER JC-810 speakers together:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the **TWS button** (if available, or a designated pairing button) until you hear a pairing prompt.
3. Repeat the process on the second speaker.

- The speakers will automatically connect to each other. Once connected, one speaker will act as the master (left channel) and the other as the slave (right channel).
- Now, connect your mobile device to the master speaker via Bluetooth as described in step 3.

## OPERATING INSTRUCTIONS

### 1. Basic Controls

Button/Control	Function
<b>Power Button</b>	Press and hold to power on/off.
<b>Play/Pause Button</b>	Press to play or pause audio.
<b>Volume Up (+)</b>	Press to increase volume. Hold to skip to next track.
<b>Volume Down (-)</b>	Press to decrease volume. Hold to skip to previous track.
<b>Mode Button (M)</b>	Press to switch between input modes (Bluetooth, USB, TF Card).
<b>LED Light Button</b>	Press to cycle through LED light modes or turn off the light.



Figure 3: Speaker showcasing the LED ambient light feature.

### 2. Using USB and TF Card Inputs

- Insert a USB flash drive or TF (Micro SD) card containing audio files into the respective port on the speaker.
- Press the **Mode button (M)** to switch to USB or TF Card mode.
- The speaker will automatically begin playing audio files from the inserted storage device.



Figure 4: USB and TF card input ports for direct media playback.

### 3. LED Ambient Light Operation

The speaker features an integrated LED ambient light. Press the **LED Light button** to:

- Turn the LED light on/off.
- Cycle through different light modes or colors (if multiple modes are available).

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

## TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the power cable and try again.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"> <li>◦ Ensure the speaker is in pairing mode.</li> <li>◦ Disable and re-enable Bluetooth on your device.</li> <li>◦ Move your device closer to the speaker.</li> <li>◦ Forget the device from your phone's Bluetooth list and try pairing again.</li> </ul>
No sound or low volume.	<ul style="list-style-type: none"> <li>◦ Increase the volume on both the speaker and your connected device.</li> <li>◦ Ensure the speaker is correctly paired or connected via the selected input mode.</li> </ul>
TWS pairing fails.	<ul style="list-style-type: none"> <li>◦ Ensure both speakers are fully charged and not connected to any other Bluetooth device.</li> <li>◦ Repeat the TWS pairing steps carefully.</li> </ul>
USB/TF card not playing.	<ul style="list-style-type: none"> <li>◦ Ensure the speaker is in the correct mode (USB or TF Card).</li> <li>◦ Verify that the audio files on the drive/card are in a compatible format.</li> <li>◦ Check if the USB drive/TF card is inserted correctly and is not corrupted.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model Name	JC-810
Brand	WSTER
Speaker Type	Portable Speaker
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Audio Output Mode	Stereo
Speaker Maximum Output Power	40 Watts
Frequency Response	18 KHz
Special Feature	LED Light, Portable

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	White
Product Dimensions	12.05"D x 4.8"W x 4.8"H
Number of Batteries	2 Nonstandard Battery (included)
Included Components	Power Cable, Quick Start Guide



Figure 5: Product dimensions of the WSTER JC-810 speaker.

## VIDEO DEMONSTRATION

Your browser does not support the video tag.

Video 1: Demonstration of the WSTER Portable Bluetooth Speaker's design and sound capabilities, highlighting its suitability for outdoor use.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in the Quick Start Guide included with your product. You may also visit the official WSTER brand store on Amazon for additional resources and support options.

[Visit the WSTER Store on Amazon](#)

