

[Manuals.plus](#) /

› [BARBERBOSS](#) /

› BarberBoss QR-8005 5-in-1 Electric Shaver for Women Instruction Manual

BARBERBOSS QR-8005

BarberBoss QR-8005 5-in-1 Electric Shaver for Women Instruction Manual

Model: QR-8005

1. INTRODUCTION

The BarberBoss QR-8005 is a versatile 5-in-1 electric shaver kit designed for comprehensive personal care. It includes five interchangeable heads: a body shaver, bikini trimmer, facial epilator, nose and ear trimmer, and eyebrow trimmer. This rechargeable, cordless device supports both wet and dry use, featuring stainless steel blades for a smooth and gentle experience across various body areas.



Premium
Triple-Layer Blade
For smooth result

Stainless-Steel
Dual-Sided Blade
Gentle on tricky areas

Image 1.1: The BarberBoss QR-8005 electric shaver with its various attachments.

2. SAFETY INFORMATION

- Do not immerse the shaver in water for extended periods.
- Keep the device out of reach of children.
- Handle replaceable blades with care to avoid injury.
- Ensure the device is fully dry before charging.

3. PRODUCT COMPONENTS

The BarberBoss QR-8005 kit includes the following:

- Main Shaver Body
- Body Shaver Head
- Bikini Trimmer Head
- Facial Epilator Head
- Nose and Ear Trimmer Head

- Eyebrow Trimmer Head
- Eyebrow Trimmer Combs (3mm, 5mm)
- Bikini Trimmer Combs (1mm, 3mm, 5mm)
- USB Charging Cable
- Cleaning Brush
- Protective Cap



Image 3.1: Overview of the 5 interchangeable shaving heads.

4. SETUP

4.1. Charging the Device

Before first use, fully charge the shaver. Connect the USB charging cable to the device and a compatible 5V 1A USB power source (e.g., computer, power bank, wall adapter). A full charge takes approximately 2 hours and provides up to 90 minutes of cordless use. The LED indicator will show charging status.

Ricarica Rapida Tramite USB-C

Ricarica comoda tramite:

Computer
portatile/PC



Banca di
alimentazione



Presse 5V 1A



2 ore

Pieno carico



90 minuti

Durata




Image 4.1: USB-C fast charging for the shaver.

4.2. Attaching and Detaching Shaver Heads

To attach a head, align it with the main body and gently push down, then rotate clockwise until it clicks into place. To detach, press the release button (if present) or twist counter-clockwise and pull upwards.



Image 4.2: Instructions for easy head switching and cleaning.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off and Wet & Dry Use

Press the power button to turn the shaver on or off. The device is designed for both wet and dry use. For wet shaving, apply shaving gel or foam. For dry shaving, ensure skin is clean and dry.



Perfect for
Wet & Dry Use

Image 5.1: The shaver is suitable for both wet and dry use.

5.2. Using the Body Shaver Head

Attach the body shaver head for general body hair removal on areas such as legs, arms, and underarms. The triple-layer blade system provides a close and smooth shave. Move the shaver gently against the direction of hair growth.



Image 5.2: Using the body shaver head for smooth results.

5.3. Using the Bikini Trimmer Head

Use the bikini trimmer head for sensitive areas. It features a dual-sided blade. For customized trimming lengths, attach one of the bikini trimmer combs (1mm, 3mm, or 5mm). Move the trimmer slowly and carefully.



Image 5.3: The bikini trimmer head with adjustable comb lengths.

5.4. Using the Facial Epilator Head

Attach the facial epilator head for delicate facial areas such as the upper lip, jawline, and cheeks. The rotary blade with a protective mesh ensures gentle hair removal. Move in small, circular motions.



Image 5.4: The facial epilator head for precise hair removal.

5.5. Using the Nose and Ear Trimmer Head

Insert the nose and ear trimmer head into the nostrils or ear canal (not too deep) to remove unwanted hair. The powerful motor ensures quick and painless trimming.

Tagliacapelli per orecchie e naso

Cure indolori per un aspetto curato



Il potente motore rimuove i peli in pochi secondi




clicca per il prossimo

➔

Testina per decespugliatore

Image 5.5: The nose and ear trimmer head for quick hair removal.

5.6. Using the Eyebrow Trimmer Head

Attach the eyebrow trimmer head for shaping and tidying eyebrows. Use the longer blade for removing excess hair and the shorter blade for precise shaping. For uniform length, attach the 3mm or 5mm eyebrow trimmer comb.

Tagliacapelli per sopracciglia

Otteni risultati precisi per le sopracciglia



3mm 5mm

Rimuovi i peli superflui con la lama lunga

Modellare le sopracciglia con una lama corta




clicca per il prossimo

➔

Testina per decespugliatore

Image 5.6: The eyebrow trimmer head with precision combs.

5.7. Travel Lock Function

To activate or deactivate the travel lock, press and hold the power button for 3 seconds. This prevents accidental activation during travel.



Image 5.7: The travel lock feature for convenient and safe transport.

6. MAINTENANCE

6.1. Cleaning the Shaver Heads

After each use, detach the shaver head and rinse it under running water. Use the provided cleaning brush to remove any trapped hairs. Ensure the head is completely dry before reattaching or storing. Do not use harsh chemicals or abrasive cleaners.



Image 6.1: Instructions for easy head switching and cleaning.

6.2. Storage

Store the shaver and its accessories in a dry place, away from direct sunlight and extreme temperatures. Use the protective cap for the main shaver head when not in use.

7. TROUBLESHOOTING

- **Device does not turn on:** Ensure the device is fully charged. Check if the travel lock is activated (deactivate by pressing and holding the power button for 3 seconds).
- **Poor shaving performance:** Ensure the shaver head is clean and free of hair debris. The blades may be dull and require replacement if performance does not improve after cleaning.
- **Device not charging:** Verify that the USB cable is securely connected to both the shaver and the power source. Try a different USB port or power adapter.
- **Irritation after shaving:** Ensure skin is clean before shaving. For wet shaving, use a suitable shaving gel or foam. Shave in the direction of hair growth for sensitive skin.

8. SPECIFICATIONS

Model Number	QR-8005
Power Source	Rechargeable Battery (1 AA included)
Battery Life	Up to 90 minutes
Charging Time	Approximately 2 hours
Dimensions	19.5 x 15.8 x 3.7 cm
Weight	366 grams
Blade Material	Stainless Steel
Head Type	Foil Heads, Rotary Heads
Color	White, Rose Gold
Special Feature	Detachable Head

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact BarberBoss customer service. Our dedicated support team is available to assist you with any questions or concerns regarding your QR-8005 electric shaver.



Image 9.1: BarberBoss customer support is available to help.