Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Miaosical SC-A80K

Miaosical Automatic Cat Feeder (Model SC-A80K) Instruction Manual

Introduction

Welcome to your new Miaosical Automatic Cat Feeder. This device is designed to provide scheduled meals for up to two cats, ensuring consistent feeding habits and precise portion control. Please read this manual thoroughly before use to ensure proper operation and maintenance of your feeder.



The Miaosical automatic cat feeder designed with opposite dual bowls, allowing two cats to eat peacefully side-by-side.

Product Structure

Familiarize yourself with the components of your automatic cat feeder.



An exploded view diagram illustrating the main components of the Miaosical Automatic Cat Feeder, including the lid, desiccant bag holder, food container, transparent strip, anti-clog rotor, and feeding bowls.

- **Safe-Lock Lid:** Secures the food container.
- **Desiccant Bag Holder:** Keeps food fresh and dry.
- **4.2L Container:** Stores dry pet food.
- **Transparent Strip:** Allows visibility of food level.
- **Anti-clog Rotor:** Ensures smooth food dispensing.
- **Pet-safe ABS Bowl:** Standard feeding bowls.
- **Stainless Steel Bowl:** Optional, included with this model for enhanced hygiene.
- **Press Panel:** Control interface for programming.



Close-up view of the feeder's internal mechanism, highlighting the anti-clog rotor designed to prevent kibble jams and ensure smooth food dispensing.

Setup Guide

1. Unpacking and Assembly

Carefully remove all components from the packaging. Ensure all parts listed in the Product Structure section are present

and undamaged.

2. Power Supply

The feeder supports dual power supply options:

- **USB Power Adapter:** Connect the provided 5V USB power adapter to the feeder and a wall outlet for continuous operation.
- **Battery Backup:** For power outages or portability, insert three D-cell batteries (not included) into the battery compartment located at the bottom of the unit.



Image showing the battery compartment at the base of the feeder, designed for three D-cell batteries (not included) as a backup power source, alongside the port for the 5V power adapter.

3. Filling the Food Container


Open the lid and pour dry pet food into the 4.2L container. Ensure the kibble size is between 2-10mm to prevent jamming. Close the lid securely.



A view of the feeder's top opening, where dry kibble is poured into the 4.2-liter food container.

4. Desiccant Bag Installation

Place the desiccant bag (if included) into its holder under the lid to keep the food fresh and dry.




Detail of the desiccant bag holder located on the underside of the feeder's lid, used to maintain food freshness and dryness.

Operating Instructions

1. Control Panel Overview

The feeder features an LCD screen and simple press buttons for setting. The panel automatically locks after 20 seconds of inactivity. Press the 'SET' button for 3 seconds to unlock.



Close-up of the feeder's user-friendly control panel, featuring an LCD screen for displaying settings and simple buttons for navigation and programming.

2. Setting Feeding Schedule

The feeder allows up to 6 meals per day, with 1 to 12 portions per meal (each portion is approximately 4g-8g).

1. Press the 'SET' button to enter programming mode.
2. Use the 'Up' and 'Down' arrows to adjust the meal time (e.g., 1st meal, 2nd meal).
3. Press 'SET' again to confirm the meal time and move to portion setting.

4. Use the 'Up' and 'Down' arrows to select the number of portions for that meal.
5. Repeat for all desired meals.
6. The feeder has a memory function, retaining settings even after power loss.



The Miaosical automatic cat feeder displaying a customizable feeding schedule, illustrating how to program up to six meals per day with specific times.



The feeder actively dispensing dry food into both bowls, demonstrating its ability to distribute equal portions for two cats.

3. Voice Recording Function

Record a 10-second voice message to call your pets at meal times.

1. Press and hold the microphone button until you hear a beep.
2. Speak your message clearly into the microphone.
3. Release the button to save the recording.

4. The recorded message will play automatically at each scheduled meal.



The automatic cat feeder with a speaker, indicating the 10-second voice recording feature that allows owners to personalize meal calls for their pets.

Maintenance and Cleaning

Regular cleaning ensures hygiene and extends the life of your feeder.


1. Disconnect the power adapter and remove any batteries before cleaning.
2. Detach the food tank, lid, and feeding bowls.
3. The pet-safe ABS bowls and optional stainless steel bowls are washable. Hand wash them with mild soap and water.
4. The main unit (with electronic components) is **not washable**. Wipe it clean with a damp cloth.
5. Ensure all parts are completely dry before reassembling and refilling with food.



Detachable components of the Miaosical automatic cat feeder, including the food container and bowls, shown being hand-washed for easy and hygienic maintenance.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions.



A comprehensive troubleshooting table outlining common operational issues and their corresponding solutions for the automatic cat feeder.

Problem	Solution
Buttons can't be pressed	The panel automatically locks without operation for 20 seconds. Please press 'SET' button for 3 seconds to unlock the screen.
Forget the feeding schedule	Unlock the screen, press 'SET' button, then press to view your setting history.
Pet food don't come out	1. Please pour in the dry pet food, make sure the dry food diameter is between 2-10 mm. 2. Check if the batteries power are low. 3. Check if the power adapter is connected.
LCD display don't show	1. The panel automatically locks without operation for 20 seconds. Please press 'SET' button for 3 seconds to unlock the screen. 2. Check if the batteries power are low or power adapter is connected. 3. If the batteries or power adapter is no problem, please contact us.
Can't hear recorded voice	Make sure you have recorded your voice. Unlock screen, press button to check. If you still don't hear the voice, please record again.

SPECIFICATIONS

Feature	Detail
Model Number	SC-A80K
Brand	Miaosical

Feature	Detail
Product Dimensions (L x W x H)	30L x 16W x 27H Centimetres
Item Weight	1.3 Kilograms
Capacity	4.2 Liters
Material	Acrylonitrile Butadiene Styrene (ABS)
Target Species	Cat
Power Source	Corded Electric (5V USB adapter) & 3x D-cell batteries (backup, not included)
Operation Mode	Automatic
Meals per Day	Up to 6
Portions per Meal	Up to 12 (approx. 4g-8g per portion)
Kibble Size	2-10mm
Special Features	Automatic, Feeding Schedule, Portion Control, Programmable, 10s Voice Recorder, Dual Power, Anti-clog Rotor, Dual Bowls, Desiccant Bag Holder
Care Instructions	Hand Wash Only (detachable parts)

Warranty and Support

Warranty Information

This Miaosical Automatic Cat Feeder comes with a **1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty inquiries, please contact Miaosical customer support.
You can visit the Miaosical Store on Amazon for more information or to contact the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FS6KPZCZ

More documents and user manuals: **https://manuals.plus/**