

[Manuals.plus](#) /

› [Mould King](#) /

› Mould King 10239 Lightsaber Building Set Instruction Manual

Mould King 10239

Mould King 10239 Lightsaber Building Set

Model: WX10239SZQMNCA

INTRODUCTION

Thank you for choosing the Mould King 10239 Lightsaber Building Set. This manual provides detailed instructions for assembling, operating, and maintaining your new lightsaber. Please read all instructions carefully before beginning assembly to ensure a correct and enjoyable building experience.

SAFETY INFORMATION

- This product contains small parts and is recommended for individuals aged 14 years and older. Keep out of reach of younger children to prevent choking hazards.
- Do not attempt to modify the electrical components or battery module. Use only the provided or recommended power sources.
- Avoid direct eye exposure to the LED light.
- Ensure all connections are secure during assembly to prevent electrical malfunctions.

PACKAGE CONTENTS

Before starting assembly, verify that all components are present in your package. The Mould King 10239 Lightsaber Building Set includes:

- 1168 Building Parts
- Detailed Paper Instruction Manual
- 3x Light Belt (LED components)
- 1x Battery Box (with rechargeable Lithium Ion battery included)
- 1x Display Nameplate
- 1x Exclusive Sword Stand




Image: Overview of the package contents, highlighting the instruction manual, light belt, and battery box.

ASSEMBLY INSTRUCTIONS

The Mould King 10239 Lightsaber is assembled from 1168 building parts. Follow the included colorful paper instructions step-by-step for a smooth assembly process. It is recommended to organize parts before starting.

1. **Unpack and Sort:** Carefully open the package and sort the building blocks by type or color as indicated in the instruction manual.
2. **Follow Manual:** Refer to the detailed paper instruction manual for sequential building steps. Each step illustrates the parts required and their placement.
3. **Integrate LED Components:** During specific steps, the manual will guide you to integrate the light belts and battery module into the lightsaber structure. Ensure these are correctly positioned and connected.
4. **Assemble Display Stand:** Once the lightsaber is complete, assemble the exclusive sword stand and display nameplate according to their dedicated instructions.



Image: The fully assembled lightsaber, highlighting key features like the rechargeable battery compartment, display nameplate, glowing blade, stand, and activation switch.



Image: The assembled lightsaber positioned on its exclusive display stand.

SETUP

After completing the physical assembly of the lightsaber and its stand, proceed with the electrical setup.

1. **Battery Installation:** Ensure the rechargeable Lithium Ion battery is correctly installed in the battery box as per the manual's diagrams.
2. **Connect Light Belts:** Verify that the 3 light belts are securely connected to the battery module and routed correctly within the lightsaber blade and hilt.
3. **Initial Charge:** If the lightsaber does not illuminate, the battery may require an initial charge. Connect the provided charging cable to the battery box and a suitable USB power source. The charging indicator (if present) will show charging status.

OPERATING INSTRUCTIONS

The Mould King 10239 Lightsaber features interactive light effects.

1. **Power On/Off:** Locate the switch button on the lightsaber hilt. Press the switch to activate the LED light

effects. Press again to turn off.

2. **Light Effects:** The integrated LED parts and battery module are designed to emit light effects, creating a glowing blade.



Image: A user demonstrating the illuminated lightsaber.

MAINTENANCE

Proper care will ensure the longevity of your Mould King Lightsaber.

- **Cleaning:** Use a soft, dry cloth to gently wipe the lightsaber and display stand. Avoid using abrasive cleaners or solvents.
- **Battery Care:** Recharge the battery when the light effects dim or cease to function. Do not overcharge the battery. If storing for an extended period, charge the battery to approximately 50% and store in a cool, dry place.
- **Storage:** When not in use, display the lightsaber on its exclusive stand or store it in a safe place to prevent damage to the building blocks or electrical components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lightsaber does not light up.	Battery is discharged or not properly connected.	Recharge the battery. Ensure the battery box and light belts are securely connected.
Parts are missing during assembly.	Manufacturing or packaging error.	Contact Mould King customer support for replacement parts.
Lightsaber is unstable on the stand.	Stand not assembled correctly.	Review the assembly instructions for the stand and ensure all connections are firm.

SPECIFICATIONS

- **Model Number:** 10239 (WX10239SZQMNCA)
- **Brand:** Mould King
- **Material:** High-quality ABS Plastic
- **Number of Pieces:** 1168
- **Dimensions (Assembled):**
 - Length: 36.3 inches (92.3 cm)
 - Width: 12.7 inches (32.5 cm)
 - Height: 10.5 inches (27.0 cm)
- **Battery Type:** 1x Lithium Ion (included, rechargeable)
- **Recommended Age:** 14+ years




Image: Visual representation of the lightsaber's dimensions.

WARRANTY AND SUPPORT

Mould King products are manufactured to high standards. If you encounter any issues with your building set, such as missing parts or functional defects, please contact Mould King customer support. Provide your model number (10239) and a detailed description of the problem for efficient assistance. Information regarding specific warranty periods can typically be found on the product packaging or the official Mould King website.