

Smtcsl W16

Smtcsl 3-in-1 Wireless Charging Station (Model W16) User Manual

Model: W16

1. INTRODUCTION

This manual provides instructions for the Smtcsl 3-in-1 Wireless Charging Station, Model W16. This device is designed to simultaneously charge your compatible smartphone, Apple Watch, and AirPods. It features a detachable 5000mAh magnetic power bank for portable charging. Please read this manual thoroughly before use to ensure proper operation and safety.

Qi Enable Phones (with Magnetic case)



Wide Compatibility
20W Faster Charger Adapter (include)

iWatch(2.5h)



iWatch S11/10/9/8/7/6/SE3/SE2/SE/5/4/3/2/1

Airpods(2h)



Airpods 4



Airpods 2/3
(wireless charging case)



Airpods Pro
1/2



Galaxy
Buds

iPhone(2-4h)



iPhone Air/17/
17 Pro/17 Pro Max



iPhone 16/16 Plus/
16 Pro/16 Pro Max



iPhone 15/15 Plus/
15 Pro/15 Pro Max



iPhone 14/14 Plus/
14 Pro/14 Pro Max



iPhone 13/13 Mini/
13 Pro/13 Pro Max



iPhone 12/12 Mini/
12 Pro/12 Pro Max



Image 1.1: Smtcsl 3-in-1 Wireless Charging Station with devices.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 3-in-1 Magnetic Charger Stand
- 5000mAh Removable Power Bank
- USB-C to USB-C Cable
- 20W PD Adapter
- User Manual (this document)

3. PRODUCT OVERVIEW

The Smtcsl 3-in-1 Wireless Charging Station offers a versatile charging solution for multiple devices. Key features include:

- **3-in-1 Charging:** Simultaneously charges compatible smartphones, Apple Watches, and AirPods.

- **Detachable Power Bank:** Includes a 5000mAh magnetic power bank for portable use.
- **Wide Compatibility:** Supports iPhone Air/17/16/15/14/13/12 series, Apple Watch 11/10/9/8/7/6/5/4/3/2/SE2/SE3, and AirPods (wireless charging case).
- **Strong Magnetic Connection:** Ensures secure placement and reliable wireless charging for compatible devices.
- **Compact Design:** Designed for portability and to reduce cable clutter.



Image 3.1: Product features and dimensions.

Your browser does not support the video tag.

Video 3.1: Official product overview of the Smtcsl 3-in-1 Wireless Charging Station, demonstrating its features and functionality.

4. SETUP INSTRUCTIONS

1. Connect to Power:

Connect the provided USB-C to USB-C cable to the charging station's USB-C port and the 20W PD adapter. Plug the adapter into a wall outlet. The charging indicators on the base will illuminate briefly.

Multi-functional wireless charging station




Image 4.1: Connecting the charging station to power.

2. Initial Power Bank Charge:

Ensure the detachable 5000mAh power bank is securely seated in its designated slot on the charging stand. It will begin charging automatically if not fully charged. The power bank's indicator lights will show its charging status.

Say Goodbye to Messy Charging Cables



5. OPERATING INSTRUCTIONS

5.1 Charging Your Smartphone

1. Ensure your smartphone is compatible with wireless charging and has a magnetic case if not natively magnetic.
2. Place your smartphone onto the magnetic charging pad of the stand. The magnets will align the phone for optimal charging.
3. The charging indicator light on the base for the phone will illuminate to confirm charging.



Image 5.1: Wide compatibility for various devices.

5.2 Charging Your Apple Watch

1. Place your Apple Watch onto the dedicated watch charging module at the top of the stand.
2. Ensure the watch is correctly positioned for the magnetic charger to engage.
3. The watch display will indicate charging status.

5.3 Charging Your AirPods

1. Place your AirPods (with wireless charging case) onto the designated charging area at the base of the stand.
2. The AirPods case indicator light will show charging status.

5.4 Using the Detachable Power Bank

1. To remove the power bank, gently pull it away from the main charging stand.
2. To charge your phone using the power bank:
 - Press the power bank button to activate it. The indicator lights will show the remaining charge.
 - Align your compatible smartphone (with magnetic case) to the magnetic surface of the power bank.
 - The phone will begin charging wirelessly.
3. The power bank can also charge devices via its USB-C port using a cable.



Fast Charging for iPhone Air/17/16/15 Series

Simply use the USB-C cable to connect the powerbank to your iPhone 16/15 series for fast charging.



20W adapter for fast charging

For a quick full charge of the rechargeable battery pack, use the 20W adapter and the USB-C cable.

Image 5.2: How to charge your phone using the power bank.

5.5 Phone Case Compatibility

For optimal magnetic connection and charging efficiency, use a magnetic-compatible phone case. Cases without magnetic properties or those thicker than 2mm may weaken the magnetic connection and reduce charging performance. Avoid metal cases, cases with magnets, or cases storing credit cards, as these can interfere with wireless charging.

Recommended Phone Cases



► iPhone 12/13/14/15/16/17/Air ► Qi Enable Phone



Magnetic Case



Non Magnetic Case



Magnetic Case



Non Magnetic Case

Cases without Magnetic will weaken magnetic connection.

Image 5.3: Recommended phone cases for magnetic charging.

6. MAINTENANCE

- Keep the charging station and power bank clean and dry. Use a soft, dry cloth to wipe surfaces.
- Avoid exposing the device to extreme temperatures, direct sunlight, or humid environments.
- Do not disassemble or attempt to repair the device yourself. This will void the warranty.
- Ensure proper ventilation around the charging station during use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device not charging or charging slowly.	◦ Improper placement of device. ◦ Non-magnetic or thick phone case. ◦ Insufficient power input. ◦ Foreign objects between charger and device.	◦ Ensure device is centered on the charging area. ◦ Use a magnetic-compatible case or remove the case. ◦ Verify the 20W PD adapter and USB-C cable are correctly connected and functioning. ◦ Remove any metal objects or cards from between the device and charger.
Magnetic connection is weak.	◦ Non-magnetic phone case. ◦ Case thickness.	◦ Use a phone case with integrated magnetic compatibility. ◦ Ensure phone case is not excessively thick (max 2mm recommended).
Charging frequently stops and restarts.	◦ Poor connection. ◦ Overheating.	◦ Re-position the device on the charging pad. ◦ Ensure the charging station is in a well-ventilated area. Disconnect and allow to cool if overheating is suspected.
Power bank not charging.	◦ Not properly seated in the stand. ◦ Charging station not powered.	◦ Ensure the power bank is correctly placed in its slot. ◦ Check that the charging station is connected to a working power outlet.

8. SPECIFICATIONS

Brand	Smtcsl
Model Number	W16
Connector Type	USB Type C
Input Voltage	9 Volts
Output Current	1 Amps
Material	Plastic
Special Feature	Wireless Charging, Detachable Power Bank
Power Bank Capacity	5000mAh
Included Components	3-in-1 Magnetic Charger Stand, 5000mAh Removable Power Bank, USB-C to USB-C Cable, 20W PD Adapter, User Manual

Compatible Devices	iPhone 12/13/14/15/16/17 Series, Apple Watch 1/2/3/4/5/6/7/8/9/10/11/SE2/SE3, AirPods (wireless charging case)
---------------------------	--

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Smtcsl products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included in your package or contact Smtcsl customer support. Keep your purchase receipt as proof of purchase for warranty claims.

9.2 Customer Support

If you encounter any issues or have questions regarding your Smtcsl 3-in-1 Wireless Charging Station, please contact our customer support team. Contact information can typically be found on the product packaging or the official Smtcsl website.

© 2026 Smtcsl. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question