

[Manuals.plus](#) /

› [Olmitos](#) /

› Olmitos EVOL 5-in-1 Tricycle Instruction Manual

Olmitos Evol

Olmitos EVOL 5-in-1 Tricycle Instruction Manual

Model: Evol | Brand: Olmitos

1. INTRODUCTION

The Olmitos EVOL 5-in-1 Tricycle is designed to adapt to your child's growth from 12 months up to 5 years. This versatile product transforms through various stages, offering a safe and comfortable riding experience while promoting motor skills and balance development. It features an adjustable parental push handle, an anti-fall protection bar, a foldable anti-UV canopy, and a padded seat for optimal comfort and safety.



Image: The Olmitos EVOL Tricycle illustrating its five different configurations, adapting to various stages of a child's development.

2. SAFETY INFORMATION

WARNING: Use under adult supervision. Never leave your child unattended while using the tricycle or bike.

- Always ensure all locking mechanisms are securely engaged before use.
- Regularly inspect the tricycle for any loose parts, damage, or wear.
- Ensure your child wears appropriate safety gear, including a helmet, when riding.
- Do not use on public roads, near motor vehicles, steep inclines, or swimming pools.
- The maximum weight capacity for this product is 25 kg (55 lbs).
- The product is suitable for children aged 12 months to 5 years.

3. COMPONENTS INCLUDED

The Olmitos EVOL Tricycle package includes the main structure and various accessories necessary for its 5-in-1 configurations. Please verify all components are present upon unboxing.

- Main Tricycle Frame
- Wheels (Front and Rear)
- Seat with Padded Cushion
- Adjustable Parental Push Handle
- Anti-Fall Protection Bar
- Foldable Anti-UV Canopy
- Footrests (Foldable/Removable)
- Pedals (Removable)
- Mesh Storage Bag
- Assembly Hardware and Tools (if required)

4. SETUP AND ASSEMBLY

Assembly is required for the Olmitos EVOL Tricycle. Detailed assembly instructions are provided in the included manual. Please follow the step-by-step visual guides carefully to ensure correct and safe assembly.

4.1 Initial Assembly

1. Unpack all components and verify against the components list.
2. Attach the front wheel assembly to the main frame.
3. Secure the rear wheels to the frame.
4. Install the seat onto the frame, ensuring it clicks into place.
5. Attach the parental push handle, protection bar, and canopy as per the manual's instructions for the desired initial mode.
6. Ensure all screws, bolts, and quick-release mechanisms are tightened and secured.

4.2 Folding Mechanism

The tricycle features a convenient folding mechanism for easy storage and transport.

Desde 1 año



Image: The Olmitos EVOL Tricycle demonstrating its compact folding mechanism for storage and portability, alongside a child comfortably seated in the tricycle configuration.

1. Remove any detachable accessories such as the canopy or storage bag.
2. Locate the folding release buttons or levers on the frame (refer to your specific manual for exact locations).
3. Press the release mechanisms and carefully fold the tricycle until it locks into its compact position.
4. To unfold, reverse the process, ensuring all parts click securely into place before use.

5. OPERATING MODES (5-IN-1)

The Olmitos EVOL Tricycle offers five distinct modes to accommodate your child's development from 1 to 5 years old.



Reversible



Sin Capota



Triciclo



Bicicleta

Image: Visual representation of the Olimitos EVOL Tricycle's versatile configurations, including reversible seat, no canopy, standard tricycle, and balance bike modes.

5.1 Parental Push Tricycle (Approx. 12-18 months)

In this mode, the tricycle is fully equipped with the parental push handle, safety bar, footrests, and canopy. The child is secured in the seat, and the parent controls the direction and movement.

Hasta los 5 años



Image: An adult pushing the Olmitos EVOL Tricycle with a child seated, demonstrating the parental push handle mode.

5.2 Tricycle with Pedals and Parental Control (Approx. 18-24 months)

As the child grows, the footrests can be removed, and pedals can be engaged. The parental push handle still provides control, allowing the child to practice pedaling while the parent guides.

5.3 Independent Tricycle (Approx. 2-3 years)

Once the child is confident with pedaling and steering, the parental push handle and safety bar can be removed, allowing for independent tricycle riding.

5.4 Balance Bike (Approx. 3-5 years)

The tricycle can be converted into a balance bike by removing the pedals and adjusting the rear wheels closer together. This helps children develop balance and coordination before transitioning to a two-wheeled bicycle.

EVOLUTIVO

Crece con tu pequeño



Image: An older child riding the Olmitos EVOL Tricycle configured as a balance bike, demonstrating its use for developing balance skills.

5.5 Seat Reversibility and Rotation

The seat can be reversed to face the parent, which is ideal for younger children. It also features a 360-degree rotation capability for added versatility and interaction.



Image: The Olmitos EVOL Tricycle showcasing its 360-degree seat rotation feature, allowing the child to face forward or backward.

6. MAINTENANCE

- **Cleaning:** Wipe down the frame and plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners. The fabric parts (canopy, seat cushion) can be spot cleaned or hand washed with mild detergent.
- **Lubrication:** Periodically check and lubricate moving parts such as wheel axles and pedal mechanisms with a silicone-based lubricant.
- **Inspection:** Regularly inspect all bolts, nuts, and fasteners to ensure they are tight. Check wheels for wear and tear, and ensure they spin freely. Inspect the safety harness and protection bar for any damage.
- **Storage:** Store the tricycle in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation. Utilize the folding mechanism for compact storage.

7. TROUBLESHOOTING

- **Wheels not turning smoothly:** Check for debris caught in the wheels or axles. Ensure axles are properly lubricated. Verify that all wheel fasteners are not overtightened.

- **Steering issues:** Ensure the parental push handle is correctly installed and locked. If in independent mode, check the handlebar connection for tightness.
- **Tricycle feels unstable:** Re-check all assembly points, especially the frame connections and wheel attachments. Ensure the product is used on a flat, stable surface.
- **Pedals not engaging:** Verify that the pedals are correctly inserted and locked into the crank arm. Ensure the pedal engagement mechanism is not obstructed.

If you encounter persistent issues not covered here, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	Evol
Product Dimensions (L x W x H)	90 x 45 x 90 cm
Item Weight	6 Kilograms
Manufacturer Recommended Age	12 months - 5 years
Material Type	Aluminum, Plastic
Assembly Required	Yes
Components Included	Structure and accessories

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. For product support, spare parts, or further assistance, please contact Olmitos customer service through their official website or the contact details provided in your product packaging.