Sandisk SDCZ530-128G-G46

SANDISK Extreme Fit USB-C Flash Drive User Manual

Model: SDCZ530-128G-G46

INTRODUCTION

The SANDISK Extreme Fit USB-C Flash Drive is a compact, high-capacity storage solution designed for seamless integration with USB-C devices. Its small form factor allows for a "plug-and-stay" experience, providing expanded storage for computers and tablets without protruding excessively. This drive offers rapid file transfers and is compatible with the SANDISK Memory Zone app for efficient file management.

Compatible with Many Essential USB-C™ Computers and Tablets.

Image: The SANDISK Extreme Fit USB-C Flash Drive connected to a laptop's USB-C port.

SETUP

To set up your SANDISK Extreme Fit USB-C Flash Drive, follow these steps:

1. **Identify the USB-C Port:** Locate an available USB-C port on your computer, tablet, or other compatible device. USB-C ports are typically oval-shaped and reversible.

2. **Insert the Drive:** Gently insert the SANDISK Extreme Fit USB-C Flash Drive into the USB-C port. The drive is designed for a snug, low-profile fit.

3. **Device Recognition:** Your operating system should automatically detect the new drive. A notification may appear, indicating that the device is ready for use. The drive will appear as a removable storage device in your file explorer (Windows) or Finder (Mac).

4. **Optional: Install SANDISK Memory Zone App:** For enhanced file management and backup features, download and install the SANDISK Memory Zone app from the official Sandisk website.

**Transfer Files at Speeds Up To 400MB/s²
(128GB – 1TB).**

²Based on read speed, unless otherwise stated. 1 MB/s = 1 million bytes per second. Based on internal testing; performance may vary depending upon host device, usage conditions, drive capacity, and other factors. USB 3.2 port required.

Image: A hand carefully inserting the compact USB-C flash drive into a laptop's port.

OPERATING INSTRUCTIONS

The SANDISK Extreme Fit USB-C Flash Drive provides straightforward operation for file storage and transfer.

File Transfer

- **Drag and Drop:** To transfer files, open the drive in your computer's file explorer or Finder. Drag and drop files or folders from your computer to the drive, or vice versa.

- **Copy and Paste:** Alternatively, right-click on the desired files or folders, select "Copy," navigate to the destination (either the flash drive or your computer), right-click, and select "Paste."

- **Speed:** The drive supports USB 3.2 Gen 1, offering read speeds up to 400MB/s (for 128GB – 1TB models). Ensure your host device has a USB 3.2 port for optimal performance.

Using SANDISK Memory Zone App

The SANDISK Memory Zone app (available for Windows and Mac devices) allows you to organize, manage, and back up your files. After installation, you can set up automatic backups within the app settings. Refer to the official Sandisk website for detailed app instructions and features.

Image: A close-up view of the SANDISK Extreme Fit USB-C Flash Drive securely plugged into a laptop.

Your browser does not support the video tag.

Video: An overview of the SANDISK Extreme Fit USB-C Flash Drive, highlighting its compact size and storage capabilities. This video demonstrates how the drive provides extra space for various data types.

Maintenance

Proper care ensures the longevity and reliable performance of your flash drive.

- **Safe Removal:** Always safely eject the drive from your device before physically removing it. This prevents data corruption. On Windows, right-click the drive icon in the taskbar and select "Eject." On Mac, drag the drive icon to the Trash or use the "Eject" option in Finder.

- **Physical Handling:** Due to its ultra-low profile design, handle the drive with care when inserting or removing it to avoid accidental damage to the drive or the port. Avoid excessive force or bending.

- **Storage:** Store the drive in a clean, dry environment away from extreme temperatures, moisture, and strong magnetic fields.

- **Cleaning:** If necessary, gently wipe the exterior of the drive with a soft, dry, lint-free cloth. Do not use liquid cleaners or solvents.

Holds Up To a Massive 1TB.[1]

¹GB=1,000,000,000 bytes. 1TB=1,000,000,000,000 bytes. Actual user storage less.

Image: The compact SANDISK Extreme Fit USB-C Flash Drive, designed to remain discreetly in a laptop, being placed into a bag.

TROUBLESHOOTING

If you encounter issues with your SANDISK Extreme Fit USB-C Flash Drive, consider the following:

- **Drive Not Recognized:**

  - Ensure the drive is fully inserted into the USB-C port.
  - Try a different USB-C port on your device.
  - Test the drive on another compatible device to rule out a port issue.
  - Restart your computer or device.
  - Check your device's operating system for driver updates or disk management tools.

- **Slow Transfer Speeds:**

  - Verify that your device's USB-C port supports USB 3.2 Gen 1 or higher. Older USB standards will result in slower speeds.
  - Ensure no other high-bandwidth operations are running in the background.
  - Avoid transferring many small files simultaneously, as this can be slower than transferring a few large files.

- *Note:* Some users have reported the drive may overheat during prolonged heavy use, which can lead to temporary speed reduction. Allow the drive to cool if this occurs.

- **Data Corruption:**

  - Always use the "Safely Remove Hardware" or "Eject" function before unplugging the drive.
  - If data corruption persists, consider reformatting the drive (this will erase all data). Back up important files before reformatting.

SPECIFICATIONS

Feature	Detail
Brand	Sandisk
Model Name	SANDISK Extreme Fit USB-C Flash Drive
Item Model Number	SDCZ530-128G-G46
Memory Storage Capacity	128 GB
Connectivity Technology	USB
Hardware Connectivity Technology	USB Type C
Hardware Interface	USB 3.2 Gen 1
Read Speed	Up to 400 Megabytes Per Second
Color	Black
Product Dimensions (D x W x H)	0.73" x 0.54" x 0.63"
Item Weight	0.096 ounces
Special Feature	Lightweight, Plug-and-Stay Design
UPC	619659222574

Enable Automatic Backup with the SANDISK® Memory Zone™ App³ for Windows® or Mac Devices.

³Download and installation required. Set up automatic backup within app settings. See official Sandisk website for app details.

Image: A close-up view of the SANDISK Extreme Fit USB-C Flash Drive with its compact dimensions clearly indicated.

Your browser does not support the video tag.

Video: A promotional video for the SANDISK Extreme Fit USB-C Flash Drive, showcasing its features and compact design.

WARRANTY AND SUPPORT

For detailed warranty information, product registration, and technical support, please visit the official Sandisk website. Sandisk offers various protection plans, including photo and data recovery services, which can be purchased separately.

- **Official Sandisk Website:** www.sandisk.com

- **SANDISK Memory Zone App:** For app details and support, refer to the Sandisk website.

- **Data Recovery Plans:** Optional 2-year or 3-year Photo and Data Recovery Plans are available for purchase. Refer to Sandisk's official channels for pricing and terms.