Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gitelsnour GCT033G

Gitelsnour Cat Tree GCT033G Instruction Manual

Model: GCT033G | Brand: Gitelsnour

1. Introduction

Thank you for choosing the Gitelsnour Cat Tree GCT033G. This multi-level play tower is designed to provide a safe, comfortable, and engaging environment for your cats, especially large adult cats. Featuring multiple perches, cozy nests, a hammock, and numerous scratching posts, it caters to your cat's natural instincts for climbing, scratching, and resting. Please read this manual carefully before assembly and use to ensure proper setup and long-lasting enjoyment for your feline companions.



Image 1.1: The Gitelsnour Cat Tree GCT033G, designed for large breeds like Maine Coons.

2. Safety Information

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children and pets away during assembly.
- **Check Stability:** After assembly, ensure all screws are tightened and the cat tree is stable. Periodically check for loose parts and tighten as necessary.
- **Placement:** Place the cat tree on a flat, level surface. For added stability, consider using the included wall fixation strap.
- **Indoor Use Only:** This cat tree is designed for indoor use. Do not expose it to outdoor elements.
- **Weight Limit:** While designed for large cats, avoid overloading platforms with multiple heavy cats simultaneously.
- **Inspect for Damage:** Regularly inspect the cat tree for any damage or wear that could pose a hazard to your pets.

3. Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged. Refer to the diagram for visual identification of parts.



Image 3.1: Overview of cat tree components, including the large deep basket and 15 scratching posts.

Note: Specific part labels (A, B, C, etc.) are typically found in the included assembly guide. This diagram provides a general visual reference.

- Baseboard (1 piece)
- Cat Condos/Nests (2 pieces)
- Wooden Perches (2 pieces)
- Top Platform (1 piece)
- Hammock (1 piece)
- Scratching Posts (15 pieces, various lengths)
- Connecting Platforms/Levels (various shapes and sizes)
- Hanging Ball Toy (1 piece)

- Assembly Hardware (screws, bolts, Allen wrench)
- Wall Fixation Strap (1 piece)
- Soft Cushions (for perches and top platform)

4. Assembly Instructions

Follow these steps carefully to assemble your Gitelsnour Cat Tree. It is recommended to have two people for assembly.

1. **Unpack and Identify:** Unpack all components and lay them out. Identify each part using the provided parts list and diagrams.
2. **Assemble the Base:** Attach the longest scratching posts to the main baseboard. Ensure they are securely fastened.
3. **Build Lower Levels:** Connect the first set of platforms and cat condos to the base posts. Follow the numerical sequence or diagram in your specific assembly guide.
4. **Install Middle Levels:** Continue adding scratching posts, platforms, and the second cat condo as per the instructions.
5. **Attach Upper Levels:** Secure the remaining scratching posts and the wooden perches.
6. **Mount the Top Platform and Hammock:** Attach the large removable top platform and the deep hammock to their designated posts.
7. **Add Accessories:** Attach the hanging ball toy and place the soft cushions on the perches and top platform.
8. **Final Tightening:** Once fully assembled, go back and tighten all screws to ensure maximum stability. Do not overtighten.
9. **Wall Fixation (Recommended):** For enhanced stability, especially with active or multiple cats, use the provided wall fixation strap to secure the cat tree to a nearby wall.



Image 4.1: Assembly diagram illustrating the construction process.



Image 4.2: Dimensions and wall fixation detail for enhanced safety.

5. Product Features & Usage

The Gitelsnour Cat Tree GCT033G offers a variety of features designed for your cat's comfort and entertainment:

- **2 Wooden Perches:** Equipped with soft, washable cushions, these perches (45cm x 45cm) provide elevated spots for your cat to observe their surroundings or nap comfortably.
- **Extra Large Removable Top Platform:** A spacious top platform (60cm x 30cm) with fully padded edges and a removable fabric cover offers a prime resting spot.
- **2 Large Cat Condos:** Two spacious enclosed nests (40cm x 45cm x 30cm) offer privacy and security for your cats to hide, sleep, or relax.
- **Deep Hammock:** A suspended, soft-fabric hammock (40cm diameter) creates a secure and cozy resting place.
- **15 Sisal Scratching Posts:** Numerous posts covered in natural sisal rope allow cats to satisfy their scratching instincts, protecting your furniture.
- **Multi-Level Design:** The various platforms and levels facilitate easy climbing and jumping for cats of all sizes.



Image 5.1: Special Wooden Perches with Washable Soft Cushions.



Image 5.2: Extra Large Removable Top Platform.



Image 5.3: Two Large Cat Condos.



Image 5.4: Cats enjoying the multi-level structure.

6. Maintenance

- **Cleaning:** The soft cushions and removable fabric cover of the top platform are machine washable. For other fabric surfaces, use a damp cloth and mild detergent to spot clean. Avoid harsh chemicals.
- **Sisal Rope:** The sisal scratching posts can be cleaned with a brush to remove loose fibers or cat hair.
- **Regular Inspection:** Periodically check all connections and screws to ensure they remain tight. Tighten any loose parts to maintain stability and safety.
- **Damage:** If any part of the cat tree becomes significantly damaged, consider replacing the affected component or the entire unit to prevent injury to your pet.

7. Troubleshooting

- **Instability:** If the cat tree wobbles, ensure it is placed on a flat surface. Re-tighten all screws. If the issue persists,

use the wall fixation strap.

- **Cat Not Using the Tree:** Introduce your cat to the tree gradually. Place treats or familiar toys on different levels. Use catnip to attract them. Spend time playing with your cat around the tree to encourage exploration.
- **Loose Parts:** If you notice any loose parts, immediately tighten them. If a part is broken, contact customer support for replacement options.

8. Specifications

Feature	Detail
Model Name	GCT033G
Product Dimensions (L x W x H)	71 x 46 x 174 cm (27.9 x 18.1 x 68.5 inches)
Item Weight	22.68 kg (50 lbs)
Material	Particle Board, Faux Fur, Sisal Rope
Color	Dark Grey
Mounting Type	Floor Mount (Wall fixation recommended)
Number of Levels	3
Target Species	Cat (Recommended for large cats)
Care Instructions	Machine Washable (cushions)

9. Warranty and Support

Gitelsnour stands behind the quality of its products. For any questions, concerns, or issues regarding your GCT033G Cat Tree, please contact our customer support team. Please have your purchase details and model number ready when contacting support.
Specific warranty details may vary by region and retailer. Please refer to your purchase documentation for precise warranty terms.

© 2023 Gitelsnour. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSCZP8HB

More documents and user manuals: **https://manuals.plus/**