

SINGMOOD S-330

SINGMOOD S-330 Karaoke Machine User Manual

Model: S-330 | Brand: SINGMOOD

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your SINGMOOD S-330 Karaoke Machine. Please read this manual thoroughly before use and retain it for future reference. The S-330 is a portable karaoke system designed to deliver high-fidelity sound with versatile connectivity options, suitable for various entertainment settings.

2. WHAT'S IN THE BOX

Carefully unpack all components and ensure the following items are included:

- 1 x SINGMOOD S-330 Stereo Speaker Unit
- 2 x Wireless UHF Handheld Microphones
- 1 x Charging Cable (for microphones)
- 1 x Power Adapter (for main unit)
- 1 x User Manual
- 1 x Remote Control
- 1 x USB Cable

2 UHF Microphones



Rechargeable



High Fidelity



Stable Signal



Sing ease



Long-range
reception



Image: Contents of the S-330 package, including the main speaker unit, two wireless microphones, and cables.

3. PRODUCT FEATURES

- **High-Fidelity Sound & Deep Bass:** Equipped with 5 speakers (midrange and treble on both sides) and a powerful bottom-positioned subwoofer for 360-degree immersive sound.
- **Tri-band Frequency Technology:** Ensures clear and resonant audio output with a 2.1 channel system.
- **Dual Wireless UHF Microphones:** Provides stable signals with a 40-foot range. Microphones feature adjustable volume, reverb, and voice mixing, and offer up to 10 hours of usage on a single charge.
- **Built-in Rechargeable Battery:** The main unit features a built-in 6000mA battery, allowing for up to 7 hours of portable playback.
- **Versatile Connectivity:** Supports Bluetooth, USB, Aux In, Optical input, and HDMI for connection to various devices like smartphones, tablets, and TVs.
- **Cool RGB Lighting:** Dynamic visual lighting to enhance the atmosphere.
- **Portable Design:** Features a compact design with a portable carrying strap for easy transport.
- **Advanced Dual-DSP Technology:** Dedicated DSP chips for music orchestration and microphone vocal polishing.
- **Powerful Output:** Delivers an impressive 400-watt peak output.



Image: The S-330 unit highlighting its built-in rechargeable battery for extended use.



Image: The two wireless UHF microphones included with the system, emphasizing their key features.



Image: An internal view illustrating the 360-degree surround sound design and speaker placement.



Image: Representation of the Advanced Dual-DSP Technology for enhanced audio processing.

4. SETUP

4.1 Initial Charging

1. Connect the main S-330 unit to a power outlet using the provided power adapter. The unit will begin

charging its internal battery.

2. Charge the wireless microphones using the provided charging cable. An indicator light on the microphones will show charging status.

4.2 Connecting Audio Sources

The S-330 offers multiple ways to connect your music source:

- **Bluetooth:**
 - a. Power on the S-330 unit.
 - b. Press the 'Mode' button on the unit or remote until 'Bluetooth' mode is selected.
 - c. On your device (smartphone, tablet), enable Bluetooth and search for 'SINGMOOD S-330'.
 - d. Select the device to pair. A confirmation sound will indicate successful pairing.
- **AUX Input:** Connect your audio device (e.g., MP3 player) to the AUX IN port on the S-330 using a 3.5mm audio cable (not included). Select 'AUX' mode.
- **Optical Input:** For high-quality digital audio from your TV or sound system, connect an optical cable (not included) to the OPTICAL IN port. Select 'OPTICAL' mode.
- **USB Playback:** Insert a USB flash drive containing MP3 audio files into the USB port. The unit will automatically switch to USB mode and begin playback.
- **HDMI (ARC/eARC):** Connect an HDMI cable (not included) from your TV's HDMI ARC/eARC port to the HDMI port on the S-330. Select 'HDMI' mode. *Note: Some users have reported compatibility issues with HDMI connections. If you experience no audio, please try an Optical or Bluetooth connection.*



Singmood

Small Yet Powerful

Unleash the full potential of your vocals with our karaoke machine featuring an impressive 400-watt peak output, guaranteeing to fill any room with rich, immersive sound.

Image: Visual representation of the various connectivity options available for the S-330.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press and hold the power button on the unit or remote control to turn the machine on or off.

5.2 Mode Selection

Press the 'Mode' button on the unit or remote control to cycle through available input modes: Bluetooth, AUX, Optical, USB, HDMI.

5.3 Microphone Usage

- Turn on the microphones. They should automatically pair with the main unit.
- Adjust microphone volume using the dedicated controls on the remote or the unit.
- Use the 'Reverb' button on the remote to add echo effects to your vocals.
- The 'Voice Mixing' function allows for blending vocal effects.



Image: A detailed view of one of the wireless microphones.

5.4 Music Playback

Once an audio source is connected and selected, use the playback controls (Play/Pause, Next, Previous) on the unit or remote to manage your music.

5.5 Vocal Reduction (ACCO Function)

Press the 'ACCO' button on the remote control to lower the original vocals in a song, effectively converting it into a karaoke track.



Singmood


Cool RGB lighting

Adding dynamic visuals to complement the party atmosphere.

Image: The remote control, indicating the 'ACCO' button for vocal reduction.

5.6 RGB Lighting Control

The unit features dynamic RGB lighting. Use the dedicated button on the unit or remote to cycle through lighting modes or turn them off.



Versatile Connectivity



2 UHF Microphones



Rechargeable



Echo Adjustment



Bluetooth



Lower the vocals



AUX



Portable



TV



PC



IPAD



PHONE



USB

Image: The S-330 unit displaying its cool RGB lighting feature.

5.7 Video Demonstrations

Video: An overview of the SINGMOOD S-330 Karaoke Machine, demonstrating its features and design.

Video: Demonstration of the Bluetooth connectivity feature of the karaoke machine.

Video: A closer look at the S-330 Portable Karaoke Machine and its two wireless microphones.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit and microphones. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** For optimal battery life, fully charge the unit and microphones before long periods of storage. Recharge periodically if stored for extended durations.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Unit not charged or power adapter not connected.	Ensure the power adapter is securely connected and the unit is charged.
No sound from speaker	Volume too low, incorrect input mode, or audio source issue.	Increase volume. Select the correct input mode (Bluetooth, AUX, Optical, USB, HDMI). Check audio source device.
Microphones not working	Microphones not charged, not turned on, or out of range.	Charge microphones. Turn them on. Ensure they are within the 40-foot operating range.
Bluetooth pairing failed	Device too far, Bluetooth not enabled, or incorrect device selected.	Move device closer. Ensure Bluetooth is enabled on your device. Select 'SINGMOOD S-330' from the list.
HDMI audio issues	TV/device compatibility, cable issue, or port setting.	Ensure your TV's HDMI port supports ARC/eARC. Try a different HDMI cable. If issues persist, use Optical or Bluetooth connection.
Remote control delay or unresponsiveness	Low battery in remote, obstruction, or signal interference.	Replace remote control batteries. Ensure a clear line of sight to the unit's IR receiver.

8. SPECIFICATIONS

Feature	Detail
Brand	SINGMOOD
Model Number	S-330
Special Feature	Portable
Color	Black
Power Source	Battery Powered (Built-in 6000mA)
Number of Speakers	5 (including subwoofer)
Connectivity Technology	Bluetooth, Optical, AUX, USB, HDMI
Compatible Devices	Smartphone, Tablet, TV, PC
Audio Output Mode	Stereo
Item Dimensions (D x W x H)	12"D x 7"W x 16"H
Microphones	2 x Wireless UHF Microphones (Rechargeable)

9. WARRANTY

The SINGMOOD S-330 Karaoke Machine comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

10. SUPPORT

If you encounter any issues or have questions regarding your SINGMOOD S-330 Karaoke Machine, please contact our customer support team. We are committed to providing assistance and aim to respond within 24 hours.

For support, please refer to the contact information provided with your product packaging or visit the official SINGMOOD website.