



Manuals.plus /

- › Xixini /
- › Xixini Shoe Cabinet with 6 Flip Drawers Instruction Manual

Xixini 3637383940

Xixini Shoe Cabinet with 6 Flip Drawers

Model: 3637383940 | Brand: Xixini

1. INTRODUCTION

Thank you for choosing the Xixini Shoe Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new shoe storage unit. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1: The Xixini Shoe Cabinet with 6 Flip Drawers in Solid Black.

2. PRODUCT FEATURES

- **Modern Design:** Features a unique wave-like fluted panel and metal handles.
- **Ample Storage:** Equipped with 6 flip-out drawers, each containing two layers, capable of storing up to 36 pairs of shoes.
- **Adjustable Panels:** Each flip-out drawer includes an adjustable or removable panel to customize storage space for various shoe types, including heels, sneakers, flats, and boots.
- **Durable Construction:** Made from optimal MDF and P2 engineered wood for long-term use and scratch resistance.
- **Space-Saving:** Narrow 9.45-inch depth with a flip drawer design, ideal for entryways and compact spaces.
- **Stability:** Includes an anti-tipping device for wall fixation and a sturdy base for strong support.

PRODUCT SIZE

- Natural Oak
- Solid Black
- Solid White
- Light Grey




Image 2: Product dimensions showing 9.44" depth, 47.24" width, and 53.34" height. Internal drawer dimensions are 3.82" and 5.17" for the two layers.




Image 3: Illustration of adjustable and removable panels within the flip drawers to accommodate different shoe sizes and types.

Close-Open

6-Layer Shoe Cabinet




Image 4: Close-up views highlighting the anti-tipping device, stable base, chic metal handle, and the fluted panel design.

3. SAFETY INFORMATION

For your safety and to prevent accidents, it is crucial to follow these guidelines:

- **Anti-Tipping Device:** The shoe cabinet is equipped with an anti-tipping device. This device **must** be fixed to the wall to prevent the cabinet from tipping over, especially in households with children or pets.
- **Assembly:** Ensure all components are correctly assembled and tightened according to the instructions. Do not use the cabinet if any parts are loose or damaged.
- **Weight Distribution:** Distribute items evenly within the drawers to maintain stability. Avoid placing excessively heavy objects on top of the cabinet.
- **Placement:** Place the cabinet on a flat, stable surface.

4. ASSEMBLY INSTRUCTIONS

The Xixini Shoe Cabinet is designed for straightforward assembly. An instruction manual and accessory bags are included with your purchase. Assembly typically takes approximately 2 hours. Using power tools or having two people assist with assembly may reduce the time required.

Steps:

1. Unpack all components and verify against the parts list provided in the included instruction manual.
2. Follow the step-by-step diagrams and instructions in the manual to assemble the frame of the cabinet.
3. Install the flip drawer mechanisms and attach the fluted drawer fronts.
4. Insert the adjustable/removable panels into the drawers as desired.
5. Attach the metal handles to the flip drawers.
6. Secure the anti-tipping device to the top rear of the cabinet and then to a wall stud using appropriate hardware.

If you require assistance during assembly, please refer to the contact information in the Support section of this manual.

Your browser does not support the video tag.

Video 1: An official Xixini video demonstrating the features and assembly process for a similar fluted shoe cabinet with 2 flip drawers. This video illustrates the adjustable panels, stable base, anti-tipping device, and overall design relevant to the 6-drawer model.

5. OPERATING INSTRUCTIONS

The Xixini Shoe Cabinet features a simple flip-drawer operation:

- **Opening Drawers:** Gently pull the metal handle on each drawer to flip it open. The drawers are designed to tilt forward, providing easy access to your shoes.
- **Storing Shoes:** Place shoes on the two internal layers within each flip drawer. Utilize the adjustable or removable panels to optimize space for different shoe heights.
- **Closing Drawers:** Push the drawer back into the cabinet until it is fully closed and flush with the cabinet front.

ADJUSTABLE & REMOVABLE PANELS

- Fit Different Shoe Types ●





Image 5: The shoe cabinet shown in both closed and open positions, demonstrating the flip-drawer functionality.

LARGE STORAGE CAPACITY



Image 6: A visual comparison showing a cluttered shoe area before using the cabinet versus a neat and tidy area after organizing shoes within the cabinet.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your shoe cabinet:

- **Cleaning:** Wipe the cabinet surfaces with a damp cloth. For best results, air-dry immediately after cleaning. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the cabinet to prevent buildup.
- **Spills:** Promptly clean any spills to prevent staining or damage to the wood finish.
- **Avoid Excessive Moisture:** Do not expose the cabinet to excessive moisture or humidity, as this can damage the engineered wood.

7. TROUBLESHOOTING

If you encounter any issues with your Xixini Shoe Cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Drawers do not open/close smoothly.	Obstruction or misaligned components.	Check for any objects blocking the drawer mechanism. Ensure all assembly screws are tightened and components are correctly aligned.
Cabinet feels unstable.	Anti-tipping device not secured or uneven floor.	Verify the anti-tipping device is properly installed and anchored to the wall. Ensure the cabinet is on a level surface. Adjust feet if applicable.
Missing parts during assembly.	Packaging error.	Contact Xixini customer support with your purchase details and the specific missing parts.

For issues not listed here, please contact Xixini customer support.

8. SPECIFICATIONS

- **Brand:** Xixini
- **Model Number:** 3637383940
- **Color:** Solid Black
- **Material:** P2 Engineered Wood
- **Product Dimensions (D x W x H):** 9.45" x 47.24" x 53.35"
- **Item Weight:** 98 Pounds
- **Number of Doors:** 6 (Flip Doors)
- **Number of Shelves (Internal Layers):** 12 (2 per drawer)
- **Installation Type:** Freestanding (with wall anchor requirement)
- **Assembly Required:** Yes
- **Additional Features:** Adjustable, Detachable panels, Heavy Duty, Scratch Resistant, Space Saving

9. WARRANTY AND SUPPORT

Xixini products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official Xixini website.

If you have any questions, require replacement parts, or need further assistance, please contact Xixini customer support. Our friendly support team is available to help.

Contact Information:

- Visit the Xixini Store on Amazon
- Refer to your purchase invoice for direct customer service contact details.