



Manuals.plus /

› AZMKIMI /

› AZMKIMI MR25GA Magic Remote Instruction Manual for LG TVs

AZMKIMI MR25GA

AZMKIMI MR25GA Magic Remote Instruction Manual

MODEL: MR25GA

Brand: AZMKIMI

1. PRODUCT OVERVIEW

The AZMKIMI MR25GA Magic Remote is designed for seamless control of compatible 2025 LG televisions. It integrates Artificial Intelligence (AI) features, a pointer function, and voice control for an enhanced user experience. This remote provides intuitive navigation and quick access to popular streaming services.

AZMKIMI Voice Remote


MR25GA Magic Remote Compatible with LG TVs




FOR QLED SERIES




FOR QLED SERIES



FOR OLED SERIES



FOR OLED SERIES



FOR UHD SERIES



Image 1.1: The AZMKIMI MR25GA Magic Remote shown alongside various LG TV series it is compatible with, including QLED, OLED, and UHD models.

Key Features:

- **AI Voice Control:** Utilize voice commands for searching content, controlling settings, and interacting with your TV.
- **Pointer Function:** Navigate on-screen menus and select items with a motion-sensing pointer.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services and functions.
- **Ergonomic Design:** Compact and comfortable to hold for extended use.

Compatibility:

This remote is compatible with specific 2025 LG TV models, including:

- 2025 LG UHD AI UA77 Series
- 2025 LG QLED AI QNED82A Series
- 2025 LG OLED evo AI G5 Series

AI Voice ID with My Profile



Image 1.2: The MR25GA Magic Remote displayed next to an LG OLED evo AI TV, illustrating its compatibility with 2025 LG TV models.

2. SETUP GUIDE

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



Image 2.1: A visual representation of the MR25GA Magic Remote, highlighting the battery compartment and indicating the requirement for two 1.5V AAA batteries.

2.2 Pairing the Remote with Your TV

After installing the batteries, the remote should automatically attempt to pair with your compatible LG TV. If pairing does not occur automatically:

1. Point the remote control towards your LG TV.
2. Press and hold the **Home** button and the **Back** button simultaneously for approximately 5 seconds until the remote's LED indicator blinks, indicating pairing mode.
3. Follow any on-screen prompts that may appear on your TV to complete the pairing process.

Once successfully paired, the remote's pointer function and voice control will be active.

3. OPERATING INSTRUCTIONS

The MR25GA Magic Remote offers various functions for controlling your LG TV. Familiarize yourself with the button layout and their respective actions.





Image 3.1: A detailed view of the AZMKIMI MR25GA Magic Remote, showing all buttons and their positions.

3.1 Button Functions:

- **Power Button (Red Circle with Line):** Turns the TV on or off.
- **Settings Button (Gear Icon):** Accesses TV settings and quick settings menu.
- **Input Button (Rectangle with Arrow):** Changes the input source (HDMI, AV, etc.).
- **Home Button (House Icon):** Returns to the TV's home screen or launcher.
- **AI / Voice Button (Microphone Icon):** Activates voice control for commands and searches.
- **Pointer / Scroll Wheel (Center Circle):** Moves the on-screen pointer and acts as a scroll wheel for lists. Press to select.
- **Back Button (Curved Arrow):** Returns to the previous screen or menu.
- **Volume Up/Down (+ / -):** Adjusts the TV volume.
- **Mute Button (Speaker with X):** Mutes or unmutes the TV audio.
- **Channel Up/Down (Up/Down Arrows):** Changes TV channels.
- **AD/SAP Button (123 / AD/SAP):** Displays an on-screen number pad for direct channel entry or accesses Audio Description/Secondary Audio Program.
- **Guide Button (GUIDE):** Opens the electronic program guide.
- **List Button (LIST):** Displays a list of channels or recorded programs.
- **Streaming Service Buttons:** Dedicated buttons for Netflix, Prime Video, Disney+, Channels, Sling, and Alexa for quick access to these applications.

MR25GA Magic Remote Compatible with 2025 LG TVs



Works with:

2025 LG UHD AI UA77

2025 LG QNED AI QNED82A

2025 LG OLED evo AI G5

Image 3.2: The MR25GA Magic Remote with its six dedicated application buttons clearly labeled for Netflix, Prime Video, Disney+, Channels, Sling, and Alexa.

3.2 Using AI Voice ID with My Profile:

The remote supports AI Voice ID, which can be linked to your TV's user profiles. This feature allows for personalized recommendations and settings based on voice recognition. To set up or use this feature:

1. Press the **AI / Voice** button.
2. Follow the on-screen instructions to configure your voice profile or select an existing one.
3. Once configured, your TV can recognize your voice and apply your personalized settings and content preferences.




Image 3.3: The MR25GA Magic Remote with a visual overlay emphasizing the 'AI Voice ID with My Profile' feature, indicating personalized user experiences.

4. MAINTENANCE

4.1 Cleaning the Remote

To maintain the remote's functionality and appearance:

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's performance degrades or if the LED indicator does not light up during use. Always

replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries or different types of batteries.

5. TROUBLESHOOTING

If you encounter issues with your AZMKIMI MR25GA Magic Remote, refer to the following troubleshooting steps:

Remote Not Responding:

- **Check Batteries:** Ensure batteries are correctly inserted and have sufficient charge. Replace them if necessary.
- **Re-pair Remote:** If the remote loses connection, try re-pairing it with your TV as described in Section 2.2.
- **Obstructions:** Ensure there are no obstructions between the remote and the TV's sensor.

Pointer Not Working:

- **Re-pair Remote:** The pointer function relies on a stable connection. Re-pairing often resolves this issue.
- **Recalibrate Pointer:** Some LG TVs allow for pointer recalibration in the settings menu. Refer to your TV's user manual for specific instructions.
- **Interference:** Minimize potential interference from other wireless devices.

Specific App Buttons Not Working:

- **TV Compatibility:** Ensure your specific LG TV model fully supports the quick access functions for all listed apps. Some older or entry-level compatible models may not support all dedicated buttons.
- **Internet Connection:** Verify your TV has an active internet connection for streaming apps.
- **App Installation:** Ensure the respective applications are installed and updated on your LG TV.

Voice Control Not Working:

- **Microphone Access:** Ensure your TV's settings grant microphone access to the remote.
- **Clear Speech:** Speak clearly and directly into the remote's microphone.
- **Internet Connection:** Voice commands often require an active internet connection.

6. PRODUCT SPECIFICATIONS

Model Number	MR25GA
Brand	AZMKIMI
Power Source	2 x AAA 1.5V Batteries (not included)
Connectivity Technology	Wi-Fi
Compatible Devices	Television (Specific 2025 LG models)
Special Feature	Voice Search, AI, Pointer
Item Weight	2.89 ounces
Package Dimensions	7.05 x 2.01 x 0.94 inches



Image 6.1: Multiple views of the MR25GA Magic Remote, showcasing its front, side profile, and rear design with FCC information.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact AZMKIMI customer service directly. Contact details can typically be found on the manufacturer's official website or through your retailer.

