Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dkenicor KF620005

Dkenicor KF620005 Collapsible Utility Cart User Manual

Model: KF620005 | Brand: Dkenicor

Introduction

Thank you for choosing the Dkenicor KF620005 Collapsible Utility Cart. This versatile 8-in-1 multi-functional cart is designed to simplify your tasks, whether for shopping, moving items in a warehouse, organizing your office, or for outdoor activities. Its robust construction and thoughtful design ensure durability and ease of use. This manual provides essential information for safe and efficient operation.

Safety Information

- Do not exceed the maximum load capacity of 200 lbs (90 lbs for the upper tier, 110 lbs for the lower tier).
- Ensure all parts are securely locked in place before use.
- Avoid using the cart on excessively uneven or steep surfaces to prevent tipping.
- Keep hands and fingers clear of moving parts during folding and unfolding.
- Do not allow children to play with or ride on the cart.
- Always engage the foot brake when the cart is stationary, especially on inclines.

Package Contents

- 1 x Collapsible Utility Cart Frame
- 2 x Collapsible Storage Crates

Setup Instructions

1. **Unfold the Cart Frame:** Place the folded cart on a flat surface. Grasp the handle and gently pull upwards to extend the frame until it locks into an upright position.
2. **Extend the Handle:** Press the button on the handle to adjust its angle to your preferred position (90° or 135°).
3. **Assemble Storage Crates:** Unfold the sides of each crate and push the base down until it locks securely into place.
4. **Place Crates on Cart:** Position the assembled crates onto the designated tiers of the cart. Ensure they sit firmly on

the platforms.

5. **Engage Support Legs (Optional):** For heavier loads or increased stability, extend the support legs located on the sides of the cart.



Figure 1: Unfolding the cart frame.



Figure 2: Assembling and placing the storage crates.

Video 1: Demonstrating the setup and assembly of the Dkenicor utility cart and crates.

Operating Instructions

1. **Loading the Cart:** Place items evenly across the two tiers. Heavier items should be placed on the lower tier for better stability. Adhere to the maximum load capacities for each tier.
2. **Moving the Cart:** Hold the adjustable handle firmly. The 360° swivel front wheels allow for easy maneuverability in various directions.
3. **Engaging the Brake:** To secure the cart in a stationary position, press down on the foot brake pedal located near the rear wheels. To release, simply lift the pedal.



Figure 3: Using the cart for grocery shopping.




Figure 4: Detail of the 360° brake wheels.

Video 2: Demonstrating the use of the Dkenicor Collapsible Shopping Cart in various scenarios.

Folding and Storage

1. **Remove Crates:** Lift the storage crates off the cart platforms.
2. **Collapse Crates:** Fold the sides of each crate inwards until they lie flat.
3. **Fold Cart Frame:** Press the button on the handle and gently push the handle downwards, allowing the cart frame to collapse into its compact, folded state.
4. **Store Compactly:** The folded cart can be stored upright against a wall or laid flat in a car trunk, minimizing space usage.




Figure 5: Folding the cart for storage.




Figure 6: Compact storage of the folded cart.
Video 3: Detailed demonstration of folding the two-layer shopping cart.

Maintenance

- **Cleaning:** Wipe the cart frame and crates with a damp cloth and mild detergent as needed. Avoid abrasive cleaners.
- **Wheel Inspection:** Regularly check the wheels for any debris (hair, string, etc.) that may hinder smooth rotation. Remove any obstructions.

- **Storage:** Store the cart in a dry, cool place away from direct sunlight to prolong its lifespan.

Troubleshooting

Problem	Possible Cause	Solution
Cart does not unfold/fold smoothly	Obstruction in hinges or locking mechanism.	Check for any foreign objects. Ensure the handle button is fully pressed during operation.
Wheels are not rolling freely	Debris caught in wheels or brake engaged.	Remove any debris from the wheels. Disengage the foot brake.
Storage crates do not stay open	Base not fully locked or sides not properly extended.	Ensure the base is pushed down completely and the side panels are securely latched.

Product Specifications

Feature	Detail
Product Dimensions	39.2"D x 24.1"W x 42.7"H
Brand	Dkenicor
Model Number	KF620005
Material	Polypropylene (PP), Aluminum
Weight Limit	200 Pounds (Overall)
Upper Tier Capacity	90 Pounds
Lower Tier Capacity	110 Pounds
Number of Shelves	2
Number of Wheels	4 (360° Swivel Front Wheels)
Special Feature	Lightweight, Foldable, Adjustable Handle, Foot Brake

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Dkenicor website. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSDBWRV2

More documents and user manuals: **https://manuals.plus/**