

Manuals.plus /

- › Belkin /
- › Belkin SoundForm Rhythm ANC True Wireless Earbuds User Manual

Belkin AUC015fqBK

Belkin SoundForm Rhythm ANC True Wireless Earbuds User Manual

Model: AUC015fqBK

			Overview	What's in the		
Box	Setup	Operation	Maintenance	Troubleshooting	Specifications	Warranty

PRODUCT OVERVIEW

The Belkin SoundForm Rhythm ANC True Wireless Earbuds provide a seamless audio experience with Active Noise Cancellation (ANC) and clear call quality. Designed for comfort and durability, these earbuds feature Bluetooth multipoint connectivity, allowing simultaneous connection to two devices. Enjoy extended listening with up to 28 hours of combined battery life (8 hours per earbud plus 20 hours from the charging case) and fast USB-C charging.




Image: Belkin SoundForm Rhythm ANC True Wireless Earbuds and their charging case.

WHAT'S IN THE BOX


- 1 x SoundForm Rhythm ANC Earbuds
- 1 x Charging Case
- 3 pairs of silicone ear tips (S, M, L)
- 1 x USB-C to USB-A charging cable
- Quick Start Guide

How to Control


Smart Touch Controls



Noise Control Modes



EQ Sound Presets



Pairing & Multipoint



Image: All items included in the Belkin SoundForm Rhythm ANC Earbuds package.

SETUP GUIDE

1. Initial Charging

Before first use, ensure the earbuds and charging case are fully charged. Connect the provided USB-C cable to the charging case and a power source. The LED indicators on the case will show charging status.

2. Ear Tip Selection and Fit

For optimal sound quality and comfort, choose the ear tip size that best fits your ears. The package includes small (S), medium (M), and large (L) ear tips. Gently insert the earbud into your ear and adjust for a snug and secure fit.




Image: Visual guide for selecting ear tips and proper earbud placement.

3. Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
3. Select "Belkin SoundForm Rhythm ANC" from the list of available devices.
4. Once connected, the earbuds are ready for use.

4. Bluetooth Multipoint Connection

The earbuds support Bluetooth multipoint, allowing connection to two devices simultaneously. After pairing with the first device, disconnect it, then pair with the second device. Reconnect to the first device, and the earbuds will maintain connection to both, allowing seamless switching between audio sources.

OPERATING INSTRUCTIONS

Touch Controls

The earbuds feature touch-sensitive controls on both the left (L) and right (R) earbuds. Refer to the table below for specific functions:

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause	1 Tap	1 Tap
Next Track	2 Taps	2 Taps
Previous Track	3 Taps	3 Taps
Answer/End Call	2 Taps	2 Taps
Reject Call	Hold 2s	Hold 2s
Voice Assistant	Hold 2s	Hold 2s

What's in the Box

- SoundForm Rhythm ANC Wireless Earbuds
- 3 pairs of silicone ear tips (S, M, L)
- USB-C® charging case
- 1 ft./30cm USB-C charging cable
- Quick Start Guide



Image: Detailed touch control functions for the earbuds.

Noise Control Modes

The earbuds offer three listening modes: Active Noise Cancellation (ANC), Hear-Thru, and Standard. You can switch between these modes by pressing and holding the left earbud for 2 seconds.

- **ANC (Active Noise Cancellation):** Filters out unwanted background noise for immersive sound.
- **Hear-Thru Mode:** Allows ambient noise to pass through, keeping you aware of your surroundings.

- **Standard Listening Mode:** Delivers exceptional audio without active noise cancellation or ambient sound pass-through.




Image: Instructions for switching between noise control modes.

EQ Presets

Customize your listening experience with three Equalizer (EQ) presets: Belkin Signature Sound, Bass Boost, and Balanced. To cycle through these presets, press and hold both the left and right earbuds simultaneously for 1 second.

- **Belkin Signature Sound:** Tuned for balanced bass and crisp highs.
- **Bass Boost:** Provides deeper lows for powerful music.
- **Balanced:** Offers clear and full sound, optimized for podcasts and voices.




Image: Instructions for adjusting EQ presets.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth to wipe the surfaces. For the ear tips, remove them from the earbuds and gently clean with a damp cloth, then allow them to dry completely before reattaching.

Storage

When not in use, store the earbuds in their charging case to protect them and ensure they remain charged. Avoid storing them in extreme temperatures or humid environments.

TROUBLESHOOTING

Earbuds Not Pairing

- Ensure the earbuds are charged and removed from the charging case.
- Verify Bluetooth is enabled on your device.
- Try forgetting the device in your Bluetooth settings and re-pairing.
- Place earbuds back in the case, close the lid, wait a few seconds, then open to reset pairing mode.

Low Sound Quality or Volume

- Check that the ear tips are correctly sized and securely fitted in your ears to create a proper seal.
- Clean any debris from the earbud speakers and ear tips.
- Adjust the volume on both your connected device and the earbuds.
- Cycle through the EQ presets to see if a different setting improves sound.

Active Noise Cancellation Not Working Effectively

- Ensure ANC mode is activated (cycle through modes by holding the left earbud for 2 seconds).
- Confirm a tight seal with the correct ear tip size. A poor seal can significantly reduce ANC performance.

SPECIFICATIONS


Feature	Detail
Model Number	AUC015fqBK
Brand	Belkin
Color	Black
Ear Placement	In Ear
Noise Control	Active Noise Cancellation
Battery Life	8 hours (earbuds) + 20 hours (case) = 28 hours total
Fast Charging	10 minutes charge for 90 minutes playtime
Bluetooth Version	5.4
Bluetooth Range	Up to 30 feet
Water Resistance	IPX5 (sweat and water resistant)
Microphones	4 (2 per earbud) for clear call quality
Driver Size	10mm
Weight	0.15 Pounds (total)
Material	Plastic (made with post-consumer recycled materials)

WARRANTY AND SUPPORT


The Belkin SoundForm Rhythm ANC True Wireless Earbuds come with a **2-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. For warranty claims or technical support, please visit the official Belkin support website or contact their customer service.

Hear It Your Way


Choose from three listening modes for a personalized listening experience.



Standard Listening Mode
Delivers exceptional audio.



Active Noise Cancellation Mode
Filters out unwanted background noise.



Hear-Thru Mode
Keeps you in tune with your surroundings.

Image: Belkin product protection information.

