

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster S290 Portable Bluetooth Speaker Instruction Manual](#)

Monster S290

Monster S290 Portable Bluetooth Speaker Instruction Manual

Model: S290 | Brand: Monster

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Monster S290 Portable Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.



Monster S290 Speaker
Take your favorite
tunes wherever you
adventure!

PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- Monster S290 Speaker x1
- AUX IN Cable x1
- USB-C Charging Cable x1
- Quick Start Guide & Warning Card x1

What's in the Box?

Monster Speaker x1
AUX-IN Cable x1
USB-C Charging Cable x1
Quick Start Guide x1



Image: All components included in the Monster S290 package.

PRODUCT FEATURES

- 30W Powerful Audio:** Delivers crisp highs and deep bass.
- Bluetooth 6.0:** Ensures faster pairing, stable connection, and extended range.
- TWS Pairing:** Connect two S290 speakers for a stereo sound experience.
- 15-Hour Playtime:** Enjoy extended music playback on a single charge.
- Type-C Fast Charge:** Quick and convenient recharging.
- IPX6 Waterproof:** Resistant to splashes, sweat, and rain, suitable for outdoor use.
- Portable Design:** Lightweight with a soft-touch silicone strap for easy carrying.
- Multiple Input Interfaces:** Supports AUX, TF card, and USB playback.




Image: Visual representation of the Monster S290's key features.

SETUP GUIDE

1. Charging the Speaker

Before first use, fully charge the speaker using the provided USB-C charging cable. The charging indicator light will show the charging status.

- Connect the USB-C cable to the speaker's charging port.
- Connect the other end of the cable to a compatible USB power adapter (not included).
- A full charge typically takes approximately 3-4 hours.

2. Powering On/Off

- To power on, press and hold the **Power button** ( for 2-3 seconds until you hear an audible prompt and the LED indicator lights up.
- To power off, press and hold the **Power button** again for 2-3 seconds.



Image: Close-up of the speaker's control panel, illustrating button functions.

3. Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected. The LED indicator will flash blue.

1. Ensure the speaker is powered on and in pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for "Monster S290" in the list of available devices and select it to connect.
4. Once connected, you will hear an audible confirmation, and the LED indicator will turn solid blue.

Your browser does not support the video tag.

Video: Demonstration of the speaker's main functions, including power-on, Bluetooth pairing, and volume control.

4. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two Monster S290 speakers together.

1. Ensure both S290 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the **TWS button** (often indicated by an 'M' or a chain link icon, refer to your quick start guide for exact icon) for 2-3 seconds.
3. The primary speaker will search for the secondary speaker. Once connected, you will hear an audible prompt.
4. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Both speakers will play audio in stereo.



Image: Two Monster S290 speakers demonstrating True Wireless Stereo (TWS) pairing.

5. Connecting via AUX, TF Card, or USB

The speaker supports multiple input options:

- **AUX Input:** Connect an audio device using the provided 3.5mm AUX cable to the AUX port. The speaker will automatically switch to AUX mode.
- **TF Card Playback:** Insert a TF (MicroSD) card with audio files into the TF card slot. The speaker will automatically begin playing music from the card.
- **USB Playback:** Insert a USB flash drive with audio files into the USB port. The speaker will automatically begin playing music from the USB drive.



Image: The speaker's input panel with AUX, TF card, and USB ports.

OPERATING INSTRUCTIONS

Button Functions

- **Power Button (PW):** Press and hold to power on/off. Short press to switch between input modes (Bluetooth, AUX, TF Card, USB).
- **Play/Pause Button (P/PAUSE):** Short press to play or pause music.
- **Volume Down / Previous Track Button (VOL-):** Short press to decrease volume. Long press to go to the previous track.

- **Volume Up / Next Track Button (Volume Up):** Short press to increase volume. Long press to go to the next track.
- **TWS Button (M):** Press and hold to initiate TWS pairing (refer to TWS Pairing section).

Hands-Free Calling

When connected via Bluetooth, the built-in microphone allows for hands-free calling:

- **Answer Call:** Short press the **Play/Pause button**.
- **End Call:** Short press the **Play/Pause button** during a call.
- **Reject Call:** Long press the **Play/Pause button**.

MAINTENANCE

- Keep the speaker away from extreme temperatures, direct sunlight, and corrosive materials.
- Clean the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the charging port cover is securely closed when not charging to maintain IPX6 water resistance.
- Store the speaker in a cool, dry place when not in use for extended periods.

Image: The Monster S290 speaker showcasing its IPX6 water-resistant feature.

TROUBLESHOOTING

Problem	Solution
Speaker does not power on.	Ensure the speaker is charged. Connect it to a power source using the USB-C cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing blue LED). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "Monster S290" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Adjust the volume on both the speaker and your connected device. Ensure the speaker is properly connected via Bluetooth or AUX. Check if the audio source is playing.
TWS pairing failed.	Ensure both speakers are S290 models and are not connected to any other Bluetooth device. Place speakers close to each other and try TWS pairing again.

SPECIFICATIONS

Feature	Detail
Model Name	Monster S290
Material	Plastic

Feature	Detail
Speaker Type	Outdoor
Speaker Maximum Output Power	30 Watts
Wireless Communication Technology	Bluetooth 6.0
Connectivity Technology	Auxiliary, Bluetooth, USB
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Special Features	Portable, 30W Loud Stereo Sound, Support AUX/TF Card, Bluetooth 6.0, True Wireless Stereo, Built-in Mic, 15H Playtime, Hands-Free Calling, IPX6 Waterproof, Skin-Friendly Touch
Power Source	Battery Powered
Battery	1 AAA batteries required (included) - <i>Note: This is likely a generic entry; the speaker features an internal rechargeable battery.</i>
Control Method	Touch
Product Dimensions	6D x 18.2W x 6H Centimetres
Item Weight	490 g
Is Waterproof	True (IPX6)

WARRANTY AND SUPPORT

The Monster S290 Portable Bluetooth Speaker comes with a Limited Warranty. Please refer to the included "Quick Start Guide & Warning Card" for specific warranty terms and conditions. For further support, please contact Monster customer service.