

BESTISAN GM07

BESTISAN GM07 Computer Gaming Speakers User Manual

Model: GM07 | Brand: BESTISAN

1. INTRODUCTION

Thank you for choosing the BESTISAN GM07 Computer Gaming Speakers. These 30W powered monitor speakers are designed to enhance your audio experience for gaming, movies, and music. Featuring versatile connectivity options including Bluetooth, AUX, and Type-C, along with customizable RGB lighting, the GM07 speakers offer powerful sound in a compact design.

This manual provides essential information for setting up, operating, and maintaining your speakers. Please read it thoroughly before use to ensure proper function and to maximize your enjoyment of the product.

2. WHAT'S IN THE BOX

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- BESTISAN GM07 Speakers (2 units)
- Power Cable
- Audio Cable (AUX)
- Quick Start Guide



Image: The package contents for the BESTISAN GM07 speakers, showing the two speaker units, power adapter, AUX cable, and the quick start guide.

3. PRODUCT OVERVIEW

3.1 Speaker Components

Each speaker unit features a front-facing grille covering the audio drivers and an integrated RGB light bar at the base. The primary controls and connection ports are located on one of the speaker units.



Image: An internal view of the speaker, illustrating the acoustic components responsible for sound output.

3.2 Controls and Ports

The main speaker unit includes the following controls and ports:

- **Power/Mode Button:** Short press to switch input modes (Bluetooth/AUX/Type-C). Long press to power off. Double press to change EQ mode.
- **Play/Pause/Light Button:** Short press to play/pause audio. Long press to disconnect Bluetooth. Double press to change light mode.
- **Volume Up (+) Button:** Increases volume.
- **Volume Down (-) Button:** Decreases volume.
- **AUX In Port:** For wired audio connection via 3.5mm audio cable.
- **Type-C Port:** For wired audio connection via Type-C cable.
- **DC Power Input:** Connects to the power adapter.
- **Speaker Output:** Connects to the secondary speaker unit.

SIMPLE BUTTON CONTROL

*Press the power button to switch input modes
(Bluetooth/AUX/Type-C) easily!*



Image: A user interacting with the control buttons located on the top of the speaker unit.



Image: The rear panel of the speaker, highlighting the AUX and Type-C input ports for various device connections.

4. SETUP

4.1 Speaker Placement

Place the two speaker units on either side of your monitor or laptop, ensuring they are at an equal distance from your listening position for optimal stereo sound. The compact design allows them to fit comfortably on most desks.

TRUE IMMERSION STARTS WITH THESE GAMING SPEAKERS



Image: The speakers are set up on a desk, flanking a computer monitor, demonstrating ideal placement.

4.2 Power Connection

1. Connect the power cable to the DC Power Input port on the main speaker unit.
2. Plug the power adapter into a standard wall outlet.

4.3 Connecting the Secondary Speaker

Connect the cable from the secondary speaker unit to the Speaker Output port on the main speaker unit.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Short press the Power/Mode button.
- **Power Off:** Long press the Power/Mode button.

5.2 Switching Input Modes

After powering on, short press the Power/Mode button to cycle through the available input modes: Bluetooth, AUX, and Type-C. The speaker will indicate the current mode.

5.3 Bluetooth Connection

1. Switch the speaker to Bluetooth mode. The indicator light will flash, indicating it is ready for pairing.
2. On your device (phone, laptop, etc.), enable Bluetooth and search for "BESTISAN GM07".
3. Select "BESTISAN GM07" to pair. Once connected, the indicator light will stop flashing.
4. To disconnect Bluetooth, long press the Play/Pause/Light button.

5.4 AUX Connection

Connect your audio source (e.g., computer, gaming console) to the AUX In port on the main speaker unit using the provided 3.5mm audio cable. Switch the speaker to AUX mode.

5.5 Type-C Connection

Connect your audio source (e.g., laptop, monitor) to the Type-C port on the main speaker unit using a compatible Type-C cable. Switch the speaker to Type-C mode.

5.6 Adjusting Volume

Use the Volume Up (+) and Volume Down (-) buttons on the main speaker unit to adjust the audio volume.

5.7 Changing Light Modes

The speakers feature 6 customizable colorful light modes. Double press the Play/Pause/Light button to cycle through the different lighting effects.

HEAR THE BEAT. CHOOSE YOUR COLORFUL LIGHT



Image: The speaker's base illuminated with different colors, demonstrating the customizable lighting options.

6. MAINTENANCE

To ensure the longevity and optimal performance of your BESTISAN GM07 speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker surfaces. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.
- **Dust:** Regularly dust the speaker grilles to prevent accumulation, which can affect sound quality.
- **Environment:** Keep the speakers away from direct sunlight, excessive heat, humidity, and water. Ensure adequate ventilation around the units.
- **Handling:** Avoid dropping or subjecting the speakers to strong impacts.

7. TROUBLESHOOTING

If you encounter issues with your speakers, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound	Speakers not powered on; incorrect input mode; volume too low; loose cable connection; device volume too low.	Ensure speakers are powered on. Switch to the correct input mode (Bluetooth, AUX, Type-C). Increase speaker and device volume. Check all cable connections.
Bluetooth pairing failure	Speakers not in pairing mode; device Bluetooth off; interference; previously paired device connected.	Ensure speakers are in Bluetooth pairing mode (flashing indicator). Turn on Bluetooth on your device. Move closer to speakers. Disconnect from any other paired devices.
RGB lights not working/changing	Incorrect button press; internal issue.	Double press the Play/Pause/Light button to cycle modes. If issue persists, power cycle the speakers.
Distorted sound	Volume too high; poor audio source quality; loose connection.	Reduce volume on both speakers and audio source. Test with a different audio source. Check cable connections.

If the problem persists after trying these solutions, please contact BESTISAN customer support.

8. SPECIFICATIONS

Feature	Detail
Model Name	GM07
Brand	BESTISAN
Speaker Type	Surround Sound
Connectivity Technology	Auxiliary, Bluetooth, Type-C
Speaker Maximum Output Power	30 Watts (29.99 Watts)
Product Dimensions	4.53"D x 4.72"W x 6.77"H
Item Weight	3.41 pounds
Color	Black

Feature	Detail
Mounting Type	Tabletop Mount

9. WARRANTY AND SUPPORT

BESTISAN products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, warranty claims, or any questions regarding your BESTISAN GM07 speakers, please contact BESTISAN customer service through the retailer where you purchased the product or visit the official BESTISAN website for contact information.

Please retain your proof of purchase for warranty purposes.