

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [PeacefulHues](#) /
- › [PeacefulHues Rocking Recliner Chair User Manual \(Model BS-Brown1ak\)](#)

PeacefulHues BS-Brown1ak

PeacefulHues Rocking Recliner Chair User Manual

Model: BS-Brown1ak

1. INTRODUCTION

Thank you for choosing the PeacefulHues Rocking Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read all instructions carefully before use and retain this manual for future reference.

2. SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before use.
- Do not allow children to play on or around the recliner unsupervised.
- Keep hands and feet clear of moving parts during reclining and rocking operations.
- Avoid placing heavy objects on the recliner's backrest or footrest when extended.
- Use the USB charging port only for low-power devices. Overloading may cause damage.
- Disconnect the power cord from the outlet before cleaning or if the chair will be unused for an extended period.
- Do not use the massage or heat functions if you have a medical condition that may be aggravated by them. Consult a physician if unsure.
- Maximum weight capacity: 300 lbs. Do not exceed this limit.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present:

- Recliner Base (with swivel and rocking mechanism)
- Backrest
- Power Adapter
- Remote Control for Massage/Heat
- Assembly Hardware (bolts, washers, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of your PeacefulHues Rocking Recliner Chair is designed to be straightforward, typically taking about 10 minutes with one person.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the recliner base. Slide the backrest down firmly until it clicks into place. Ensure it is securely locked.
3. **Connect Power:** Locate the power cord from the chair and connect it to the provided power adapter. Plug the adapter into a standard electrical outlet.
4. **Verify Functionality:** Once assembled, test the reclining, rocking, swivel, massage, and heat functions to ensure proper operation.



Figure 4.1: Multifunctional rocking chair demonstrating rocking, swivel, and power recline features.

5. OPERATING INSTRUCTIONS

5.1 Reclining Function

To recline the chair, locate the side-pull buckle on the side of the chair. Pull the buckle to release the footrest and lean back to your desired reclining angle. To return to the upright position, push the footrest down with your legs until it locks into place, and the backrest will return to its original position.

5.2 Swivel and Rocking Functions

The chair features a 360° smooth swivel base, allowing you to rotate freely. The gentle rocking motion is always active when the chair is in the upright position, providing a soothing experience.

5.3 Massage and Heat Functions

Your recliner is equipped with 8 vibration massage points located in the back, lumbar, thighs, and legs, along with lumbar heating. These functions are controlled via the included remote control.

- **Power On/Off:** Press the power button on the remote to activate or deactivate the massage and heat functions.
- **Massage Modes:** Use the mode buttons to cycle through different vibration patterns.
- **Intensity Adjustment:** Adjust the massage intensity using the intensity buttons.
- **Targeted Zones:** Select specific massage zones (back, lumbar, thighs, legs) as desired.
- **Heat Function:** Press the heat button to activate the lumbar heating. Press again to turn off.



Figure 5.1: Illustration of massage points and 360° swivel capability.

5.4 USB Charging Port

A built-in USB charging port is located on the side of the chair. This port is designed for charging low-power devices such as smartphones or small tablets. Avoid connecting high-power devices to prevent damage.

5.5 Storage Pockets

The recliner includes dual side pockets and a front storage pocket, ideal for keeping remote controls, books, magazines, or other small items within easy reach.



Figure 5.2: Details of storage pockets and material features.

6. MAINTENANCE

6.1 Cleaning

- **Fabric:** For general cleaning, use a soft, damp cloth with mild soap. Blot spills immediately. Do not use harsh chemicals or abrasive cleaners.
- **Frame:** Wipe metal parts with a dry cloth.

6.2 General Care

- Periodically check all bolts and connections to ensure they remain tight.
- Avoid exposing the chair to direct sunlight or extreme temperatures for prolonged periods, as this may cause fading or material degradation.
- Do not stand on the chair or use it as a step stool.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline	Side-pull buckle not engaged; obstruction	Ensure buckle is pulled completely; check for objects blocking the mechanism.
Massage/Heat not working	Power cord disconnected; remote battery low; power button not pressed	Check power connections; replace remote batteries; press power button on remote.
Chair feels unstable	Loose assembly bolts	Check and tighten all assembly bolts.
USB port not charging	Device requires too much power; cable faulty; power not connected	Ensure device is low-power; try a different USB cable; verify chair is plugged in.

8. SPECIFICATIONS



Figure 8.1: Product Dimensions and Weight Capacity.

Feature	Detail
Brand	PeacefulHues
Model Name	BS-Brown1ak
Color	Brown
Material	Wood frame, Chenille fabric, High-density sponge, PP Cotton
Product Dimensions (Upright)	37.8"D x 38.58"W x 40.16"H
Seat Depth	20.87 inches
Item Weight	108 pounds

Feature	Detail
Weight Capacity	300 lbs
Massage Points	8 vibration points (back, lumbar, thighs, legs)
Heat Function	Lumbar heating
Swivel Angle	360°
USB Port	Yes (for low-power devices)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact PeacefulHues customer service. Details can typically be found on the product packaging or the retailer's website where the product was purchased. Please have your model number (BS-Brown1ak) and purchase date available when contacting support.