

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [INTERGREAT](#) /

› [INTERGREAT 53" H Wall Gun Safe Instruction Manual](#)

## INTERGREAT 53"H Wall Gun Safe

# INTERGREAT 53" H Wall Gun Safe Instruction Manual

Model: 53"H White Wall Gun Safe

### 1. INTRODUCTION

Thank you for choosing the INTERGREAT 53" H Wall Gun Safe. This manual provides essential information for the safe and effective use of your new wall safe. Please read it thoroughly before installation and operation, and keep it for future reference.

### 2. IMPORTANT SAFETY INFORMATION

**WARNING: Failure to follow these instructions may result in serious injury or property damage.**

- Mount this safe to the floor for stability.
- Always follow proper gun safety procedures when handling firearms.
- Keep the safe away from heat sources and do not install it in a location where it may be exposed to extreme temperatures or humidity.
- Store emergency keys in a secure location away from the safe and out of reach of children.
- Ensure the safe is securely installed to prevent unauthorized removal.

### 3. PRODUCT FEATURES

- **Hidden Design:** Designed for discreet installation between wall studs, making it less noticeable.
- **Multiple Unlocking Methods:** Offers three ways to access: digital keypad, fingerprint recognition, and emergency keys.
- **Adjustable Storage:** Includes three removable shelves and key hooks for organized storage of firearms, cash, jewelry, documents, and passports.
- **Spacious Interior:** Internal Dimensions: 14.75"(W) x 5.71"(D) x 49.76"(H). Exterior dimensions: 18"(W) x 5.86"(D) x 53"(H).
- **Anti-Theft Alarm:** Activates a 60-second warning beep after 3 consecutive incorrect password attempts or any significant movement/bumping.

## 4. SETUP AND INSTALLATION

The INTERGREAT Wall Gun Safe is designed for installation between standard wall studs (16-inch on center). It can also be mounted on the outside surface of a wall or secured to the floor.

### 4.1. Wall Installation

For optimal security and discretion, install the safe between wall studs. Ensure the chosen location is free of electrical wiring, plumbing, or other obstructions.

1. **Prepare the Wall:** Locate two adjacent wall studs with 16-inch spacing. Mark the outline of the safe's exterior dimensions on the wall.
2. **Cut the Opening:** Carefully cut an opening in the drywall or other wall material according to your markings.
3. **Insert the Safe:** Slide the safe into the prepared opening. Ensure it fits snugly and is flush with the wall surface.
4. **Secure the Safe:** Use the provided expansion bolts to secure the safe to the wall studs. There are pre-drilled holes inside the safe for this purpose.
5. **Concealment (Optional):** The safe can be hidden behind a painting or within a closet for enhanced discretion.



Figure 1: The INTERGREAT wall gun safe installed discreetly in a closet, demonstrating its easy installation between wall studs.



Figure 2: Installation steps for securing the safe, including drilling at fixed positions and fixing components.




Figure 3: The wall gun safe is suitable for installation in multiple scenarios, including living rooms and bedrooms.

#### 4.2. Battery Installation

The safe requires 4 AAA batteries (not included) to power the electronic lock. Ensure batteries are installed correctly before first use.

1. Locate the internal battery compartment on the lower left corner of the safe.
2. Press the battery compartment cover and take out the battery compartment.
3. Place 4 AAA batteries into the battery compartment according to the markings (+/-). The side with the spring is the negative electrode.
4. Close the battery compartment cover.

Your browser does not support the video tag.

Video 1: This video demonstrates how to install the batteries into the safe's internal battery compartment, ensuring correct polarity.

## 5. OPERATING INSTRUCTIONS

### 5.1. Unlocking the Safe

The safe offers three methods for unlocking:

1. **Digital Keypad:** Enter your programmed password on the keypad.
2. **Fingerprint Recognition:** Place your registered fingerprint on the sensor.
3. **Emergency Key:** In case of battery failure or forgotten password, use the emergency key to manually open the safe.



Figure 4: The three primary methods for unlocking the safe: digital password, fingerprint, and emergency key.

Your browser does not support the video tag.

Video 2: This video provides an overview of the wall gun safe, including a demonstration of its unlocking mechanisms and internal features.

Your browser does not support the video tag.

Video 3: A detailed demonstration of the unlocking methods for the wall gun safe, including key, keypad, and fingerprint access.

## 5.2. Setting Your Password

To ensure security, it is highly recommended to set a new password as soon as you use this wall safe for the first time.

1. After the safe is unlocked and the battery is installed, press and hold the PROGRAM button (located inside the safe) until you hear a beep and the keypad lights up.
2. Enter your new password (the password should be 3-8 digits).
3. Press and release the PROGRAM button to confirm the password.
4. If the password is set successfully, the blue light will blink twice, accompanied by two beeps.
5. To test your new password, keep the door open. Lightly press the keypad to wake it up, then enter the new password to test if it was set successfully. If your new password does not work, please repeat the password setting steps.

Your browser does not support the video tag.

Video 4: This video guides you through the process of setting a new password for your safe, including confirmation and testing.



Figure 5: The safe offers multiple unlocking methods for convenience and security.


## 5.3. Internal Organization

The safe features adjustable shelves and door pockets for versatile storage.

- **Adjustable Shelves:** The three removable shelves can be adjusted up or down to accommodate items of various heights.
- **Door Pockets:** The inside of the door includes pistol pockets, a zippered pocket, and ammunition pockets for smaller items.

# ADJUSTABLE SHELF

Internal shelves can be adjusted up and down, can be removed to increase storage space.



**Please note the dimensions for better installation**

Figure 6: The internal shelves are adjustable and can be removed to increase storage space.

# Multifunctional Wall Safe



Figure 7: The multifunctional wall safe can store both firearms and other valuables like cash and jewelry.

## 6. MAINTENANCE

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- **Battery Replacement:** Replace batteries annually or when the low battery indicator appears to ensure continuous operation of the electronic lock.
- **Key Storage:** Keep emergency keys in a safe, separate location, known only to trusted individuals.

## 7. TROUBLESHOOTING

### 7.1. Anti-Theft Alarm

The safe is equipped with a security smart alarm system:

- If an incorrect password is entered 3 times in a row, the system will activate a continuous warning beep for 60 seconds.
- Any significant movement or bumping of the safe may also trigger the alarm.
- To stop the alarm, enter the correct user code and press "#" to confirm, or power off the system.



Figure 8: The dual alarm system provides security against unauthorized access and tampering.

## 8. SPECIFICATIONS

Feature	Detail
Brand	INTERGREAT
Color	White
Material	Metal
Recommended Uses	Firearms

Feature	Detail
Product Dimensions (Exterior)	18"W x 5.86"D x 53"H
Product Dimensions (Interior)	14.75"W x 5.71"D x 49.76"H
Special Feature	Waterproof
Mounting Type	Wall Mount
Included Components	Shelves
Number of Shelves	3 (Removable)
Lock Type	Electronic (Keypad, Fingerprint, Key)
Assembly Required	No

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact INTERGREAT customer service directly. Keep your purchase receipt as proof of purchase.