

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [ropelux](#) /
- > [ropelux HW-06 Rechargeable Hand Warmers Instruction Manual](#)

ropelux HW-06

ropelux HW-06 Rechargeable Hand Warmers Instruction Manual

Brand: ropelux | Model: HW-06

1. PRODUCT OVERVIEW

The ropelux HW-06 Rechargeable Hand Warmers are designed to provide portable and consistent warmth in cold conditions. Featuring an ultra-slim and lightweight design, these hand warmers are equipped with dual 3200mAh batteries, offering up to 13 hours of heat. They provide three adjustable temperature settings and rapid heating in just 5 seconds. A smart display allows for easy monitoring of battery life and heat levels. Certified for safety, these hand warmers are ideal for outdoor activities, daily commutes, and anyone seeking reliable warmth.



Image: ropelux HW-06 Rechargeable Hand Warmers

2. GETTING STARTED

2.1. Charging the Device

Before first use, fully charge your ropelux HW-06 Hand Warmers. Connect the provided USB charging cable to the charging port on each hand warmer and to a compatible 5V power source. The charging time is approximately 4-4.5 hours. The smart display will indicate the charging status.

Charging Time: 4-4.5H, Input: 5V, Output: 3.7V



Image: Charging the Hand Warmers

2.2. Portability and Storage

The hand warmers are designed to be ultra-slim and portable, fitting easily into gloves, pockets, or purses. They can be connected together for convenient storage and to prevent loss.

A Warm Holiday Gift



Image: Connected Hand Warmers for Storage

3. OPERATING INSTRUCTIONS

3.1. Power On/Off

- To turn ON: Long-press the power button for a few seconds. The device will vibrate and the display will light up.
- To turn OFF: Long-press the power button again until the device powers down.

3.2. Adjusting Heat Settings

The ropelux HW-06 offers three heat settings:

- **Low:** 41–45°C (106–113°F) - Up to 13 hours of heat.
- **Medium:** 46–50°C (114–122°F) - Up to 11 hours of heat.
- **High:** 51–55°C (123–131°F) - Up to 9 hours of heat.

To cycle through the heat settings, short-press the power button. Each press will advance to the next heat level. The display will

show the current temperature.

3 Heating Levels Options

Premium battery 3200mAh*2 keeps long-lasting warmth



Heating Area


Low	Medium	High
		
41-45°C/106-113°F About 13 hours	46-50°C/114-122°F About 11 hours	51-55°C/123-131°F About 9 hours

Image: Three Heat Level Options

3.3. Checking Battery Level and Temperature Unit

- The built-in screen automatically cycles between displaying the current heat level and the remaining battery percentage.
- To toggle between Fahrenheit (°F) and Celsius (°C) temperature units, double-tap the power button.

Simple Operation



Long-press:

Turn ON/OFF

Short-press:

Switch 3 Temperatures

Double-click:

Switch °F/°C

During Operation:

The display automatically cycles between heat level and battery %.

Image: Simple Operation Guide

4. CARE AND MAINTENANCE

- **Cleaning:** Wipe the surface of the hand warmers with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use, store the hand warmers in a cool, dry place. Ensure they are fully charged before long-term storage to maintain battery health.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge when the battery level is low.

5. TROUBLESHOOTING

- **Device not turning on:**
 - Ensure the device is sufficiently charged. Connect to a power source and allow it to charge for at least 30 minutes before attempting to power on again.

- Perform a long-press on the power button (3-5 seconds) to ensure it's not a short press.

- **Device not heating up:**

- Check the battery level. If low, recharge the device.
- Ensure the heat setting is activated by short-pressing the power button to cycle through the heat levels.

- **Device not charging:**

- Verify that the charging cable is securely connected to both the hand warmer and the power source.
- Try using a different USB cable or power adapter to rule out a faulty accessory.

6. TECHNICAL SPECIFICATIONS

Brand	ropelux
Model Number	HW-06
Product Dimensions	9.5 x 5.4 x 1.49 cm
Item Weight	190 g
Battery Capacity	Dual 3200mAh (Total 6400mAh) Lithium-Polymer
Heat Settings	3 Levels (41-55°C / 106-131°F)
Max Heat Duration	Up to 13 hours (on low setting)
Charging Time	4-4.5 Hours
Material	Plastic
Safety Certifications	FCC, UL499 (Built-in smart chip with overcharge, overheat, overvoltage, overcurrent protection)

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact ropelux customer service directly. Keep your purchase receipt for any warranty claims.

