



[Manuals.plus](#) /

› [T4TREAM](#) /

› T4TREAM Fluted 5-Drawer Dresser (Model RCC5FDRDS) Instruction Manual

T4TREAM RCC5FDRDS

T4TREAM Fluted 5-Drawer Dresser Instruction Manual

Model: RCC5FDRDS

1. INTRODUCTION

Thank you for choosing the T4TREAM Fluted 5-Drawer Dresser. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The T4TREAM Fluted 5-Drawer Dresser in Dark Walnut.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Tipping Device:** This dresser is equipped with an anti-tipping device. It is crucial to install this device securely to a wall to prevent accidental tipping, which can cause serious injury.
- **Weight Capacity:** Do not exceed the recommended weight capacity for each drawer or the top surface. Overloading can compromise stability and structural integrity. The top surface can support up to 100 lbs.
- **Rounded Corners:** The dresser features safety-enhanced rounded corners to reduce the risk of injury from accidental bumps.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all hardware is tightened correctly before use.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser.

Product Dimensions

Our dressers are designed to meet the latest stability standards



Image 2.1: Product dimensions and anti-tipping device illustration.

3. PACKAGE CONTENTS

The T4TREAM Fluted 5-Drawer Dresser is delivered in two separate packages. Please ensure you have received both packages and all components are present before starting assembly.

Included Components:

- All necessary wood panels (labeled with serial numbers).
- Hardware pack (screws, dowels, cam locks, etc.).
- Anti-tipping device kit.
- Assembly instructions manual.
- Spare parts pack (for potential loss of hardware during assembly).

4. ASSEMBLY INSTRUCTIONS

Assembly of your T4TREAM dresser is designed to be straightforward, though it may require some time. Follow these steps carefully:

1. **Unpack and Identify:** Carefully unpack all components. Lay them out on a soft, clean surface. Each component is meticulously labeled with a serial number. Refer to the parts list in the included manual to identify each piece.
2. **Follow Step-by-Step Instructions:** Use the provided user-friendly instructions manual. Each step is illustrated to guide you through the process.
3. **Secure Hardware:** Ensure all screws, dowels, and other fasteners are tightened securely. Do not overtighten, as this can damage the engineered wood.
4. **Install Anti-Tipping Device:** Once the dresser is fully assembled and in its final position, install the anti-tipping device to a wall stud using appropriate hardware. This is a critical safety step.
5. **Adjust Feet:** The dresser features adjustable feet. Use these to level the dresser on uneven surfaces, ensuring stability.



Image 4.1: Close-up of chic metal handles and adjustable feet.

5. OPERATING INSTRUCTIONS

Using your T4TREAM dresser is simple and efficient:

- **Drawer Operation:** The dresser features 5 smooth-glide drawers. To open, gently pull the metal handle. To close, push the drawer firmly until it is fully seated.

- **Storage Capacity:** Each drawer offers ample storage space, capable of holding approximately 20-25 T-shirts or 15-20 pairs of jeans. Organize clothing, bedding, cosmetics, jewelry, and other items as needed.
- **Placement:** Position the dresser in your desired location, such as a bedroom, living room, or hallway. Ensure it is on a level surface.



Image 5.1: Illustration of ample storage space within a drawer.

6. MAINTENANCE

To ensure the longevity and appearance of your dresser, follow these maintenance tips:

- **Cleaning:** The surface is waterproof and easy to clean. Wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Hardware:** Periodically check and tighten all hardware to ensure the dresser remains stable.



Image 6.1: Features including waterproof surface, rounded corners, and smooth-sliding drawers.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly or are misaligned.	Incorrect installation of drawer slides or panels.	Review assembly instructions for drawer slide and panel installation. Ensure all screws are tightened and slides are aligned.
Dresser feels wobbly or unstable.	Loose hardware or uneven floor.	Check and tighten all screws and fasteners. Use the adjustable feet to level the dresser on uneven surfaces. Ensure the anti-tipping device is properly installed.
Missing parts or damaged components.	Shipping damage or packaging error.	Contact T4TREAM customer support with your purchase details. Refer to the spare parts pack for minor hardware replacements.

8. SPECIFICATIONS

- **Model:** RCC5FDRDS
- **Dimensions (D x W x H):** 15.7" x 31.5" x 47.6"
- **Number of Drawers:** 5
- **Material:** FSC-Certified Wood, Optimal MDF, P2 Engineered Wood
- **Finish Type:** Painted
- **Color:** Dark Walnut
- **Item Weight:** 125 Pounds
- **Safety Certification:** ASTM F2057-23 (for clothing storage units)
- **Assembly Required:** Yes

9. WARRANTY INFORMATION

T4TREAM products are manufactured with quality and durability in mind. For specific warranty details regarding your Fluted 5-Drawer Dresser, please refer to the warranty card included with your purchase or visit the official T4TREAM website. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

Should you require assistance with assembly, missing parts, or have any questions about your T4TREAM Fluted 5-Drawer Dresser, please contact our customer support team. Refer to the contact information provided in your product packaging or on the official T4TREAM website for the most up-to-date support channels.