Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM RCC6SDRDS-NO

T4TREAM Fluted 6 Drawers Dresser User Manual

Model: RCC6SDRDS-NO

Introduction

Thank you for choosing the T4TREAM Fluted 6 Drawers Dresser. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser features a natural oak finish with a fluted design and curved profile, offering both aesthetic appeal and practical storage. It is designed for use in bedrooms, living rooms, hallways, or as a TV stand.



Image: The T4TREAM Fluted 6 Drawers Dresser in a bedroom setting, showcasing its natural oak finish and fluted design.

Safety Information

Your safety is paramount. This dresser is designed with safety features to minimize risks. Please adhere to the following guidelines:

- **Anti-Tip Mechanism:** This product includes an anti-tip mechanism. It is crucial to install this device securely to a wall to prevent furniture tipping, which can cause serious injury or death, especially to children.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the dresser top (150 lbs) or drawers. Distribute weight evenly.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface. Avoid placing heavy objects on top that could cause instability.



Image: Illustration highlighting the importance of the anti-tip mechanism for child safety, indicating compliance with ASTM F2057-23 safety standards.

Setup and Assembly

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly guide included with your package. Ensure you have all components and tools before starting.

Preparation:

- Unpack all components and verify against the parts list in the assembly guide. Each component is meticulously labeled with serial numbers.
- Lay out all hardware. A pack of spare parts is included in case of loss during assembly.
- Clear a spacious, clean area for assembly.

Assembly Steps:

1. Follow the step-by-step diagrams and instructions in the assembly guide.
2. Ensure all screws and fasteners are tightened securely, but do not overtighten.
3. **Install the Anti-Tip Device:** Once the dresser is fully assembled and in its final position, securely attach the anti-tip device to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.



Image: Diagram illustrating the dresser's dimensions and the proper installation of the anti-tip device.

Operating Instructions

The T4TREAM Fluted 6 Drawers Dresser is designed for convenient storage and versatile use.

Drawer Usage:

- The dresser features six smooth-glide drawers for efficient storage.
- Organize clothing, bedding, cosmetics, jewelry, and other items within the drawers to keep your space tidy.
- To open, gently pull the metal handles. To close, push firmly until the drawer is fully seated.



Image: The dresser with two drawers partially open, revealing neatly folded clothes and towels, demonstrating its storage capacity.

Top Surface Use:

- The wide wooden tabletop can serve as a display area for decorations such as photo frames, plants, or mirrors.
- It can also function as a TV stand. Ensure the television's weight does not exceed the dresser's capacity and that it is placed centrally for stability.



Image: The dresser positioned beneath a wall-mounted television, adorned with decorative items, highlighting its use as a TV stand.

Adjustable Feet:

The dresser is equipped with adjustable feet to ensure stability on uneven surfaces. Rotate the feet clockwise or counter-clockwise to level the unit.

Maintenance

Proper care will extend the life and maintain the appearance of your T4TREAM dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish. The surface is designed to be waterproof and easy to clean.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the wood finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.



Image: A close-up side view of the dresser, highlighting the smooth sliding mechanism of the drawers and the waterproof nature of the top surface.

Troubleshooting

If you encounter any issues with your dresser, please refer to the following common solutions:

- **Drawers do not slide smoothly:** Check that the drawer slides are correctly aligned and free from obstructions. Ensure all screws securing the slides are tight.
- **Dresser is wobbly or unstable:** Verify that the dresser is on a level surface. Adjust the leveling feet at the bottom of the unit until stability is achieved. Confirm all assembly fasteners are securely tightened.
- **Missing or damaged parts:** If you find any parts missing or damaged upon unpacking, please contact customer support immediately for assistance. Refer to the parts list in your assembly guide.

Specifications

Feature	Detail
Brand	T4TREAM
Model Name	RCC6SDRDS-NO
Product Dimensions	15.75"D x 54"W x 36"H
Color	Natural Oak
Item Weight	140 Pounds
Number of Drawers	6
Material	FSC-Certified wood, MDF, P2 engineered wood
Safety Standard	ASTM F2057-23 certified (anti-tip)
Assembly Required	Yes



Image: An infographic detailing key features such as ample storage, sleek curve profile, unique waveform panel, thickened top plate, smooth slide rail, and sturdy leg base.

Warranty and Support

T4TREAM stands behind the quality of its products. For specific warranty details, please refer to the warranty information included with your purchase or visit the official T4TREAM website.

If you require assistance with assembly, have questions about product functionality, or need to report missing/damaged parts, please contact T4TREAM customer support. Contact information can typically be found on the packaging, in the assembly guide, or on the official brand website: T4TREAM Store on Amazon.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSKRB1K7

More documents and user manuals: **https://manuals.plus/**