

[manuals.plus](#) /› [EarFun](#) /› [EarFun Air Pro 4+ Wireless Earbuds Instruction Manual](#)

EarFun Air Pro 4+

EarFun Air Pro 4+ Wireless Earbuds Instruction Manual

Model: TW700B | Brand: EarFun

INTRODUCTION

Thank you for choosing the EarFun Air Pro 4+ Adaptive Noise Cancelling Wireless Earbuds. This manual provides detailed instructions to help you set up, operate, and maintain your earbuds for optimal performance. Please read this manual thoroughly before use and retain it for future reference.

WHAT'S IN THE Box

- EarFun Air Pro 4+ Earbuds
- Charging Case
- USB-C Charging Cable
- User Manual
- Multiple Sizes of Eartips



Image: EarFun Air Pro 4+ earbuds in their charging case, with the lid open.

SETUP

1. Initial Charging

1. Place both earbuds into the charging case.
2. Connect the USB-C cable to the charging port on the case and a power source.
3. Ensure the earbuds and case are fully charged before first use. The LED indicator on the case will show

charging status.

True Simultaneous Multipoint Connection

Enjoy stable connections and seamless switching between two devices with latest Bluetooth 6.0



Multipoint
Connection



Bluetooth® 6.0




Image: The EarFun Air Pro 4+ charging case resting on a wireless charging pad, indicating its wireless charging capability.

2. Selecting the Right Eartips

A proper fit is crucial for sound quality and noise cancellation. Experiment with the included eartips to find the size that provides the best seal and comfort for your ears.

Adaptive Hybrid ANC Tailored to Your Surroundings

QuietSmart™ 3.0 Adaptive Hybrid Active Noise Cancellation up to 50dB

50 dB 



Image: A selection of different sized silicone eartips for the EarFun Air Pro 4+ earbuds, highlighting the importance of finding the correct fit.

3. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode (LEDs will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "EarFun Air Pro 4+" in the list of available devices and select it to connect.
4. For Android devices, Google Fast Pair is supported for quick connection.

Auracast Compatible

Sharing audio and listening to public audio effortlessly with Auracast technology

 AURACAST



LE Audio



Auracast Broadcast



Bluetooth 6.0

Image: EarFun Air Pro 4+ earbuds shown alongside a smartphone and a laptop, illustrating the multipoint connection feature.

OPERATING INSTRUCTIONS

1. Power On/Off

- Power On:** Open the charging case, and the earbuds will automatically power on.
- Power Off:** Place the earbuds back into the charging case and close the lid.

2. Touch Controls

The EarFun Air Pro 4+ features customizable touch controls. Refer to the EarFun App for detailed customization options.

Action	Function (Default)
Single Tap (Left/Right)	Volume Down / Volume Up
Double Tap (Left/Right)	Play/Pause
Triple Tap (Left/Right)	Previous Track / Next Track
Long Press (Left/Right)	Noise Control / Voice Assistant

3. Noise Control Modes

Utilize the EarFun QuietSmart 3.0 technology for various listening experiences:

- **Adaptive Hybrid Active Noise Cancellation (ANC):** Reduces ambient noise by up to 50dB, intelligently adjusting based on your surroundings.
- **Ambient Sound Mode:** Allows you to hear your surroundings while listening to audio.
- **Normal Mode:** Standard audio playback without noise cancellation or ambient sound.
- **Wind Noise Cancelling:** Specifically designed to reduce wind interference during calls or listening outdoors.

4. Multipoint Connection

The earbuds support connecting to two devices simultaneously (e.g., phone and laptop) for seamless switching between audio sources.

5. Auracast Broadcast Audio

With Auracast technology, you can share audio with others or tune into public audio broadcasts in compatible environments.

6. Smart In-Ear Detection

Audio playback automatically pauses when you remove an earbud and resumes when you put it back in.

7. Gaming Mode (Low Latency)

Activate Gaming Mode via the EarFun App for ultra-low latency (under 50ms), enhancing your gaming and video experience.

8. Call Management

Equipped with 6-Mic AI Beamforming and Qualcomm cVc 8.0 technology, the earbuds ensure clear calls by focusing on your voice and suppressing background noise.

CHARGING AND BATTERY

- **Battery Life:** Up to 12 hours on a single charge (normal mode), and up to 54 hours with the charging case.
- **Fast Charging:** A 10-minute charge provides approximately 3 hours of playtime.
- **Charging Case:** Supports both USB-C cable charging and wireless charging.

MAINTENANCE AND CARE

- **Water & Dust Resistance:** The earbuds are IP55 rated, protecting against sweat, light rain, and dust. The charging case is not water-resistant.
- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Ensure charging contacts are free of debris.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and maintain battery life.

TROUBLESHOOTING

If you encounter any issues, please refer to the EarFun App's FAQ section or contact customer support. Common issues and solutions include:

- **No Sound:** Check device volume, earbud battery, and Bluetooth connection.
- **Pairing Issues:** Ensure earbuds are in pairing mode, disable/enable Bluetooth on your device, or reset the

earbuds.

- **Poor Sound Quality:** Check eartip fit, clean earbuds, or adjust EQ settings in the EarFun App.
- **Noise Cancellation Ineffective:** Ensure proper eartip seal and select the appropriate ANC mode.



SPECIFICATIONS

Feature	Detail
Model Name	EarFun Air Pro 4+
Model Number	TW700B
Noise Control	Adaptive Hybrid Active Noise Cancellation (up to 50dB)
Audio Drivers	Dual-Driver Synergy: 10mm composite dynamic driver + ultra-light FeatherBA balanced armature
Connectivity	Bluetooth 6.0
Audio Codecs	Qualcomm aptX Lossless, Snapdragon Sound, LDAC, LC3, LE Audio, SBC, AAC
Microphones	6-Mic AI Beamforming with Qualcomm cVc 8.0 ENC
Battery Life (Earbuds)	Up to 12 hours (Normal Mode)
Total Playtime (with Case)	Up to 54 hours (Normal Mode)
Water Resistance	IP55 (Earbuds only)
Special Features	Multipoint Connection, Auracast Broadcast Audio, Google Fast Pair, Smart In-Ear Detection, Gaming Mode (<50ms latency)
Control Method	App, Touch
Item Weight	1.87 ounces (53 Grams)
Product Dimensions	2.36 x 1.97 x 1.1 inches

WARRANTY AND SUPPORT

EarFun products typically come with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official EarFun website for detailed warranty information and support options. For technical assistance or inquiries, contact EarFun customer service.

Related Documents - Air Pro 4+

	<p><u>EarFun Air Pro 4 ANC Wireless Earbuds User Manual and Troubleshooting Guide</u></p> <p>Comprehensive user manual for EarFun Air Pro 4 ANC Wireless Earbuds, covering app features, pairing, in-ear detection, LDAC, reset, touch controls, LED indicators, specifications, and troubleshooting. Learn how to optimize your audio experience with these Hi-Res Audio Wireless earbuds featuring Qualcomm aptX Adaptive and Snapdragon Sound.</p>
	<p><u>EarFun Free Pro 3 Wireless Earbuds FAQ and Troubleshooting Guide</u></p> <p>Comprehensive FAQ for EarFun Free Pro 3 wireless earbuds, covering setup, usage, sound, calls, ANC, app features, and common troubleshooting steps for connectivity and performance issues.</p>
	<p><u>EarFun Air Pro 4 ANC Wireless Earbuds User Manual</u></p> <p>Discover the EarFun Air Pro 4 ANC Wireless Earbuds user manual. Learn how to fit, pair, and control your earbuds for an enhanced audio experience. This guide covers app features, touch controls, LDAC activation, troubleshooting, and product specifications for optimal use of your Hi-Res Audio Wireless and Qualcomm aptX Adaptive earbuds.</p>
	<p><u>EarFun Air Pro 4 ANC Wireless Earbuds User Manual</u></p> <p>Comprehensive user manual for the EarFun Air Pro 4 ANC Wireless Earbuds, covering app features, fitting, pairing, in-ear detection, LDAC, touch controls, LED indicators, specifications, and troubleshooting. Learn how to optimize your audio experience and manage your earbuds.</p>
	<p><u>EarFun Air Pro 4 ANC Wireless Earbuds User Manual</u></p> <p>User manual for the EarFun Air Pro 4 ANC Wireless Earbuds, detailing features like the EarFun Audio App, fitting instructions, pairing, in-ear detection, LDAC, reset, touch controls, LED indicators, specifications, and troubleshooting.</p>
	<p><u>EarFun Air S ANC Wireless Earbuds User Manual</u></p> <p>Comprehensive user guide for the EarFun Air S ANC Wireless Earbuds, covering setup, pairing, advanced features, specifications, and troubleshooting. Learn how to maximize your audio experience with these advanced wireless earbuds.</p>