

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE 180 x 200 cm Storage Bed Frame with Hydraulic Lift and Storage, Model RMB618GN01 User Manual

VASAGLE RMB618GN01

VASAGLE 180 x 200 cm Storage Bed Frame

Model: RMB618GN01

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Assembly](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the VASAGLE 180 x 200 cm Storage Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read these instructions carefully before beginning assembly and retain them for future reference.

This bed frame features a robust metal structure, a comfortable upholstered headboard, and a hydraulic lift system for convenient under-bed storage. It is designed for mattresses measuring 180 x 200 cm.

VASAGLE
by SONGMICS HOME



Figure 1: Fully assembled VASAGLE storage bed frame (Model RMB618GN01) in a modern bedroom. The bed features a padded headboard and a discreet storage base.

2. SAFETY INFORMATION

- Always follow the assembly instructions step-by-step.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.

- Assembly is recommended for two people to ensure safety and ease.
- Do not allow children to play on or around the hydraulic lift mechanism.
- When lifting the bed base, ensure hands and fingers are clear of pinch points.
- The hydraulic system is designed to hold the bed base in the raised position. Do not attempt to force it down.
- Do not exceed the maximum weight limit of 500 kg for the bed frame.
- Keep small parts out of reach of children during assembly to prevent choking hazards.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Bed frame components (metal frame, wooden slats)
- Upholstered headboard
- Hydraulic lift mechanism (gas springs, locking system)
- Accessory pack (screws, bolts, tools, foam pads)
- Assembly instructions manual

4. SETUP & ASSEMBLY


Assembly of this bed frame is designed to be straightforward with clear, illustrated instructions and labeled parts. Two people can typically assemble the frame in approximately one hour.

4.1. Preparation

- Clear a spacious area for assembly.
- Unpack all components and lay them out, checking against the parts list.
- Ensure you have the necessary tools (usually included in the accessory pack).

4.2. Assembly Steps

1. **Assemble the Bed Frame Base:** Follow the provided diagrams to connect the metal frame sections. Ensure all connections are firm.
2. **Install the Wooden Slats:** Secure the wooden slatted base onto the frame. The foam pads should be attached to the structure to eliminate friction noise.
3. **Attach the Headboard:** Connect the upholstered headboard to the main bed frame.
4. **Install the Hydraulic Lift System:** Carefully attach the hydraulic gas springs and the damping device according to the instructions. This system ensures stable and smooth movements when lifting the bed base.



Dimensions du cadre de lit	Dimensions du matelas	Niveau de confort
198,8 × 143,4 × 110 cm	140 x 190 cm	
209,3 × 163,4 × 110 cm	160 x 200 cm	
209,3 × 183,4 × 110 cm	180 x 200 cm	

Figure 2: Detailed diagram illustrating the overall dimensions of the bed frame (209.3 cm L x 183.4 cm W x 110 cm H) and the internal mattress dimensions (180 x 200 cm).




Figure 3: This image highlights the superior storage capacity of the VASAGLE bed, showing its 35.5 cm under-bed height compared to a typical 30 cm. An illustration depicts the bed's internal storage organized with various items, equating its 1100L capacity to that of a large wardrobe.

5. OPERATING INSTRUCTIONS

5.1. Using the Hydraulic Lift System

The bed frame is equipped with a hydraulic lift system for easy access to the under-bed storage. The integrated damping device ensures smooth and controlled movement, while the cylinder locking system keeps the bed base securely in the raised position.

1. **To Lift:** Grasp the handle or edge of the bed base and lift upwards. The hydraulic system will assist in raising the base smoothly. Continue lifting until the safety lock engages, holding the base in the fully open position.
2. **To Lower:** Gently disengage the safety lock (if applicable, refer to specific mechanism in your manual) and apply slight downward pressure. The hydraulic system will control the descent, preventing rapid drops. Ensure the area beneath the bed is clear before lowering.


Levier hydraulique sûr et facile à soulever



Système hydraulique avec amortisseur

500 kg

Charge maximale
en position relevée



Prévient toute chute
accidentelle du sommier

Testé pour **3500** cycles
d'ouverture et
de fermeture sans dommage

Figure 4: This image demonstrates the hydraulic lift system in action, with the bed base raised to reveal the spacious under-bed storage. The integrated damping device and safety lock are visible, designed to prevent accidental lowering and ensure stable operation. The system is tested for 3500 cycles.

5.2. Hydraulic System Test

It is important to test the hydraulic system correctly after assembly.

- **Pre-installation Test:** The hydraulic lever cannot be tested independently before the bed frame is fully assembled.

- **Post-installation Test:** After installing the bed frame and placing the mattress, lightly press down on the bed base to test its functionality. The system should operate smoothly.

Mode d'emploi du levier hydraulique



Test de pré-installation

Le levier hydraulique ne peut pas être testé de manière indépendante



Test après l'installation

Après avoir installé ce cadre de lit, placez le matelas, puis appuyez légèrement pour tester son fonctionnement



Figure 5: This diagram provides instructions for testing the hydraulic lift system. It clarifies that the hydraulic lever cannot be tested independently before installation. After installation and placing the mattress, the system should be lightly pressed to test its functionality.

6. MAINTENANCE

6.1. Cleaning

- **Frame:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners.
- **Upholstery:** The headboard features removable and washable padding. Detach the padding (secured with hook-and-loop fasteners) and follow the care instructions on the fabric label for cleaning.

Le rembourrage amovible et lavable

Fixée avec des scratchs,
la housse est amovible et lavable pour un nettoyage facile



Figure 6: This image shows a person detaching a section of the headboard padding, highlighting its removable and washable design for easy maintenance and cleaning.

6.2. General Care

- Periodically check all fasteners and re-tighten if they become loose.
- Ensure the foam pads on the structure are intact to maintain quiet operation.
- Avoid placing the bed in direct sunlight or near heat sources to prevent material degradation.

7. TROUBLESHOOTING

- **Issue: Bed frame feels unstable or cannot be assembled solidly.**
Solution: Double-check all connections and ensure every screw and bolt is fully tightened according to the instructions. Verify that no parts are missing or incorrectly installed. If a part is defective (e.g., missing screw threads), contact customer support for replacement.
- **Issue: Bed frame makes creaking noises.**
Solution: Ensure all fasteners are tight. Check if the foam pads on the structure are correctly placed and not damaged. Loose connections or missing pads can cause friction noise.
- **Issue: Hydraulic lift system is difficult to activate or seems stiff.**
Solution: The hydraulic system may require initial force to activate, especially when new. After assembly and placing the mattress, you may need to pull or push with significant strength a few times to get the system moving smoothly. It will become easier after several movements. Ensure the mattress is on the bed when testing, as the weight of the mattress is necessary for the hydraulics to function as intended.
- **Issue: Bed base does not stay in the raised position.**
Solution: Ensure the safety lock mechanism is fully engaged when the bed base is lifted. If the lock is not engaging, inspect the hydraulic cylinders and the locking mechanism for any obstructions or damage.

8. SPECIFICATIONS

Feature	Detail
Model Number	RMB618GN01
Product Dimensions (L x W x H)	209.3 x 183.4 x 110 cm
Item Weight	45.4 kg
Mattress Size Compatibility	180 x 200 cm
Maximum Weight Limit	500 kg
Frame Material	Powder-coated Metal
Upholstery Fabric Type	Linen-look fabric
Color	Slate Grey
Special Feature	Lift-up bed base with hydraulic system and storage space
Under-bed Storage Height	31.7 cm
GTIN	194343509792

9. WARRANTY & SUPPORT

For warranty information, please refer to the documentation provided with your purchase or visit the official VASAGLE website. If you encounter any issues or require assistance with your product, please contact VASAGLE customer support through their official channels.

Keep your purchase receipt and model number (RMB618GN01) handy when contacting support.

© 2026 VASAGLE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question