

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Boytond](#) /

› [Boytond S30i Ultra Open-Ear Earbuds User Manual](#)

Boytond S30i

Boytond S30i Ultra Open-Ear Earbuds User Manual

Model: S30i

INTRODUCTION

Thank you for choosing the Boytond S30i Ultra Open-Ear Earbuds. These earbuds are designed to provide a comfortable listening experience while keeping you aware of your surroundings. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in your package:

- Boytond True Wireless Earbuds (2 units)
- Boytond Charging Case (1 unit)
- Fast Charging USB-C Cable (1 unit)
- Quick Start User Guide (1 unit)

Unbox Your Next Audio Adventure

Boytond True Wireless Earbuds × 2

Boytond Charging Case × 1

Fast Charging USB-C Cable × 1

Quick Start User Guide × 1

Open the Box and Start Your Journey to Superior Sound



Image: The Boytond S30i earbuds, charging case, USB-C cable, and quick start guide laid out.

PRODUCT OVERVIEW

The Boytond S30i earbuds feature an open-ear clip-on design for comfort and situational awareness. They are equipped with Bluetooth 5.3 for stable connectivity and offer extended battery life with the charging case.

Key Features:

- **Open-Ear Design:** Allows you to hear your surroundings while listening to audio.
- **Ergonomic Clip-On Fit:** Designed for secure and comfortable wear, especially for extended use.
- **Bluetooth 5.3:** Provides fast, stable, and low-latency wireless connections.
- **Extended Battery Life:** Up to 10 hours on a single charge, with an additional 40 hours from the charging case.
- **Fast Charging:** 5 minutes of charge provides 1 hour of playback.
- **IPX7 Waterproof:** Suitable for various activities, including workouts.
- **Touch Control:** Intuitive controls for music playback and calls.

Lightweight and Secure Fit

Feather-like Weight Makes It Almost Imperceptible to Feel the Presence of the Earphones

[ 5g]



Image: The Boytond S30i earbuds and charging case.

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer).

3. The LED indicator on the charging case will show the charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.




Image: The charging case with earbuds, connected to a USB-C cable, displaying battery levels.

2. Pairing with Your Device

The earbuds feature smart auto-pairing for convenience.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn on Bluetooth.
3. Search for available devices and select "Boytond S30i" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when taken out of the case.




Image: Boytond S30i earbuds seamlessly connected to multiple devices.

WEARING THE EARBUDS

The S30i earbuds are designed for a secure and comfortable fit around your ear.

1. Identify the left (L) and right (R) earbuds.
2. Gently clip each earbud onto your ear, ensuring the speaker part is positioned near your ear canal and the flexible clip wraps securely around the back of your ear.

3. Adjust the earbud for a snug yet comfortable fit. The flexible design allows for adaptation to various ear shapes.



Image: A diagram illustrating the correct way to wear the clip-on earbuds.

Your browser does not support the video tag.


Video: A user demonstrating how to wear the Boytond S30i earbuds, highlighting their comfortable and secure fit.

OPERATING INSTRUCTIONS

The Boytond S30i earbuds feature intuitive touch controls on each earbud.

Touch Control Functions

Action	Function
Single Tap (either earbud)	Play/Pause Music, Answer/End Call
Double Tap (right earbud)	Next Song
Double Tap (left earbud)	Previous Song
Triple Tap (either earbud)	Voice Assistant
Long Press (2 seconds, either earbud)	Reject Call



Feel Every Note, Enjoy Every Beat

Open-ear Design for All-day Comfort and Effortless Listening

Relax, Listen, and Enjoy—Perfect for Home or Work
Engineered for Comfort, Made for You

Image: Visual guide to the touch controls on the earbuds.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Boytond S30i earbuds.

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. However, the charging case is not waterproof. Ensure earbuds are dry before placing them back in the case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery:** To preserve battery life, charge the earbuds and case regularly, even if not used frequently. Avoid fully depleting the battery for extended periods.

TROUBLESHOOTING

If you encounter any issues with your earbuds, refer to the following common solutions:

Common Issues and Solutions

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Boytond S30i" from your device's Bluetooth list and re-pair.
No sound from one earbud	Place both earbuds back in the charging case, close the lid, wait a few seconds, then take them out again to re-sync. Check device audio balance settings.
Low volume	Adjust volume on both your device and the earbuds (if applicable via touch controls). Ensure earbuds are worn correctly.
Earbuds not charging	Check the charging cable and power source. Ensure the charging contacts on the earbuds and case are clean and free of debris.
Unstable connection	Ensure your device is within the Bluetooth range (33 feet/10 meters). Avoid obstacles between the earbuds and your device.

SPECIFICATIONS

Boytond S30i Earbuds Specifications

Feature	Detail
Model Name	S30i
Brand	Boytond
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Version	5.3
Bluetooth Range	33 Feet (10 meters)

Feature	Detail
Ear Placement	Open Ear
Form Factor	Over Ear (Clip-On)
Battery Life (Earbuds)	Up to 10 Hours
Total Playtime with Case	Up to 50 Hours
Fast Charging	5 minutes charge for 1 hour playback
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Audio Driver Type	Dynamic Driver (16.3mm)
Material	Plastic
Item Weight	0.31 Ounces (per earbud)

WARRANTY AND SUPPORT

Boytond products are designed for reliability and performance. For warranty information and customer support, please refer to the official Boytond website or contact your retailer.

For further assistance, you may also refer to the [Boytond Store on Amazon](#).

