



Manuals.plus /

› Silonn /

› Silonn Clear Ice Cube Maker Countertop (Model SLICM54ST-US) Instruction Manual

Silonn SLICM54ST-US

Silonn Clear Ice Cube Maker Countertop (Model SLICM54ST-US) Instruction Manual

Your guide to crystal clear, slow-melting ice.

1. INTRODUCTION

Thank you for choosing the Silonn Clear Ice Cube Maker Countertop. This appliance is designed to produce high-quality, clear, and slow-melting ice cubes for various beverages. Please read this manual thoroughly before operating the appliance to ensure safe and efficient use. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The Silonn Clear Ice Cube Maker is a compact and efficient countertop appliance designed to provide clear ice cubes. It features a user-friendly interface and multiple functions for convenience.

Key Features:

- **Fast Ice Production:** Produces 3 large 1.6-inch clear ice cubes in approximately 20 minutes, with a daily capacity of up to 26 lbs.
- **Crystal Clear Ice:** Designed to produce transparent, slow-melting ice cubes ideal for whiskey and other beverages, minimizing dilution.
- **Adjustable Ice Thickness:** Offers three size options (thin, medium, thick) by adjusting the ice-making time.
- **Easy-to-Use Control Panel:** Features an LED touch control panel for simple operation, indicating ice-making status, low water, and full ice basket.
- **Dual Cleaning Modes:** Includes both a self-cleaning function and an option for manual cleaning.
- **Compact Design:** Measures 15.04"D x 9.45"W x 14.96"H, suitable for countertop placement.

What's in the Box:

- Silonn Clear Ice Cube Maker
- Ice Scoop
- User Manual



Image: The Silonn Clear Ice Cube Maker Countertop, showcasing its sleek design.

Compact Design



Image: The compact design of the Silonn ice maker, showing its dimensions (15"D x 9.4"W x 15"H).

3. SETUP

- 1. Unpacking:** Carefully remove the ice maker from its packaging. Retain all packaging materials for future transport or storage.
- 2. Placement:** Place the ice maker on a flat, stable, and level surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.
- 3. Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the 'Maintenance and Cleaning' section for detailed instructions.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet (115 Volts).
5. **Add Water:** Open the water reservoir cover and fill the reservoir with potable water up to the 'MAX' fill line. For best results and clearer ice, use purified or distilled water.



Image: Simple steps to add water to the ice maker before operation.

4. OPERATING INSTRUCTIONS

1. **Power On:** Press the 'ICE' button on the LED touch control panel to turn on the ice maker.
2. **Select Ice Thickness:** Use the 'UP/LIGHT' and 'DOWN/SET' buttons to adjust the ice-making time, which determines the thickness of the ice cubes (thin, medium, or thick). A longer time results in thicker ice.
3. **Ice Production:** The appliance will begin the ice-making cycle. The display will show the remaining time for the current cycle.
4. **Ice Collection:** Once ice cubes are formed, they will drop into the ice basket. The unit will automatically stop when the ice basket is full or when water is low.
5. **Serving Ice:** Use the provided ice scoop to retrieve ice cubes from the basket.

Control Panel Overview:

- **ICE Button:** Powers the unit on/off and starts ice production.
- **CLEAN Button:** Initiates the self-cleaning cycle.
- **UP/LIGHT Button:** Adjusts ice thickness setting upwards; also controls internal light.
- **DOWN/SET Button:** Adjusts ice thickness setting downwards; also used for setting.
- **Indicators:** Displays ice-making status, low water warning, and full ice basket alert.

Control With Ease



Image: The LED touch control panel for easy operation and monitoring.

Adjustable Thickness For Drink



Note: Adjust ice making time to choose ice thickness.

Image: Visual representation of adjustable ice thickness options (thin, medium, thick) for different drinks.

Official Product Videos:

Your browser does not support the video tag.

Video: Demonstrates various ice styles produced by Silonn ice makers, including clear cubes, nugget ice, and bullet ice, highlighting their versatility for different beverages.

Your browser does not support the video tag.

Video: Explores the different types of ice produced by Silonn ice makers, showing how each type can enhance various drinks and occasions.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your ice maker.

Self-Cleaning Mode:

1. Ensure the ice basket is empty.
2. Fill the water reservoir with water and a small amount of white vinegar (recommended 5:1 water to vinegar ratio).
3. Press the 'CLEAN' button on the control panel. The unit will run a 15-minute cleaning cycle.
4. After the cycle, drain the water by unplugging the drain plug located at the bottom of the unit.
5. Rinse the reservoir with clean water and drain again to remove any residual cleaning solution.

Manual Cleaning:

- Unplug the appliance before cleaning.
- Remove the ice basket and wash it with mild soap and warm water.
- Wipe the interior and exterior surfaces of the ice maker with a soft cloth dampened with mild detergent.
- Ensure all parts are thoroughly dry before reassembling and operating the unit.

2 Cleaning Modes



Self-Cleaning



Manual Clean




Image: Illustration of the two cleaning modes: Self-Cleaning and Manual Clean.

6. TROUBLESHOOTING

If you encounter issues with your Silonn Clear Ice Cube Maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; water pump malfunction; ambient temperature too high.	Fill water reservoir; contact customer support; ensure unit is in a cool, well-ventilated area.
Ice cubes are cloudy or small.	Water quality; short ice-making cycle.	Use purified or distilled water; adjust ice thickness setting to a longer cycle.
"Water Low" indicator is on.	Insufficient water in the reservoir.	Add water to the reservoir up to the 'MAX' line.
"Ice Full" indicator is on.	Ice basket is full.	Remove ice from the basket.
Unit is leaking water.	Drain plug not properly sealed; damaged water line.	Ensure drain plug is securely closed; contact customer support.

7. SPECIFICATIONS

- **Brand:** Silonn
- **Model Name:** SLICM54ST-US
- **Product Dimensions:** 15.04"D x 9.45"W x 14.96"H
- **Capacity:** 2 Liters (water tank)
- **Wattage:** 185 watts
- **Voltage:** 115 Volts
- **Refrigerant:** R600a
- **Material Type:** Stainless Steel
- **UPC:** 840478836615

8. WARRANTY AND SUPPORT

Silonn products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Silonn website. Do not attempt to repair the appliance yourself, as this may void the warranty and pose safety risks.