

[Manuals.plus](#) /

› [Superday](#) /

› Superday 10-15 Gun Safe Instruction Manual (Model 10 Keyboard Gun Safe)

Superday 10 Keyboard Gun Safe

Superday 10-15 Gun Safe Instruction Manual

MODEL: 10 KEYBOARD GUN SAFE

Brand: Superday

INTRODUCTION

This manual provides essential instructions for the safe and proper use of your Superday 10-15 Gun Safe. Designed for secure storage of rifles and pistols, this safe features high-density cold-rolled steel construction, a reliable electronic keyboard lock, and versatile interior organization. Please read all instructions carefully before assembly and operation to ensure optimal security and functionality.

SETUP AND ASSEMBLY


The Superday 10-15 Gun Safe is designed for straightforward assembly. Before beginning, carefully check all parts against the included list. The assembly process involves securing the panels and installing interior components. For enhanced security, the safe includes pre-drilled holes for mounting to a wall or floor using the provided anchor bolts.

DESIGNED FOR GUNS

H 55.2 IN

W 21.0 IN

L 15.2 IN



1 x Gray Carpet



4 x Anchor Bolts



2 x Emergency Keys



Image: Superday 10-15 Gun Safe dimensions and included accessories. This image illustrates the external dimensions of the safe (55.2"H x 21.0"W x 15.2"D) and highlights included components such as 1x Gray Carpet, 4x Anchor Bolts, and 2x Emergency Keys.

Video: This video provides detailed instructions for the assembly of the Superday 10-15 Gun Safe, including step-by-step guidance for putting together the main components.

Video: Watch this video for a visual guide on how to assemble and securely fix the Superday 10-15 Gun Safe to a wall or floor, ensuring maximum stability and security.

OPERATING THE LOCKING MECHANISM

Your Superday gun safe is equipped with an electronic lock for quick and secure access. It offers multiple access methods: a digital password, an override key, and a backup power box for emergencies. Always store emergency keys in a secure location outside the safe. If the batteries run out, the override key can be used to open the safe.



Image: Three ways to access the Superday 10-15 Gun Safe: digital password, override key, and backup power box with code. This graphic illustrates the keypad for digital password entry, the keyhole for manual override, and the external battery port for emergency power.

Video: This video demonstrates the process of setting and changing the digital password for your Superday 10-15 Gun Safe's electronic lock.

STORAGE AND FEATURES

The Superday 10-15 Gun Safe offers ample storage with dimensions of 15.2"D x 21"W x 55.21"H, capable of holding 10-15 rifles. It features 3 adjustable racks that can be customized to fit your specific firearm lengths. Additionally, 6 pockets on the inside of the door provide convenient storage for pistol bags and ammunition boxes.




Image: Interior view of Superday 10-15 Gun Safe with adjustable shelves, gun racks, and door pockets. This image showcases the organized interior with rifles stored vertically, adjustable shelving, and multiple door pockets for smaller items.

SPECIFICATIONS

Feature	Detail
Brand	Superday
Model	10 Keyboard Gun Safe
Product Dimensions	15.2"D x 21"W x 55.21"H
Material	High-density cold-rolled steel
Special Features	Alarm System, Anti-Theft, Removable Shelf
Mounting Type	Floor Mount
Locking Mechanism	Electronic Keyboard Lock with Override Key

Feature	Detail
Capacity	10-15 Rifles
UPC	784227750114

MAINTENANCE

To ensure the longevity and proper functioning of your Superday gun safe, regular maintenance is recommended. Keep the safe clean by wiping it with a soft, dry cloth. Avoid using abrasive cleaners. Periodically check the battery level of the electronic lock and replace batteries as needed to prevent lockout. Ensure emergency keys are stored securely and are accessible only to authorized individuals.

TROUBLESHOOTING

- **Electronic Lock Failure:** If the electronic lock is unresponsive, check the batteries. If batteries are depleted, use the backup power box or the emergency key to open the safe.
- **Forgotten Password:** If you forget your digital password, use the emergency key to access the safe and reset the password according to the instructions in the manual.
- **Door Not Closing Properly:** Ensure no items are obstructing the door or the locking bolts. Check that the safe is level and securely mounted.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact Superday customer support. If you encounter any problems or have questions regarding your gun safe, please reach out to the manufacturer's customer service for assistance. Keep your purchase receipt and model information handy when contacting support.