

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FOHERE](#) /

› [FOHERE Slush Machine User Manual \(Model ISM-1001\)](#)

FOHERE ISM-1001

FOHERE Slush Machine User Manual

Model: ISM-1001

1. INTRODUCTION

Thank you for choosing the FOHERE Slush Machine. This appliance is designed to create a variety of refreshing frozen beverages, including slushies, milkshakes, and frozen cocktails, with ease and efficiency. Its innovative rapid freezing technology eliminates the need for ice, simplifying the preparation process. Please read this manual thoroughly before operating the machine to ensure safe and optimal performance. Keep this manual for future reference.



The FOHERE Slush Machine, ready to create a variety of frozen beverages in a modern kitchen environment.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure proper ventilation: Maintain a minimum distance of 15 cm (6 inches) between the appliance (top, left, right, and rear sides) and surrounding cabinets or walls to ensure sufficient heat dissipation.

3. PRODUCT OVERVIEW AND COMPONENTS

The FOHERE Slush Machine is designed for user-friendly operation with a clear liquid container and intuitive controls.




The FOHERE Slush Machine, highlighting its main components.

Key Features:

- **Rapid Freezing Technology:** No ice cubes required for operation.
- **5 Intelligent Programs:** Optimized settings for various frozen drinks.
- **Generous 2.6 Liter Capacity:** Ideal for preparing multiple servings.
- **Self-Cleaning Function:** Simplifies post-use cleanup.
- **12-Hour Cold Lock:** Maintains drink consistency for extended periods.
- **Compact Design:** Space-saving dimensions for various counter spaces.

Say Goodbye to Complicated Panels



The intuitive control panel for selecting drink modes and settings.

4. INITIAL SETUP

1. **Unpacking:** Carefully remove the machine from its packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the machine on a stable, flat, and dry surface. Ensure there is at least 15 cm (6 inches) of clear space around the top, left, right, and rear sides of the appliance for adequate ventilation.
3. **Initial Resting Period:** After receiving the appliance, allow it to stand upright for 24 hours before first

use. This allows the refrigerant to settle.

4. **First Cleaning:** Before first use, clean all removable parts that will come into contact with food. Refer to the "Maintenance and Cleaning" section for detailed instructions.
5. **Power Connection:** Ensure the voltage specified on the appliance matches your local power supply before plugging it in.

5. OPERATION

5.1 Preparing Your Drink

1. **Add Ingredients:** Pour your desired liquid ingredients into the main container. The machine has a generous 2.6-liter capacity.
2. **Ingredient Recommendations:** For optimal taste and texture, it is recommended to use liquids with a sugar content of at least 5%. For alcoholic beverages, an alcohol content between 2.8% and 16% is suggested.



Simple three-step process for making frozen drinks.

5.2 Selecting a Program

The FOHERE Slush Machine features 5 intelligent pre-programmed modes for perfect consistency:

- **Slush:** For classic frozen fruit drinks.
- **Frappe:** For coffee or chocolate-based frozen beverages.
- **Milkshake:** For creamy, thick milkshakes.
- **Spiked Slush:** For alcoholic slushies.
- **Frozen Cocktail:** For various frozen mixed drinks like margaritas.

Press the corresponding button on the control panel to select your desired program. The machine will automatically mix and freeze the ingredients to the ideal consistency.

Your Drink Master: 5 Modes Infinite Creations



Explore a World of Flavors with
5 Customizable Temperatures



Family Moment



Outdoor Party



Daily Use



Holiday Gatherings

The five intelligent programs available for diverse frozen drink creations.

5.3 Freezing Process

The rapid freezing technology allows you to enjoy creamy slush in approximately 15 to 45 minutes, depending on the selected program and initial temperature of ingredients. The machine operates without the need for ice, ensuring the original flavor is not diluted.

Rapid Cooling in as Little as 15 Mins

Get Icy Drinks in Minutes, and Enjoy Them for Hours



12:00
Add Ingredients



12:45
Production Completed



Rapid cooling allows for quick preparation of icy drinks.

5.4 Serving and Cold Lock Function

Once the program is complete, your frozen beverage is ready to serve. The machine's superior insulation maintains the slush perfectly cooled and consistent for up to 12 hours, making it suitable for parties or extended enjoyment.

Stay Icy & Fresh: 12-Hour Cold Lock

Enjoy a Perfectly Chilled Smoothie All Day Long



The 12-hour cold lock feature keeps your drinks perfectly chilled.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your FOHERE Slush Machine.

6.1 Self-Cleaning Function

After use, the machine's Auto-Clean function simplifies the cleaning process. Follow these steps:

1. Empty any remaining liquid from the container.

2. Fill the container with clean water and a small amount of mild detergent.
3. Select the 'Auto-Clean' program (refer to your control panel for the specific button).
4. Allow the cycle to complete.
5. Drain the cleaning solution and rinse the container thoroughly with clean water.

6.2 Dishwasher Safe Parts

Many removable parts of the FOHERE Slush Machine are dishwasher safe for maximum convenience. Refer to the product diagram to identify these parts. Always ensure parts are completely dry before reassembling.



Self-clean & Dishwasher Safe

Spend less time cleaning, enjoy more time sipping

 3S  5Mins


Easy to Rinse


Dishwasher Safe

The self-clean function and dishwasher-safe components make cleaning effortless.

6.3 General Cleaning

- Wipe the exterior of the machine with a damp cloth. Do not use abrasive cleaners or scourers.
- Ensure no water enters the electrical components.
- Always unplug the machine before cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your FOHERE Slush Machine, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outlet malfunction; Power switch off	Check power cord connection; Test outlet with another appliance; Ensure power switch is on
Liquid not freezing	Insufficient freezing time; Ingredients too warm; Low sugar content in liquid	Allow more time for freezing; Use chilled ingredients; Ensure liquid has at least 5% sugar content
Slush is too watery	Incorrect program selected; Low sugar content	Select appropriate program for desired consistency; Adjust sugar content of ingredients
Machine is noisy	Normal operation sound; Machine not on a flat surface	Some operational noise is normal; Ensure machine is on a stable, flat surface
Self-clean function not working	Container not filled with water/detergent; Program not selected correctly	Ensure container is filled; Re-select the self-clean program

If the problem persists after attempting these solutions, please contact FOHERE customer support.

8. SPECIFICATIONS

Big on Capacity, Small on Size

Small Footprint, Giant Results

Liquid Capacity

 OR  = 68 OZ
2L Soda 6 Cans

Holds up to **88** ounces
— perfect for making
giant batches



Dimensions and capacity of the FOHERE Slush Machine.

Feature	Detail
Brand	FOHERE
Model Number	ISM-1001
Color	Bean Green
Dimensions (L x W x H)	18.3 x 42.7 x 43 cm (7.2 x 16.8 x 16.9 inches)

Feature	Detail
Capacity	2.6 Liters (approx. 88 oz)
Power	800 Watts
Voltage	220 Volts
Material	Plastic
Item Weight	12.7 Kilograms (27.9 lbs)
UPC	762765695715
Recommended Use	Domestic

9. WARRANTY AND SUPPORT

FOHERE products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the documentation included with your purchase or visit the official FOHERE website. Please have your model number (ISM-1001) and purchase date available when contacting support.