

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [OLEVS](#) /
- › [OLEVS Men's Analog Quartz Watch 5653nanshi Instruction Manual](#)

### OLEVS 5653nanshi

# OLEVS Men's Analog Quartz Watch 5653nanshi Instruction Manual

Model: 5653nanshi

## INTRODUCTION

---

Thank you for purchasing the OLEVS Men's Analog Quartz Watch, model 5653nanshi. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image: OLEVS Men's Analog Quartz Watch, model 5653nanshi, featuring a blue dial and black mesh band, worn on a wrist.

## SETUP

---

### Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch) to the first click position to set the date, or to the second click position to set the time.
2. **Adjust the date:** If the crown is in the first click position, turn it clockwise or counter-clockwise to adjust the date.
3. **Adjust the time:** If the crown is in the second click position, turn it to set the hour and minute hands. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator or if you are setting the date.
4. **Push in the crown:** Once the time and date are set, push the crown back into its normal operating position. This will start the watch movement.



Image: A close-up view of the OLEVS watch on a wrist, highlighting the crown used for setting the time and date.

## Adjusting the Band

This watch is available with either a black leather strap or a black mesh band. Adjustments vary by band type.

- **Leather Strap:** The leather strap features a standard buckle clasp. Adjust the strap by selecting the appropriate hole for a comfortable fit on your wrist.
- **Mesh Band:** The mesh band typically uses an adjustable clasp. To adjust, lift the locking plate on the clasp, slide the clasp along the mesh band to your desired length, and then press the locking plate back down firmly to secure it. Ensure the clasp is securely fastened to prevent accidental opening.



30メートル防水



純正石英ムーブメント



高硬度コーティング鏡面



ミラニスベルト

Image: A collage displaying various features of the OLEVS watch, including a detailed view of the mesh band and its adjustable clasp mechanism.

## OPERATING THE WATCH

---

### Reading the Time and Date

The watch features a clear analog display with Arabic numerals for easy readability. The date is displayed in a window at the 3 o'clock position.

### Luminous Function

The watch hands are equipped with a luminous coating, allowing you to read the time in low-light conditions or darkness. Exposure to light will charge the luminous material.

# HDナイトライト機能

高配置の好ましい材質、高精細夜光コーティング、  
吸収が短く、発光が強い



Image: The OLEVS watch dial illuminated in the dark, demonstrating its luminous hands and hour markers for visibility in low light.

## Water Resistance

This watch is designed with 50-meter (5 ATM) water resistance. This means it is suitable for daily use, such as hand washing, splashes, and brief immersion in water. It is not recommended for swimming, diving, or showering with hot water, as steam and temperature changes can compromise the seals.

## 腕時計の展示



Image: The OLEVS watch shown with water splashing, indicating its water-resistant capabilities for everyday activities.

## MAINTENANCE

---

### Cleaning Your Watch

- Wipe the watch case and crystal with a soft, dry cloth regularly to remove dust and fingerprints.
- For mesh bands, a soft brush can be used to gently clean between the links. For leather straps, avoid excessive moisture.
- Do not use chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish or seals.

### Battery Replacement

The watch is powered by a quartz movement, which requires a battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is maintained.

### Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original packaging or a watch box is ideal for protection.

## TROUBLESHOOTING

---

- **Watch not running:** Ensure the crown is fully pushed in. If it still doesn't run, the battery may need replacement.
- **Date not changing:** Check if the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight.
- **Condensation inside the crystal:** This may indicate a breach in the water resistance. Avoid further

contact with water and seek professional service immediately.

- **Inaccurate timekeeping:** While quartz watches are highly accurate, significant deviation may indicate a low battery or a need for servicing.

For issues not resolved by these steps, please contact customer support.

## SPECIFICATIONS

PRODUCT PARAMETERS | 製品パラメータ |



**Product Size**

(調把を含まず)	
ケース径:	40mm
(顕微鏡を含む)	
ケースの厚さ:	8MM
バンド幅:	20MM
バンド周長:	鋼:21CM 皮:21CM

  

ブランドモデル:	OLEVS/5653
表 鏡:	高硬度コーティング鏡面
バ ン ド:	ミラノニース鋼ベルト/通気革ベルト
ムーブメント:	石英ムーブメント
防 水:	30メートル防水
腕時計の重量:	鋼67皮38 g

暖かい注意: 人工測定データは参考にして、実物を基準にして!

Image: Detailed product parameters and dimensions for the OLEVS watch, including case diameter, thickness, and band width.

Feature	Detail
Brand	OLEVS
Model Number	5653nanshi
Movement	Quartz
Display Type	Analog

Feature	Detail
Case Material	Stainless Steel
Case Diameter	40 mm
Case Thickness	8 mm
Band Material	Stainless Steel (Mesh) / Leather
Band Width	20 mm
Dial Color	Blue
Clasp Type	Buckle
Water Resistance	50 Meters (5 ATM)
Item Weight	42 grams
Crystal Material	High-hardness Mineral Glass
Special Features	Date Display, Luminous Hands

## WARRANTY INFORMATION

---

This OLEVS watch comes with a **1-year warranty** from the date of purchase. The warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover:

- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Water damage if the watch was used beyond its specified water resistance limits or if the crown was not fully pushed in.
- Battery replacement.
- Damage to the strap or crystal.

To claim warranty service, please retain your proof of purchase and contact customer support.

## SUPPORT

---

For any questions, technical assistance, or warranty claims regarding your OLEVS watch, please contact our customer support team. Refer to the retailer's contact information or the official OLEVS website for support details.

**Online Resources:** For additional information and product updates, please visit the official OLEVS brand store: [OLEVS Brand Store](#)