

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VEVOR](#) /

› [VEVOR Weighted Digital Piano S186 User Manual](#)

## VEVOR S186

# VEVOR Weighted Digital Piano S186 User Manual

Model: S186 | Brand: VEVOR

## INTRODUCTION

---

This manual provides essential information for the proper setup, operation, and maintenance of your VEVOR Weighted Digital Piano. Please read it thoroughly before using the product to ensure safe and efficient operation.

The VEVOR Weighted Digital Piano features a full-size 88-key fully weighted keyboard with hammer action and 3-level touch sensitivity, designed to simulate the feel of an acoustic piano. It is equipped with a French DREAM sound engine and a dual speaker system for high-fidelity audio. The piano supports wireless connectivity and various apps, offering 600 rhythms, 680 tones, and 200 demo songs. Its dual keyboard design facilitates learning and teaching, and its modern, minimalist aesthetic complements any home decor.

## SETUP

---

### Unpacking and Assembly

Carefully unpack all components from the packaging. Ensure all parts listed in the packing list are present and undamaged. Assembly typically involves attaching the main keyboard unit to the furniture stand and connecting the triple pedal unit.



This image illustrates the realistic touch and feel of the 88 fully weighted keys with hammer action and 3-level touch sensitivity, providing an authentic piano playing experience.


## Connections

Connect the power adapter to the DC input port on the piano and then to a power outlet. Connect the triple pedal unit to the designated pedal socket. For private practice, plug headphones into the dual headphone jacks. Additional connectivity options include USB for MIDI transmission and audio output.

# Intuitive Control, Versatile Connectivity



Clear & Easy Operation



Seamlessly Connect to Phone, Tablet, Headphones, Pedals

The control panel provides clear and easy operation. Connectivity options include USB, audio output, extension pedal socket, USB transmission, dual headphone jack, and triple pedal socket for seamless connection to phones, tablets, headphones, and pedals.

## OPERATING INSTRUCTIONS

### Power On/Off and Volume Control

Locate the power button on the control panel and press it to turn the piano on or off. Adjust the master volume using the dedicated volume knob to your desired level.

### Selecting Tones and Rhythms

The piano offers 680 tones and 600 rhythms. Use the 'Tone' and 'Rhythm' selection buttons on the control

panel to browse and select different instrument sounds and accompaniment patterns. The integrated dual speaker system ensures rich, high-fidelity sound reproduction.



The digital piano features a dual speaker system and a French DREAM sound engine, delivering rich, clear, and full-bodied audio that accurately reproduces grand piano tones.

### **Demo Songs and Learning Features**

Access 200 built-in demo songs for inspiration and practice. The piano supports wireless connectivity, allowing integration with various learning apps and devices for an enhanced smart learning experience. The dual keyboard design enables teachers to guide students effectively.

# Play Together Make Practice Fun

Boost coordination & rhythm skills



**600**  
Rhythms



**680**  
Tones



**200**  
Demo Songs



**Before Use:**  
Peel off the key  
protection tape

• Bench Not Included

Two individuals playing the VEVOR digital piano in dual keyboard mode, highlighting the 600 rhythms, 680 tones, and 200 demo songs available for learning and practice.

# Smart Learning Made Easy

Built-in Recording  
Function



Wireless Connectivity  
Support



This image shows the piano's smart learning capabilities, including wireless connectivity to various apps and devices, and a built-in recording function.

## Recording Function

Utilize the built-in recording function to capture your performances. Refer to the control panel for specific record and playback buttons.

## Metronome and Tempo

Engage the metronome function to assist with timing and rhythm practice. Adjust the tempo to match your practice needs.

## Transpose Function

Use the transpose function to shift the pitch of the keyboard up or down, allowing you to play in different keys without changing your finger positions.

## Pedal Usage

The triple pedal unit includes Soft, Sostenuto, and Sustain pedals, providing expressive control over your music, similar to an acoustic piano.

Your browser does not support the video tag.

This official VEVOR video provides an overview of the Weighted Digital Piano, demonstrating its features and sound quality. It highlights the realistic touch, sound engine, and smart learning capabilities.

## MAINTENANCE

---

### Cleaning and Care

To maintain the appearance and functionality of your digital piano, regularly wipe the keys and surfaces with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish. Keep the piano away from direct sunlight, extreme temperatures, and high humidity.

### Storage

When not in use, it is recommended to cover the piano with the provided piano cover to protect it from dust and debris.

## TROUBLESHOOTING

---

### No Sound

- Ensure the piano is powered on and the volume is turned up.
- Check if headphones are plugged in; if so, unplug them or adjust headphone volume.
- Verify that the power adapter is securely connected.

### Keys Not Responding

- Check for any foreign objects lodged between the keys.
- Ensure the piano is powered on and not in a demo mode that might restrict manual play.

### Pedals Not Functioning


- Confirm that the triple pedal unit is correctly plugged into the designated socket.

## SPECIFICATIONS

---

Feature	Detail
Model Number	S186
Number of Keys	88
Key Type	Fully Weighted with Hammer Action, 3-level Touch Sensitivity

	Connectivity
Tones	680
Rhythms	600
Demo Songs	200
Sound Engine	French DREAM
Speakers	Dual Speaker System
Connectivity	Wireless Connection, USB, Audio Output, Headphone Jacks
Recording Function	Built-in
Pedals	Triple Pedal Unit (Soft, Sostenuto, Sustain)
Net Weight	61.7 lbs (28 kg)
Product Dimensions (with Sheet Music Stand)	53.9 x 12.2 x 29.1 inches (1370 x 310 x 740 mm)



Recording Function: **Built-in**

Wireless Connection: **Supported**

Net Weight: **66.3 lbs/30.1 kg (Including Accessories)**

Product Dimensions (with Sheet Music Stand):

**53.9 x 12.2 x 29.1 in/1370 x 310 x 740 mm**

The piano's dimensions are 53.9 x 12.2 x 29.1 inches (1370 x 310 x 740 mm) with the sheet music stand. Included accessories are 1x Headphones, 1x MIDI Cable, 1x DC Adapter & Power Cable, 1x Sheet Music Clip, 1x Piano Stickers, and 1x Piano Cover.

## WARRANTY AND SUPPORT

---

### Warranty Information

For detailed warranty information, please refer to the documentation included with your product or contact VEVOR customer support.

### Customer Support

If you encounter any issues or have questions regarding your VEVOR Weighted Digital Piano, please contact our customer support team for assistance. Contact details can be found on the VEVOR official website or in your product packaging.