

DUMOS FP203R-T3-P

DUMOS 26-inch Freestanding Electric Fireplace Heater Instruction Manual

Model: FP203R-T3-P

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this electric fireplace heater. Failure to follow these instructions may result in fire, electric shock, or injury.

- **Electrical Safety:** Ensure the power outlet matches the voltage requirements of the heater. Do not overload circuits.
- **Placement:** Position the heater on a firm, level surface. Maintain a minimum distance of 3 feet (0.9 meters) from combustible materials such as furniture, curtains, bedding, paper, clothes, and other objects.
- **Ventilation:** Do not block air vents. Ensure proper airflow around the heater.
- **Overheat Protection:** This unit is equipped with an automatic overheat protection system. If the heater overheats, it will automatically shut off. Unplug the unit, allow it to cool for 15 minutes, then plug it back in. If it continues to shut off, contact customer support.
- **Child Lock:** The unit includes a child lock feature to prevent accidental operation. Refer to the operating instructions for activation and deactivation.
- **Moisture:** Do not use the heater in wet or damp locations, such as bathrooms or laundry areas.
- **Supervision:** Close supervision is necessary when any heater is used by or near children or individuals with reduced physical, sensory, or mental capabilities.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package. If any items are missing or damaged, contact DUMOS customer support.

- DUMOS 26-inch Freestanding Electric Fireplace Heater Unit
- Remote Control
- Instruction Manual

- Legs (4 pieces)
- Mounting Hardware for Legs

3. SETUP AND ASSEMBLY

The DUMOS Electric Fireplace Heater requires minimal assembly. Follow these steps to prepare your unit for use:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Attach Legs:** Invert the main fireplace unit. Align each of the four legs with the designated mounting points on the bottom of the unit. Secure each leg using the provided mounting hardware (screws). Ensure all screws are tightened firmly to provide stability.
3. **Positioning:** Place the assembled fireplace heater on a stable, level surface. Ensure it is at least 3 feet (0.9 meters) away from any walls, furniture, curtains, or other combustible materials. Do not place it directly under a wall-mounted television or other heat-sensitive electronics.
4. **Power Connection:** Plug the power cord into a grounded 120V AC outlet. Ensure the outlet is not shared with other high-wattage appliances.



Figure 3.1: Front view of the DUMOS Electric Fireplace Heater after assembly.

4. OPERATING INSTRUCTIONS

The DUMOS Electric Fireplace Heater can be operated using the control panel on the unit or the included remote control.

4.1 Control Panel and Remote Control Overview




Figure 4.1: Remote control and integrated control panel on the fireplace unit.

The remote control provides convenient access to all functions. Ensure the remote has working batteries (not included, typically AAA).

- **Power Button:** Turns the unit ON or OFF.
- **Flame Button:** Cycles through flame brightness levels.
- **Timer Button:** Activates and adjusts the 1-12 hour timer.
- **Up/Down Buttons:** Adjust temperature settings or timer duration.
- **Heater Button:** Toggles heating function ON/OFF or adjusts heat levels.

4.2 Initial Power On

1. Ensure the unit is properly plugged into a grounded outlet.
2. Locate the master power switch, usually at the bottom or rear of the unit, and switch it to the 'ON' position.
3. Press the 'Power' button on the control panel or remote control to turn on the fireplace. The flame effect will activate.

4.3 Adjusting Flame Effect

The fireplace features a 3D flame effect with adjustable brightness levels.

1. Press the 'Flame' button on the remote or control panel.
2. Each press will cycle through different brightness settings (e.g., Off, Level 1, Level 2, Level 3, Level 4). Select your desired brightness.



Figure 4.2: Visual representation of the 5 adjustable flame brightness levels.

4.4 Setting the Heat Output

The heater provides efficient warmth with adjustable temperature settings.

1. Press the 'Heater' button on the remote or control panel to activate the heating function.
2. Use the 'Up' and 'Down' buttons to adjust the desired temperature. The temperature range is typically 59°F to 95°F.
3. The heater operates at 750W or 1500W, automatically adjusting based on the selected temperature and room conditions.



Figure 4.3: The heater provides adjustable warmth within a specified temperature range.

4.5 Using the 12-Hour Timer

The integrated timer allows for automatic shut-off, promoting energy efficiency.

1. Press the 'Timer' button on the remote or control panel.
2. Use the 'Up' and 'Down' buttons to set the desired operating duration, from 1 to 12 hours.
3. The unit will automatically turn off after the set time has elapsed.

Product Dimension




Figure 4.4: The 12-hour timer function helps manage energy consumption.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Periodically vacuum or wipe dust from the air intake and exhaust vents to maintain efficient airflow.
- **Storage:** If storing the heater for an extended period, unplug it and store it in a cool, dry place, preferably in its original packaging.
- **No User-Serviceable Parts:** Do not attempt to open or repair the unit yourself. Refer all servicing to qualified service personnel.

6. TROUBLESHOOTING

If you encounter issues with your DUMOS Electric Fireplace Heater, consult the following table before contacting customer support.

Problem	Possible Cause	Solution
Unit does not turn on.	No power to the unit; Master power switch is off; Remote control batteries are dead.	Check power cord connection and wall outlet; Ensure master power switch is ON; Replace remote control batteries.
No heat output.	Heater function is off; Temperature setting is too low; Overheat protection activated.	Press the 'Heater' button; Increase the temperature setting; Unplug, wait 15 minutes, then plug back in.
Flame effect not working.	Flame effect is turned off; Unit is off.	Press the 'Flame' button to cycle through settings; Ensure the unit is powered on.
Unit repeatedly shuts off.	Overheat protection activated; Blocked air vents.	Unplug, wait 15 minutes, then plug back in; Clear any obstructions from air vents. If problem persists, contact support.

7. SPECIFICATIONS

Feature	Detail
Brand	DUMOS
Model Name	DUMOS Electric Fireplace Heater
Item Model Number	FP203R-T3-P
UPC	753747462173
Power Source	Corded Electric
Product Dimensions	13.78"D x 20.2"W x 26"H
Installation Type	Floor Mount (Freestanding)
Heat Output	1500 Watts (5000 BTU)
Adjustable Temperature Range	59°F - 95°F
Special Features	3D Flame Effect, Overheat Protection, 12-Hour Timer, Remote Control, Child Lock
Finish Type	Painted
Item Weight	25.8 pounds

8. WARRANTY AND SUPPORT


DUMOS products are manufactured to high-quality standards. For warranty information or technical

assistance, please contact DUMOS customer support through the retailer where the product was purchased or visit the official DUMOS website. Please have your model number (FP203R-T3-P) and proof of purchase available when contacting support.

© 2025 DUMOS. All rights reserved.

Related Documents - FP203R-T3-P

	<p>Electric Standing Desk D-THO-4024 Assembly and Operation Manual</p> <p>Comprehensive guide for assembling and operating the D-THO-4024 electric standing desk, including specifications, step-by-step instructions, controller usage, and error code troubleshooting.</p>
	<p>DUMOS C-2193 Office Chair Assembly and Instruction Manual</p> <p>Comprehensive guide for assembling and using the DUMOS C-2193 office chair. Includes safety information, package contents, step-by-step assembly instructions, and usage guidelines.</p>
	<p>L Shaped Computer Desk Assembly and Instruction Manual</p> <p>Comprehensive instruction manual for assembling the L Shaped Computer Desk, model D-L02-49IN, including component lists, hardware details, and step-by-step assembly guidance.</p>
	<p>Ice Maker Instruction Manual - WBJ-10A</p> <p>Instruction manual for the WBJ-10A ice maker, covering safety information, product introduction, usage instructions, troubleshooting, and technical specifications. Learn how to operate and maintain your ice maker.</p>
	<p>DUMOS C-2193 Armless Office Chair Assembly and Usage Instructions</p> <p>Detailed assembly instructions and user guide for the DUMOS C-2193 armless office chair. Learn how to assemble your PU leather desk chair, understand safety precautions, and find maintenance tips for longevity.</p>



[Electric Fireplace Instruction Manual - QBL Models](#)

Comprehensive instruction manual for QBL-X36IN-BK, QBL-Z50IN-BK, and QBL-D60IN-BK electric fireplaces, covering safety, specifications, operation, installation, and maintenance.